

# **Agilent X-Series Signal Generators**

**N5181B/82B MXG  
N5171B/72B EXG**

**User's Guide**



**Agilent Technologies**

# Notices

© Agilent Technologies, Inc. 2012

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Agilent Technologies, Inc. as governed by United States and international copyright laws.

## Manual Part Number

N5180-90056

## Edition

July 2012

Printed in USA

Agilent Technologies, Inc.  
3501 Stevens Creek Blvd.  
Santa Clara, CA 95052 USA

## Warranty

**The material contained in this document is provided “as is,” and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.**

## Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

## Restricted Rights Legend

U.S. Government Restricted Rights. Software and technical data rights granted to the federal government include only those rights customarily provided to end user customers. Agilent provides this customary commercial license in Software and technical data pursuant to FAR 12.211 (Technical Data) and 12.212 (Computer Software) and, for the Department of Defense, DFARS 252.227-7015 (Technical Data - Commercial Items) and DFARS 227.7202-3 (Rights in Commercial Computer Software or Computer Software Documentation).

## Safety Notices

### CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

---

### WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

---

**1 Signal Generator Overview**

|   |    |
|---|----|
| Signal Generator Features . . . . .                               | 2  |
| Modes of Operation . . . . .                                      | 4  |
| Continuous Wave . . . . .   | 4  |
| Swept Signal . . . . .  | 4  |
| Analog Modulation . . . . .                                       | 4  |
| Digital Modulation (Vector Models with Option 65x Only) . . . . . | 4  |
| Front Panel Overview . . . . .                                    | 5  |
| 1. Host USB . . . . .   | 5  |
| 2. Display . . . . .  | 5  |
| 3. Softkeys . . . . .   | 6  |
| 4. Numeric Keypad . . . . .                                       | 6  |
| 5. Arrows and Select. . . . .                                     | 6  |
| 6. Page Up . . . . .  | 6  |
| 7. MENUS . . . . .  | 6  |
| 8. Trigger . . . . .  | 7  |
| 9. Local Cancel/(Esc) . . . . .                                   | 7  |
| 10. Help . . . . .  | 7  |
| 11. Preset and User Preset. . . . .                               | 7  |
| 12. RF Output . . . . .   | 7  |
| 13. RF On/Off and LED. . . . .                                    | 7  |
| 14. Mod On/Off and LED. . . . .                                   | 7  |
| 15. Page Down. . . . .  | 7  |
| 16. I Input (vector models only) . . . . .                        | 8  |
| 17. Q Input (vector models only). . . . .                         | 8  |
| 18. Knob. . . . .   | 8  |
| 19. Incr Set . . . . .  | 8  |
| 20. Return . . . . .  | 8  |
| 21. More and LED . . . . .  | 8  |
| 22. Power Switch and LEDs . . . . .                               | 8  |
| . . . . .   | 8  |
| Front Panel Display . . . . .                                     | 9  |
| 1. Active Function Area. . . . .                                  | 9  |
| 2. Frequency Area . . . . .                                       | 9  |
| 3. Annunciators . . . . .   | 9  |
| 4. Amplitude Area . . . . .                                       | 10 |
| 5. Error Message Area. . . . .                                    | 11 |
| 6. Text Area . . . . .  | 11 |
| 7. Softkey Label Area . . . . .                                   | 11 |
| Rear Panel Overview. . . . .                                      | 12 |

---

# Contents

|  |    |
|--|----|
| 1. AC Power Receptacle . . . . .                             | 12 |
| 2. EXT 1 & EXT 2 . . . . .                                   | 13 |
| 3. LF OUT . . . . .  | 13 |
| 4. SWEEP OUT . . . . .                                       | 13 |
| 5. PULSE . . . . .   | 13 |
| 6. TRIG 1 & 2 . . . . .                                      | 13 |
| 7. REF IN . . . . .  | 13 |
| 8. 10 MHz OUT . . . . .                                      | 14 |
| 9. GPIB . . . . .  | 14 |
| 10. LAN . . . . .  | 14 |
| 11. Device USB . . . . .                                     | 14 |
| 12. Host USB . . . . .                                       | 14 |
| 13. SD Card . . . . .  | 14 |
| Digital Modulation Connectors (Vector Models Only) . . . . . | 15 |
| I OUT, Q OUT, OUT, OUT . . . . .                             | 15 |
| BB TRIG 1 & BB TRIG 2 . . . . .                              | 16 |
| EVENT 1 . . . . .  | 16 |
| PAT TRIG . . . . .   | 16 |
| DIGITAL BUS I/O . . . . .                                    | 16 |
| AUX I/O . . . . .  | 17 |

## 2 Setting Preferences & Enabling Options

|   |    |
|---|----|
| User Preferences . . . . .  | 20 |
| Display Settings . . . . .  | 20 |
| Power On and Preset . . . . .                                       | 21 |
| Front Panel Knob Resolution . . . . .                               | 22 |
| Setting Time and Date . . . . .                                     | 22 |
| Reference Oscillator Tune . . . . .                                 | 23 |
| Upgrading Firmware . . . . .  | 23 |
| Remote Operation Preferences . . . . .                              | 24 |
| GPIB Address and Remote Language . . . . .                          | 24 |
| Configuring the LAN Interface . . . . .                             | 25 |
| Enabling LAN Services: “Browser,” “Sockets,” and “VXI-11” . . . . . | 26 |
| Configuring the Remote Languages . . . . .                          | 27 |
| Configuring the Preset Languages . . . . .                          | 28 |
| Enabling an Option . . . . .  | 29 |
| Viewing Options and Licenses . . . . .                              | 30 |
| Hardware Assembly Installation and Removal Softkeys . . . . .       | 31 |
| . . . . .   | 31 |

**3 Basic Operation**

Presetting the Signal Generator. . . . . 34

Viewing Key Descriptions. . . . . 34

Entering and Editing Numbers and Text. . . . . 35

    Entering Numbers and Moving the Cursor. . . . . 35

    Entering Alpha Characters . . . . . 35

    Example: Using a Table Editor . . . . . 36

Setting Frequency and Power (Amplitude) . . . . . 37

    Example: Configuring a 700 MHz, -20 dBm Continuous Wave Output. . . . . 38

    Using an External Reference Oscillator. . . . . 38

Setting ALC Bandwidth Control . . . . . 39

Configuring a Swept Output. . . . . 40

    Routing Signals . . . . . 42

    Step Sweep . . . . . 42

    List Sweep . . . . . 44

    Example: Using a Single Sweep. . . . . 47

    Example: Manual Control of Sweep . . . . . 48

Modulating the Carrier Signal. . . . . 48

    Example . . . . . 48

    Simultaneous Modulation . . . . . 50

Working with Files . . . . . 50

    File Softkeys . . . . . 51

    Viewing a List of Stored Files. . . . . 52

    Storing a File . . . . . 53

    Loading (Recalling) a Stored File. . . . . 55

    Moving a File from One Media to Another . . . . . 56

    Working with Instrument State Files . . . . . 57

    Selecting the Default Storage Media . . . . . 61

Reading Error Messages . . . . . 62

    Error Message Format. . . . . 62

**4 Using Analog Modulation (Option UNT)**

Analog Modulation Waveforms . . . . . 64

Analog Modulation Sources . . . . . 64

Using an Internal Modulation Source. . . . . 66

Using an External Modulation Source . . . . . 67

    Removing a DC Offset . . . . . 67

    Using Wideband AM . . . . . 67

Configuring the LF Output (Option 303). . . . . 69

---

# Contents

|  |     |
|--|-----|
| LF Out Modulation Sources . . . . .                                    | 69  |
| Configuring the LF Output with an Internal Modulation Source . . . . . | 70  |
| Configuring the LF Output with a Function Generator Source . . . . .   | 71  |
| <b>5 Optimizing Performance</b>  |     |
| Using the Dual Power Meter Display . . . . .                           | 74  |
| Example: Dual Power Meter Calibration . . . . .                        | 77  |
| Using Flatness Correction . . . . .                                    | 82  |
| Creating a User Flatness Correction Array . . . . .                    | 84  |
| Recalling and Applying a User Flatness Correction Array . . . . .      | 90  |
| Using Internal Channel Correction . . . . .                            | 91  |
| Configure Internal Channel Correction . . . . .                        | 92  |
| Using External Leveling . . . . .                                      | 93  |
| Option IEQ Output Attenuator Behavior and Use . . . . .                | 96  |
| Configure External Leveling . . . . .                                  | 97  |
| Using Unleveled Operating Modes . . . . .                              | 101 |
| ALC Off Mode . . . . .   | 101 |
| Power Search Mode . . . . .  | 102 |
| Using an Output Offset, Reference, or Multiplier . . . . .             | 104 |
| Setting an Output Offset . . . . .                                     | 104 |
| Setting an Output Reference . . . . .                                  | 105 |
| Setting a Frequency Multiplier . . . . .                               | 106 |
| Using the Frequency and Phase Reference Softkeys . . . . .             | 108 |
| Using Free Run, Step Dwell, and Timer Trigger . . . . .                | 108 |
| Understanding Free Run, Step Dwell, and Timer Trigger Setup . . . . .  | 109 |
| Using a USB Keyboard . . . . .   | 111 |
| <b>6 Using Pulse Modulation (Option UNW or 320)</b>                    |     |
| Pulse Characteristics . . . . .  | 115 |
| The Basic Procedure . . . . .  | 117 |
| Example . . . . .  | 117 |
| Pulse Train (Option 320 – Requires: Option UNW) . . . . .              | 119 |
| <b>7 Basic Digital Operation—No BBG Option Installed</b>               |     |
| I/Q Modulation . . . . .   | 126 |
| Configuring the Front Panel Inputs . . . . .                           | 127 |
| <b>8 Basic Digital Operation (Option 653/655/656/657)</b>              |     |
| Waveform File Basics . . . . .   | 130 |

|  |     |
|--|-----|
| Signal Generator Memory . . . . .                                      | 130 |
| Dual ARB Player . . . . .  | 130 |
| Storing, Loading, and Playing a Waveform Segment . . . . .             | 132 |
| Loading a Waveform Segment into BBG Media . . . . .                    | 132 |
| Storing/Renaming a Waveform Segment to Internal or USB Media . . . . . | 133 |
| Playing a Waveform Segment . . . . .                                   | 133 |
| Waveform Sequences . . . . .   | 135 |
| Creating a Sequence . . . . .  | 136 |
| Viewing the Contents of a Sequence . . . . .                           | 137 |
| Editing a Sequence . . . . .   | 137 |
| Playing a Sequence . . . . .   | 138 |
| Saving a Waveform's Settings & Parameters . . . . .                    | 139 |
| Viewing and Modifying Header Information . . . . .                     | 141 |
| Viewing & Editing a Header without Selecting the Waveform . . . . .    | 143 |
| Using Waveform Markers . . . . .                                       | 145 |
| Waveform Marker Concepts . . . . .                                     | 146 |
| Accessing Marker Utilities . . . . .                                   | 150 |
| Viewing Waveform Segment Markers . . . . .                             | 151 |
| Clearing Marker Points from a Waveform Segment . . . . .               | 151 |
| Setting Marker Points in a Waveform Segment . . . . .                  | 152 |
| Viewing a Marker Pulse . . . . .                                       | 155 |
| Using the RF Blanking Marker Function . . . . .                        | 156 |
| Setting Marker Polarity . . . . .                                      | 158 |
| Controlling Markers in a Waveform Sequence . . . . .                   | 158 |
| Using the EVENT Output Signal as an Instrument Trigger . . . . .       | 161 |
| Triggering a Waveform . . . . .  | 162 |
| Trigger Type . . . . .   | 163 |
| Trigger Source . . . . .   | 164 |
| Example: Segment Advance Triggering . . . . .                          | 165 |
| Example: Gated Triggering . . . . .                                    | 166 |
| Example: External Triggering . . . . .                                 | 168 |
| Clipping a Waveform . . . . .  | 169 |
| How Power Peaks Develop . . . . .                                      | 170 |
| How Peaks Cause Spectral Regrowth . . . . .                            | 172 |
| How Clipping Reduces Peak-to-Average Power . . . . .                   | 173 |
| Configuring Circular Clipping . . . . .                                | 176 |
| Configuring Rectangular Clipping . . . . .                             | 177 |
| Scaling a Waveform . . . . .   | 178 |

---

# Contents

|  |     |
|--|-----|
| How DAC Over-Range Errors Occur . . . . .  | 179 |
| How Scaling Eliminates DAC Over-Range Errors . . . . .   | 180 |
| Setting Waveform Runtime Scaling. . . . .  | 181 |
| Setting Waveform Scaling. . . . .  | 182 |
| Setting the Baseband Frequency Offset . . . . .  | 184 |
| DAC Over-Range Conditions and Scaling . . . . .  | 186 |
| I/Q Modulation . . . . .   | 188 |
| Using the Rear Panel I and Q Outputs. . . . .  | 190 |
| Configuring the Front Panel Inputs. . . . .  | 191 |
| I/Q Adjustments . . . . .  | 192 |
| I/Q Calibration . . . . .  | 194 |
| Using the Equalization Filter . . . . .  | 196 |
| Using Finite Impulse Response (FIR) Filters in the Dual ARB Real-Time Modulation Filter. . . . .                   | 198 |
| Creating a User-Defined FIR Filter Using the FIR Table Editor . . . . .  | 199 |
| Modifying a FIR Filter Using the FIR Table Editor. . . . .   | 204 |
| Loading the Default Gaussian FIR File. . . . .   | 205 |
| Modifying the Coefficients . . . . .   | 206 |
| Storing the Filter to Memory . . . . .   | 207 |
| Setting the Real-Time Modulation Filter. . . . .   | 208 |
| Multiple Baseband Generator Synchronization. . . . .   | 209 |
| Understanding the Master/Slave System . . . . .  | 212 |
| Equipment Setup . . . . .  | 213 |
| Configuring the Setup. . . . .   | 213 |
| Making Changes to the Multiple Synchronization Setup and Resynchronizing the Master/Slave System. . . . .          | 215 |
| Understanding Option 012 (LO In/Out for Phase Coherency) with Multiple Baseband Generator Synchronization. . . . . | 216 |
| Configuring the Option 012 (LO In/Out for Phase Coherency) with MIMO . . . . .                                     | 216 |
| Real-Time Applications. . . . .  | 220 |
| Waveform Licensing . . . . .   | 221 |
| Understanding Waveform Licensing . . . . .   | 221 |
| Installing an Option N5182-22x or Option N5182B-25x . . . . .  | 221 |
| Licensing a Signal Generator Waveform . . . . .  | 221 |
| <b>9 Adding Real-Time Noise to a Signal (Option 403)</b>   |     |
| Adding Real-Time Noise to a Dual ARB Waveform. . . . .   | 229 |
| Eb/No Adjustment Softkeys for Real Time I/Q Baseband AWGN . . . . .  | 232 |
| Using Real Time I/Q Baseband AWGN. . . . .   | 235 |



**10 Real-Time Phase Noise Impairments (Option 432)**

Real-Time Phase Noise Impairment . . . . . 238

The Agilent X-Series Phase Noise Shape and Additive Phase Noise Impairments . . . . . 239

Understanding the Phase Noise Adjustments . . . . . 241

DAC Over-Range Conditions and Scaling . . . . . 242

**11 Custom Digital Modulation (Option 431)**

Custom Modulation . . . . . 244

    ARB Custom Modulation Waveform Generator . . . . . 244

    Real-Time Custom Modulation Waveform Generator . . . . . 244

Creating and Using Bit Files . . . . . 252

    Creating a User File . . . . . 253

    Renaming and Saving a User File . . . . . 255

    Recalling a User File . . . . . 256

    Modifying an Existing User File . . . . . 256

    Applying Bit Errors to a User File . . . . . 257

Using Customized Burst Shape Curves . . . . . 258

    Understanding Burst Shape . . . . . 258

    Creating a User-Defined Burst Shape Curve . . . . . 261

    Storing a User-Defined Burst Shape Curve . . . . . 263

    Recalling a User-Defined Burst Shape Curve . . . . . 263

Using the Arbitrary Waveform Generator . . . . . 265

    Using Predefined Custom Digital Modulation . . . . . 265

    Creating a Custom Digital Modulation State . . . . . 267

    Storing a Custom Digital Modulation State . . . . . 269

    Recalling a Custom Digital Modulation State . . . . . 271

    Defining a Modulation . . . . . 272

    Creating a Custom Multicarrier Digital Modulation State . . . . . 278

    Storing a Custom Multicarrier Digital Modulation State . . . . . 280

    Applying Changes to an Active Multicarrier Digital Modulation State . . . . . 280

Using Finite Impulse Response (FIR) Filters with Custom Modulation . . . . . 281

    Understanding FIR Filters . . . . . 281

    Creating a User-Defined FIR Filter Using the FIR Table Editor . . . . . 283

Modifying a FIR Filter Using the FIR Table Editor . . . . . 287

    Loading the Default Gaussian FIR File . . . . . 288

    Modifying the Coefficients . . . . . 289

    Storing the Filter to Memory . . . . . 290

Differential Encoding . . . . . 290

    Using Differential Encoding . . . . . 294

---

# Contents

## 12 Multitone and Two-Tone Waveforms (Option 430)

|  |     |
|--|-----|
| Creating a Custom Two-Tone Waveform . . . . .            | 297 |
| Creating a Custom Multitone Waveform . . . . .           | 297 |
| Using Two-Tone Modulation . . . . .                      | 297 |
| Two-Tone Modulation Softkeys . . . . .                   | 298 |
| Creating a Two-Tone Waveform . . . . .                   | 298 |
| Viewing a Two-Tone Waveform . . . . .                    | 299 |
| Minimizing Carrier Feedthrough . . . . .                 | 300 |
| Changing the Alignment of a Two-Tone Waveform . . . . .  | 301 |
| Using Multitone Modulation . . . . .                     | 303 |
| Multitone Modulation Softkeys . . . . .                  | 303 |
| Initializing the Multitone Setup Table Editor . . . . .  | 303 |
| Configuring Tone Powers and Tone Phases . . . . .        | 304 |
| Removing a Tone . . . . .                                | 304 |
| Generating the Waveform . . . . .                        | 304 |
| Configuring the RF Output . . . . .                      | 304 |
| Applying Changes to an Active Multitone Signal . . . . . | 305 |

## 13 Working in a Secure Environment

|  |     |
|--|-----|
| How to Obtain the Security Features Document . . . . . | 307 |
| Using Secure Display . . . . .                         | 308 |

## 14 Troubleshooting

|  |     |
|--|-----|
| Display . . . . .  | 310 |
| The Display is Too Dark to Read . . . . .                            | 310 |
| The Display Turns Black when Using USB Media . . . . .               | 310 |
| Signal Generator Lock-Up . . . . .                                   | 310 |
| RF Output . . . . .  | 310 |
| No RF Output . . . . .   | 310 |
| Power Supply Shuts Down . . . . .                                    | 310 |
| No Modulation at the RF Output . . . . .                             | 310 |
| RF Output Power too Low . . . . .                                    | 311 |
| Distortion . . . . .   | 311 |
| Signal Loss While Working with a Spectrum Analyzer . . . . .         | 311 |
| Signal Loss While Working with a Mixer . . . . .                     | 312 |
| Sweep . . . . .  | 314 |
| Cannot Turn Off Sweep . . . . .                                      | 314 |
| Sweep Appears Stalled . . . . .                                      | 314 |
| Incorrect List Sweep Dwell Time . . . . .                            | 314 |
| List Sweep Information is Missing from a Recalled Register . . . . . | 314 |

|   |     |
|---|-----|
| Amplitude Does Not Change in List or Step Sweep. . . . .                              | 314 |
| Internal Media Data Storage. . . . .  | 315 |
| Instrument State Saved but the Register is Empty or Contains the Wrong State. . . . . | 315 |
| USB Media Data Storage . . . . .  | 315 |
| Instrument Recognizes USB Media Connection, but Does Not Display Files . . . . .      | 315 |
| Preset . . . . .  | 315 |
| The Signal Generator Does Not Respond. . . . .  | 315 |
| Pressing Preset Performs a User Preset . . . . .                                      | 315 |
| Error Messages . . . . .  | 316 |
| Error Message Types. . . . .  | 316 |
| . . . . .   | 316 |
| Front Panel Tests. . . . .  | 317 |
| Self Test Overview . . . . .  | 318 |
| Licenses . . . . .  | 321 |
| A Time-Based License Quits Working. . . . .   | 321 |
| Cannot Load a Time-Based License. . . . .   | 321 |
| Contacting Agilent Technologies . . . . .   | 321 |
| Returning a Signal Generator to Agilent . . . . .                                     | 321 |

---

# Contents

# Documentation Overview

## Installation Guide

- Safety Information
- Receiving the Instrument
- Environmental & Electrical Requirements
- Basic Setup
- Accessories
- Operation Verification
- Regulatory Information

## User's Guide

- Signal Generator Overview
- Setting Preferences & Enabling Options
- Basic Operation
- Optimizing Performance
- Using Analog Modulation (Option UNT)
- Using Pulse Modulation (Option UNW and 320)
- Basic Digital Operation – No BBG Option Installed
- Basic Digital Operation (Option 653/655/656/657)
- Adding Real-Time Noise to a Signal (Option 403)
- Real-Time Phase Noise Impairments (Option 432)
- Custom Digital Modulation (Option 431)
- Multitone and Two-Tone Waveform Generator (Option 430)
- Working in a Secure Environment
- Troubleshooting

## Programming Guide

- Getting Started with Remote Operation
- Using IO Interfaces
- Programming Examples
- Programming the Status Register System
- Creating and Downloading Files
- Creating and Downloading User-Data Files

**SCPI Reference**

- SCPI Basics
- Basic Function Commands
- LXI System Commands
- System Commands
- Analog Modulation Commands
- Arb Commands
- Real-Time Commands

**Programming  
Compatibility Guide**

Provides a listing of SCPI commands and programming codes for signal generator models that are supported by the Agilent N5171B/72B EXG and N5181B/82B MXG X- Series signal generators.

**Service Guide**

- Troubleshooting
- Replaceable Parts
- Assembly Replacement
- Post-Repair Procedures
- Safety and Regulatory Information
- Instrument History

**Key Help<sup>a</sup>**

- Key function description
- Related SCPI commands

<sup>a</sup>Press the **Help** hardkey, and then the key for which you wish help.

---

# 1 Signal Generator Overview

---

**CAUTION** To avoid damaging or degrading the performance of the instrument, do not exceed 33 dBm (2W) *maximum* of reverse power levels at the RF input. See also *Tips for Preventing Signal Generator Damage* on [www.agilent.com](http://www.agilent.com).

---

- [Signal Generator Features](#) on page 2
- [Modes of Operation](#) on page 4
- [Front Panel Overview](#) on page 5
- [Front Panel Display](#) on page 9
- [Rear Panel Overview](#) on page 12

## Signal Generator Features

- N5171B/N5181B, RF analog models: 9 kHz to 1 (N5171B only), 3, or 6 GHz (Options 501, 503, and 506 respectively)
- N5172B/N5182B, RF vector models: 9 kHz to 3 or 6 GHz (Options 503, and 506 respectively)
- step & list sweep of frequency, power, or frequency and power
- vector models can include waveforms in list sweep
- automatic leveling control (ALC)
- real-time modulation filtering
- 8648/ESG code compatible
- 10 MHz reference oscillator with external output
- two channel power meter display
- user settable maximum power limit
- user flatness correction
- external analog I/Q inputs (vector models)
- enhanced assembly replacement
- GPIB, USB 2.0, and 100Base-T LAN interfaces
- deep amplitude modulation providing greater dynamic range
- manual power search (ALC off)
- SCPI and IVI-COM driver
- multiple baseband generator synchronization when using multiple signal generators (master/slave setup)
- with Signal Studio Software, vector models can generate 802.11 WLAN, W-CDMA, cdma2000, 1xEV-DO, GSM, EDGE, and more
- real-time baseband generator (Option 660)
- pulse train generator (Option 320)
- LF multifunction generator (Option 303)
- narrow pulse modulation, including internal pulse generator (Option UNW)
- analog differential I/Q outputs (vector models, Option 1EL)
- analog modulation: AM, FM, and  $\Phi$ M (Option UNT)
- arbitrary I/Q waveform playback up to 200 MSa/s (vector models, Option 656/657)
- external AM, FM, and  $\Phi$ M inputs (Option UNT)
- Wideband AM (vector models, Option UNT)
- flexible reference input, 1 – 50 MHz (Option 1ER)
- LO In/Out for phase coherency (Option 012)
- phase noise interference (vector models, Option 432)



- expanded license key upgradability (Option 099)

For more details on hardware, firmware, software, and documentation features and options, refer to the data sheet shipped with the signal generator and available from the Agilent Technologies website at [http://www.agilent.com/find/X-Series\\_SG](http://www.agilent.com/find/X-Series_SG).

## Modes of Operation

Depending on the model and installed options, the Agilent X-Series signal generator provides up to four basic modes of operation: continuous wave (CW), swept signal, analog modulation, and digital modulation.

### Continuous Wave

In this mode, the signal generator produces a continuous wave signal. The signal generator is set to a single frequency and power level. Both the analog and vector models can produce a CW signal.

### Swept Signal

In this mode, the signal generator sweeps over a range of frequencies and/or power levels. Both the analog and vector models provide list and step sweep functionality.

### Analog Modulation

In this mode, the signal generator modulates a CW signal with an analog signal. The analog modulation types available depend on the installed options.

Option UNT provides AM, FM, and  $\Phi$ M modulations. Some of these modulations can be used together.

---

**NOTE** The Mod On/Off hardkey and LED functionality are only valid for instruments with Option UNT installed.

Refer to [14. Mod On/Off and LED](#).

---

Option 303 provides a multifunction generator that consists of seven waveform generators.

Option UNW provides standard and narrow pulse modulation capability.


### Digital Modulation (Vector Models with Option 65x Only)

In this mode, the signal generator modulates a CW signal with a arbitrary I/Q waveform. I/Q modulation is only available on vector models. An internal baseband generator (Option 65x) adds the following digital modulation formats:

- *Custom Arb Waveform Generator* mode can produce a single-modulated carrier or multiple-modulated carriers. Each modulated carrier waveform must be calculated and generated before it can be output; this signal generation occurs on the internal baseband generator. Once a waveform has been created, it can be stored and recalled, which enables repeatable playback of test signals. To learn more, refer to [“Using the Arbitrary Waveform Generator” on page 265](#).
- *Custom Real-Time Waveform Generator* mode can produce a single-modulated carrier or multiple-modulated carriers. Each modulated carrier waveform must be calculated and generated before it can be output; this signal generation occurs on the internal baseband generator. Once a waveform has been created, it can be stored and recalled, which enables repeatable playback of test signals. To learn more, refer to [“Using the Arbitrary Waveform Generator” on page 265](#).
- *Multitone* mode produces up to 64 continuous wave signals (or tones). Like the Two Tone mode, the frequency spacing between the signals and the amplitudes are adjustable. To learn more, refer to [“Creating a Custom Multitone Waveform” on page 297](#).

- *Two-tone* mode produces two separate continuous wave signals (or tones). The frequency spacing between the signals and the amplitudes are adjustable. To learn more, refer to [Chapter 12, "Multitone and Two-Tone Waveforms \(Option 430\)"](#).
- *Dual ARB* mode is used to control the playback sequence of waveform segments that have been written into the ARB memory located on the internal baseband generator. These waveforms can be generated by the internal baseband generator using the Custom Arb Waveform Generator mode, or downloaded through a remote interface into the ARB memory. To learn more, refer to ["Dual ARB Player"](#) on page 130.

## Front Panel Overview



### 1. Host USB

**Connector** Type A  
**USB Protocol** 2.0

Use this universal serial bus (USB) to connect a USB Flash Drive (UFD) for data transfer. You can connect or disconnect a USB device without shutting down or restarting the signal generator. The instrument also has a rear panel device USB connector (see [page 14](#)) used to remotely control the instrument.

### 2. Display

The LCD screen provides information on the current function. Information can include status

indicators, frequency and amplitude settings, and error messages. Labels for the softkeys are located on the right hand side of the display. See also, “[Front Panel Display](#)” on [page 9](#).

### 3. Softkeys

A softkey activates the function indicated by the displayed label to the left of the key.

### 4. Numeric Keypad

The numeric keypad comprises the 0 through 9 hardkeys, a decimal point hardkey, a minus sign hardkey, and a backspace hardkey. See “[Entering and Editing Numbers and Text](#)” on [page 35](#).

### 5. Arrows and Select


The **Select** and arrow hardkeys enable you to select items on the signal generator’s display for editing. See “[Entering and Editing Numbers and Text](#)” on [page 35](#).

### 6. Page Up

In a table editor, use this hardkey to display a previous page. See “[Example: Using a Table Editor](#)” on [page 36](#). When text does not fit on one page in the display area, use this key in conjunction with the [Page Down](#) key ([page 7](#)) to scroll text.

### 7. MENUS

These hardkeys open softkey menus that enable you to configure instrument functions or access information.



## 8. Trigger

When trigger mode is set to **Trigger Key**, this hardkey initiates an immediate trigger event for a function such as a list or step sweep.

## 9. Local Cancel/(Esc)

This hardkey deactivates remote operation and returns the signal generator to front panel control, cancels an active function entry, and cancels long operations (such as an IQ calibration).

## 10. Help

Use this key to display a description of any hardkey or softkey. See [“Viewing Key Descriptions” on page 34](#).

## 11. Preset and User Preset

These hardkeys set the signal generator to a known state (factory or user-defined). See [“Presetting the Signal Generator” on page 34](#).

## 12. RF Output

|                      |                              |                          |
|----------------------|------------------------------|--------------------------|
| <b>Connector</b>     | Standard:                    | female Type-N            |
|                      | Option 1EM:                  | Rear panel female Type-N |
|                      | Impedance:                   | 50 $\Omega$              |
| <b>Damage Levels</b> | 50 Vdc, 2 W maximum RF power |                          |

## 13. RF On/Off and LED

This hardkey toggles the operating state of the RF signal present at the RF OUTPUT connector. The **RF On/Off** LED lights when RF output is enabled.

## 14. Mod On/Off and LED

This hardkey enables or disables the modulation of the output carrier signal by an active modulation format. This hardkey does not set up or activate a format (see [“Modulating the Carrier Signal” on page 48](#)).

The **MOD ON/OFF** LED lights when modulation of the output is enabled.

---

**NOTE** The Mod On/Off hardkey and LED functionality are only valid for instruments with Option UNT installed.

---

## 15. Page Down

In a table editor, use this hardkey to display the next page. See [“Example: Using a Table Editor” on page 36](#). When text does not fit on one page in the display area, use this key in conjunction with the [Page Up](#) key ([page 6](#)) to scroll text.

## 16. I Input (vector models only)

**Connector** Type: female BNC Impedance: 50  $\Omega$

**Signal** An externally supplied analog, in-phase component of I/Q modulation.  
The signal level is  $\sqrt{I^2+Q^2} = 0.5 V_{\text{rms}}$  for a calibrated output level.

**Damage Levels** 1  $V_{\text{rms}}$

See also, “[I/Q Modulation](#)” on page 188.

## 17. Q Input (vector models only)

**Connector** Type: female BNC Impedance: 50  $\Omega$

**Signal** An externally supplied analog, quadrature-phase component of I/Q modulation.  
The signal level is  $\sqrt{I^2+Q^2} = 0.5 V_{\text{rms}}$  for a calibrated output level.

**Damage Levels** 1  $V_{\text{rms}}$

See also, “[I/Q Modulation](#)” on page 188.

## 18. Knob

Rotating the knob increases or decreases a numeric value, or moves the highlight to the next digit, character, or item in a list. See also, “[Front Panel Knob Resolution](#)” on page 22.

## 19. Incr Set

This hardkey enables you to set the increment value of the currently active function. The increment value also affects how much each turn of the knob changes an active function’s value, according to the knob’s current ratio setting (see “[Front Panel Knob Resolution](#)” on page 22).

## 20. Return

This hardkey enables you to retrace key presses. In a menu with more than one level, the **Return** key returns to the prior menu page.


## 21. More and LED

When a menu contains more softkey labels than can be displayed, the More LED lights and a More message displays below the labels. To display the next group of labels, press the **More** hardkey.

## 22. Power Switch and LEDs

This switch selects the standby mode or the power on mode. In the standby position, the yellow LED lights and all signal generator functions deactivate. The signal generator remains connected to the line power, and some power is consumed by some internal circuits. In the on position, the green LED lights and the signal generator functions activate.

## Front Panel Display



### 1. Active Function Area

This area displays the currently active function. For example, if frequency is the active function, the current frequency setting appears. If the currently active function has an increment value associated with it, that value also appears.

### 2. Frequency Area

This area displays the current frequency setting.

### 3. Annunciators

Annunciators show the status of some of the signal generator functions, and indicate error conditions. An annunciator position may be used by more than one annunciator; in this case, only one of the functions sharing a given position can be active at a given time.

#### This annunciator appears when...

|          |   |
|----------|---|
| ΦM       | Phase modulation is on. If you turn frequency modulation on, the FM annunciator replaces ΦM.  |
| ARB      | The ARB generator is on. ARB is running and not waiting on a trigger.   |
| ALC OFF  | The ALC circuit is disabled. The UNLEVEL annunciator appears in the same position if the ALC is enabled and is unable to maintain the output level. |
| AM       | Amplitude modulation is on.   |
| ARMED    | A sweep has been initiated and the signal generator is waiting for the sweep trigger event.   |
| ATTNHOLD | The attenuator hold function is on. When this function is on, the attenuator is held at its current setting.  |
| AWGN     | Real Time I/Q Baseband additive white Gaussian noise is on.   |

**This annunciator appears when...**

|          |  |
|----------|--|
| BEG DAC  | A DAC overflow is occurring, adjust the runtime scaling adjust until the BEG DAC annunciator turns off. Another annunciator, UNLOCK, appears in the same position and has priority over the BEG DAC annunciator (see UNLOCK, below).   |
| CHANCORR | The internal channel correction is enabled.  |
| DETHTR   | The ALC detector heater is not up to temperature. To meet ALC specifications the heater must be at temperature.  |
| DIGBUS   | The digital bus is in use.   |
| DIGMOD   | Custom Arb waveform generator is on.   |
| ERR      | An error message is placed in the error queue. This annunciator does not turn off until you either view all of the error messages or clear the error queue (see <a href="#">“Reading Error Messages” on page 62</a> ).   |
| EXTREF   | An external frequency reference is applied.  |
| FM       | Frequency modulation is on. If you turn phase modulation on, the $\Phi$ M annunciator replaces FM.   |
| I/Q      | I/Q vector modulation is on.   |
| L        | The signal generator is in listener mode and is receiving information or commands over the GPIB, USB, or VXI-11/Sockets (LAN) interface.   |
| M-TONE   | Multitone waveform generator is on.  |
| MULT     | A frequency multiplier is set (see <a href="#">“Setting a Frequency Multiplier” on page 107</a> ).   |
| OFFS     | An output offset is set (see <a href="#">“Setting an Output Offset” on page 105</a> ).   |
| PN       | Phase noise interference is on.  |
| PULSE    | Pulse modulation is on.  |
| R        | The signal generator is remotely controlled over the GPIB, USB, or VXI-11/Sockets (LAN) interface. When the signal generator is in remote mode, the keypad is locked out. To unlock the keypad, press <b>Local</b> .   |
| REF      | An output reference is set (see <a href="#">“Setting an Output Reference” on page 106</a> ).   |
| RF OFF   | The signal generator’s RF Output is not enabled.   |
| S        | The signal generator has generated a service request (SRQ) over the GPIB, USB, or VXI-11/Sockets (LAN) interface.  |
| SWEEP    | The signal generator is currently sweeping in list or step mode.   |
| SWMAN    | The signal generator is in manual sweep mode.  |
| T        | The signal generator is in talker mode and is transmitting information over the GPIB, USB, or VXI-11/Sockets (LAN) interface.  |
| T-TONE   | Two-Tone waveform generator is on.   |
| UNLEVEL  | The signal generator is unable to maintain the correct output level. This is not necessarily an indication of instrument failure; unlevelled conditions can occur during normal operation. Another annunciator, ALC OFF, appears in the same position when the ALC circuit is disabled (see ALC OFF, above). |
| UNLOCK   | Any of the phase locked loops cannot maintain phase lock. To determine which loop is unlocked, examine the error messages (see <a href="#">“Reading Error Messages” on page 62</a> ).  |
| WATRG    | The current modulation mode is waiting on the Arb trigger.   |
| WINIT    | The signal generator is waiting for you to initiate a single sweep.  |

## 4. Amplitude Area

This area displays the current output power level setting (If the RF Output is off, this area is greyed out).



## 5. Error Message Area

This area displays abbreviated error messages. If multiple messages occur, only the most recent message remains displayed. See [“Reading Error Messages”](#) on page 62.

## 6. Text Area

This area displays signal generator status information, such as the modulation status, and other information such as sweep lists and file catalogs. This area also enables you to perform functions such as managing information (entering information, and displaying or deleting files).


## 7. Softkey Label Area

This area displays labels that define the function of the softkeys located immediately to the right of the display. Softkey labels change, depending on the function selected.

## Rear Panel Overview

Digital Modulation Connectors (Vector Models Only) on page 15

1. AC Power Receptacle



### 1. AC Power Receptacle

The AC power cord receptacle accepts a three-pronged AC power cord that is supplied with the signal generator. For details on line setting requirements and the power cord, see the *Installation Guide*.

---

**CAUTION** To avoid the loss of data, GPIB settings, or current user instrument states that have not been permanently saved to non-volatile memory, the signal generator should always be powered down either via the instrument's front panel power button or the appropriate SCPI command. Signal generators installed in rack systems and powered down with the system rack power switch rather than the instrument's front panel switch display a Error -310 due to the instrument not being powered down correctly.

---

## 2. EXT 1 & EXT 2

|                      |  |                                 |
|----------------------|--|---------------------------------|
| <b>Connector</b>     | female BNC   | Impedance nominally 50 $\Omega$ |
| <b>Signal</b>        | An externally supplied $\pm 1 V_p$ signal that produces the indicated depth. |                                 |
| <b>Damage Levels</b> | 5 $V_{rms}$ and 10 $V_p$   |                                 |

## 3. LF OUT

|                  |   |                       |
|------------------|---|-----------------------|
| <b>Connector</b> | female BNC  | Impedance 50 $\Omega$ |
| <b>Signal</b>    | Voltage range: 0 to +5 $V_p$<br>Offset: -5 V to +5 V, nominal |                       |
|                  | For more information, see page 69.                            |                       |

## 4. SWEEP OUT

|                  |  |   |
|------------------|--|---|
| <b>Connector</b> | female BNC   | Impedance <1 $\Omega$<br>Can drive 2 k $\Omega$ . |
| <b>Signal</b>    | Voltage range: 0 to +10 V, regardless of sweep width<br>In swept mode: beginning of sweep = 0 V; end of sweep = +10 V<br>In CW mode: no output |   |
|                  | This is a multiple use connector. For signal routing selections, see pages 42 and 113.   |   |

## 5. PULSE

|                      |   |                                 |
|----------------------|---|---------------------------------|
| <b>Connector</b>     | female BNC                                | Impedance nominally 50 $\Omega$ |
| <b>Signal</b>        | Externally supplied: +1 V = on; 0 V = off |                                 |
| <b>Damage Levels</b> | $\leq -0.3$ and $\geq +5.3$ V             |                                 |

## 6. TRIG 1 & 2

|                      |  |                  |
|----------------------|--|------------------|
| <b>Connector</b>     | female BNC   | Impedance high Z |
| <b>Signal</b>        | An externally supplied TTL or CMOS signal for triggering operations, such as point to point in manual sweep mode or an LF sweep in external sweep mode.<br>Triggering can occur on either the positive or negative edge. |                  |
| <b>Damage Levels</b> | $\leq -0.5$ and $\geq +5.5$ V  |                  |

## 7. REF IN

|                  |   |                                 |
|------------------|---|---------------------------------|
| <b>Connector</b> | female BNC  | Impedance nominally 50 $\Omega$ |
| <b>Signal</b>    | An externally supplied -3.5 to +20 dBm signal from a timebase reference that is within $\pm 1$ ppm. |                                 |

In its factory default mode, the signal generator can detect a valid reference signal at this connector and automatically switch from internal to external reference operation. See [“Presetting the Signal Generator” on page 34](#). With Option 1ER (flexible reference input), you must explicitly tell the signal generator the external reference frequency you wish to use; enter the information through the front

panel or over the remote interface.

## 8. 10 MHz OUT

**Connector** female BNC Impedance nominally 50  $\Omega$

**Signal** A nominal signal level greater than 4 dBm.

## 9. GPIB

This connector enables communication with compatible devices such as external controllers, and is one of three connectors available to remotely control the signal generator (see also [10. LAN](#) and [11. Device USB](#)).

## 10. LAN

The signal generator supports local area network (LAN) based communication through this connector, which enables a LAN-connected computer to remotely program the signal generator. The LAN interface supports auto-MDIX. The signal generator is limited to 100 meters on a single cable (100Base-T). For more information on the LAN, refer to the *Programming Guide*.

## 11. Device USB

**Connector** Type B

**USB Protocol** Version 2.0

Use this universal serial bus (USB) connector to connect a PC to remotely control the signal generator.

## 12. Host USB

**Connector** Type A

**USB Protocol** 2.0

Use this universal serial bus (USB) to connect a USB Flash Drive (UFD) for data transfer. You can connect or disconnect a USB device without shutting down or restarting the signal generator. The instrument also has a rear panel device USB connector (see [page 14](#)) used to remotely control the instrument.

## 13. SD Card

Holds the Secure Digital (SD) non-volatile memory card.

## Digital Modulation Connectors (Vector Models Only)

### I OUT, Q OUT, $\bar{I}$ OUT, $\bar{Q}$ OUT

---

**NOTE**  $\bar{I}$  OUT and  $\bar{Q}$  OUT, require Option 1EL.

---

**Connector** Type: female BNC Impedance: 50  $\Omega$   
DC-coupled

**Signal**

I OUT The analog, in-phase component of I/Q modulation from the internal baseband generator.

Q OUT The analog, quadrature-phase component of I/Q modulation from the internal baseband generator.

$\bar{I}$  OUT Used in conjunction with the I OUT connector to provide a balanced<sup>a</sup> baseband stimulus.

$\bar{Q}$  OUT Used in conjunction with the Q OUT connector to provide a balanced<sup>a</sup> baseband stimulus.

**Damage Levels** > 1 Vrms **DC Origin Offset** typically <10 mV

**Output Signal Levels into a 50  $\Omega$  Load**

- 0.5 V<sub>pk</sub>, typical, corresponds to one unit length of the I/Q vector
- 0.69 V<sub>pk</sub> (2.84 dB), typical, maximum crest factor for peaks for  $\pi/4$  DQPSK, alpha = 0.5
- 0.71 V<sub>pk</sub> (3.08 dB), typical, maximum crest factor for peaks for  $\pi/4$  DQPSK, alpha = 0.35
- Typically 1 V<sub>p-p</sub> maximum

<sup>a</sup>Balanced signals are signals present in two separate conductors that are symmetrical relative to ground, and are opposite in polarity (180 degrees out of phase).

## BB TRIG 1 & BB TRIG 2

|                  |  |                                 |
|------------------|--|---------------------------------|
| <b>Connector</b> | female BNC   | Impedance nominally 50 $\Omega$ |
| <b>Signal</b>    | Reserved for arbitrary and real-time baseband generators I/O, such as markers or trigger inputs. |                                 |

## EVENT 1

|                      |   |                                  |
|----------------------|---|----------------------------------|
| <b>Connector</b>     | female BNC  | Impedance: nominally 50 $\Omega$ |
| <b>Signal</b>        | A pulse that can be used to trigger the start of a data pattern, frame, or timeslot. Adjustable to $\pm$ one timeslot; resolution = one bit   |                                  |
|                      | <b>Markers</b>  |                                  |
|                      | Each Arb-based waveform point has a marker on/off condition associated with it.   |                                  |
|                      | Marker 1 level = +3.3 V CMOS high (positive polarity selected); -3.3 V CMOS low (negative polarity selected).                                 |                                  |
|                      | Output on this connector occurs whenever Marker 1 is on in an Arb-based waveform (see <a href="#">“Using Waveform Markers” on page 145</a> ). |                                  |
| <b>Damage Levels</b> | < -4 and > +8 V   |                                  |

## PAT TRIG

|                      |  |   |
|----------------------|--|---|
| <b>Connector</b>     | female BNC   | Impedance: nominally 50 $\Omega$                                    |
| <b>Signal</b>        | A TTL/CMOS low to TTL/CMOS high, or TTL/CMOS high to TTL/CMOS low edge trigger. The input to this connector triggers the internal digital modulation pattern generator to start a single pattern output or to stop and re-synchronize a pattern that is being continuously output. To synchronize the trigger with the data bit clock, the trigger edge is latched, then sampled during the falling edge of the internal data bit clock. This is the external trigger for all ARB waveform generator triggers. |   |
|                      | <b>Minimum Trigger Input Pulse Width</b>   | (high or low) = 100 ns  |
|                      | <b>Minimum Trigger Delay</b>   | (trigger edge to first bit of frame) = 1.5 to 2.5 bit clock periods |
| <b>Damage Levels</b> | < -4 and > +8 V  |   |

## DIGITAL BUS I/O


This is a proprietary bus used by Agilent Technologies signal creation software. This connector is not operational for general purpose use. Signals are present only when a signal creation software option is installed (for details, refer to <http://www.agilent.com/find/signalcreation>).

---

**NOTE** The X-Series' Digital BUS I/O connector can be used for enabling operation with the Agilent Technologies N5106A PXB MIMO Receiver Tester.

---

## AUX I/O



Pin 1 = Event 1  
Pin 2 = Event 2  
Pin 3 = Event 3  
Pin 4 = Event 4  
Pin 5 = Sample Rate Clock Out  
Pin 6-36 = application specific\*

The AUX I/O connector is a shielded .050 series board mount connector.

\* Refer to the application's help for more information.

### Event 1, 2, 3, and 4 (pins 1 - 4)

A pulse that can be used to trigger the start of a data pattern, frame, or timeslot.  
Adjustable to  $\pm$  one timeslot; resolution = one bit

### Markers

Each Arb-based waveform point has a marker on/off condition associated with it.  
Marker level = +3.3 V CMOS high (positive polarity selected); -3.3 V CMOS low (negative polarity selected).

### Sample Rate Clock Out (pin 5)

This output is used with an internal baseband generator. This pin relays a CMOS bit clock signal for synchronizing serial data.  
Damage levels: < -0.5 and > +5.5 V.






---

## 2 Setting Preferences & Enabling Options

The Utility menu provides access to both user and remote operation preferences, and to the menus in which you can enable instrument options.



## User Preferences


From the Utility menu, you can set the following user preferences:

- [Display Settings](#), below
- [Power On and Preset](#) on page 21
- [Front Panel Knob Resolution](#) on page 22

## Display Settings

See also, [Using Secure Display](#) on page 308.


Utility > Display



For details on each key, use key help as described on [page 34](#).

**NOTE** With the brightness set to minimum, the display may be too dark to see the softkeys. If this happens, use the figure above to locate the brightness softkey and adjust the value so that you can see the display.

## Power On and Preset



### \*Caution

To avoid the loss of data, GPIB settings, or current user instrument states that have not been permanently saved to non-volatile memory, the X-Series signal generator should always be powered down either via the instrument's front panel power button or the appropriate SCPI command. X-Series signal generators installed in rack systems and powered down with the system rack power switch rather than the instrument's front panel switch display a Error -310 due to the instrument not being powered down correctly.

### Note

To define a user preset, set the instrument up as desired and press **User Preset > Save User Preset**.

## Front Panel Knob Resolution

**Incr Set** — Makes the increment value of the current function the active entry.

Utility >  
Instrument Adjustments

The increment value and the step/knob ratio determine how much each turn of the knob changes the active function value.

For example, if the increment value of the active function is 10 dB and the step/knob ratio is 50 to 1, each turn of the knob changes the active function by 0.2 dB (1/50th of 10 dB).

To change the amount for each turn of the knob, modify the increment value, the step/knob ratio, or both.

Executes the ALC Modulator Bias Adjustment. When using the ALC in open loop mode, this compensates for open loop power drift due to temperature and humidity.

SCPI Commands:  
:CALibration:ALC:MODulator:BIAS

For details on each key, use key help as described on [page 34](#).

## Setting Time and Date

**CAUTION** Changing the time or date can adversely affect the signal generator's ability to use time-based licenses, even if a time-based license is not installed.


The signal generator's firmware tracks the time and date, and uses the *latest* time and date as its time/date reference point.

Utility >  
Instrument Adjustments >

The Adjustments menu shows 'Step/Knob Ratio 50/1', 'Time/Date', 'Ref Oscillator Tune 0', and 'Execute ALC Modulator Bias Adjustment'. The Time Date menu shows 'Time/Date Off On', 'Date Format MDY DMY', 'Set Time', and 'Set Date'.

### Setting the Time or Date Forward

If you set the time or date forward, be aware that you are using up any installed time-based licenses, and that you are *resetting the signal generator's time/date reference point*. When you set a new time or date that is later than the signal generator's current reference point, that date becomes the new reference point. If you then set the date back, you run the risk described in the next section.




### Setting the Time or Date Backward

When you set the time back, the signal generator notes that the time has moved back from the reference point. If you set the time back more a few hours, you disable the signal generator's ability to use time-based licenses, even if there is no license installed at the time that you set the time

back. In this case, you can re-enable the signal generator's ability to use time-based licenses by moving the clock forward to the original time or simply waiting that length of time.

## Reference Oscillator Tune

Utility > Instrument Adjustments



Tunes the internal VCTXCO oscillator frequency.

The user value offsets the factory tuned value (the value is added to the factory calibrated DAC value). The tune value of 0 sets the factory calibrated value.

The range; -8192 to 8192, can be set by using the front panel keypad, knob or remote command.

For details on each key, use key help as described on [page 34](#).

See also the *SCPI Command Reference*.

## Upgrading Firmware

For information on new firmware releases, go to <http://www.agilent.com/find/upgradeassistant>.

## Remote Operation Preferences


For details on operating the signal generator remotely, refer to the *Programming Guide*.

### GPIB Address and Remote Language

#### NOTES

USB is also available. It is not shown in the menu because it requires no configuration.


For details on using the instrument remotely, see the *Programming Guide*.



For details on each key, use key help as described on page 34.

## Configuring the LAN Interface

Utility > I/O Config



### NOTES

Use a 100Base-T LAN cable to connect the signal generator to the LAN.


Use a crossover cable to connect the signal generator directly to a PC.

For details on using the instrument remotely, refer to the *Programming Guide* and to [www.agilent.com](http://www.agilent.com) and search on FAQs: *Hardware Configurations and Installation* for the Agilent MXG.

For details on each key, use key help as described on page 34.

## Enabling LAN Services: "Browser," "Sockets," and "VXI-11"

Utility > I/O Config



For details on each key, use key help as described on [page 34](#).


For more information refer to the *Programming Guide*.



## Configuring the Remote Languages

Utility > I/O Config

Select the desired Remote language.



For details on each key, use key help as described on [page 34](#).


Refer to the *SCPI Command Reference*.

## Configuring the Preset Languages

Figure 2-1 N5171B/72B/81B/82B

Utility > Power On/Preset

Select the desired Remote language.



## Enabling an Option

There are two ways to enable an option:

- Use the License Manager software utility:
  1. Run the utility and follow the prompts.
  2. Download the utility from [www.agilent.com/find/LicenseManager](http://www.agilent.com/find/LicenseManager) and select license (.lic) files from an external USB Flash Drive (UFD).
- Use SCPI commands, as described in the *Programming Guide*.

## Viewing Options and Licenses

Utility >  
 Instrument Info

| Instrument Info      |
|----------------------|
| Diagnostic Info      |
| Options Info         |
| Self Test            |
| Installed Board Info |
| Front Panel Tests    |

| Options Info               |
|----------------------------|
| Instrument Options         |
| Auxiliary Software Options |
| Waveform Licenses          |

| Aux Software Licenses                  |
|--|
| Service Software Licenses appear here. |

| Waveform Licenses   |           |             |
|---|-----------|-------------|
| Wave ID   | Days Left | Description |
| Waveform licenses from some Signal Studio applications appear here. |           |             |


Instrument options appear here. A check mark means that an option is enabled.

| Instrument Option | Options Expiration | Description                                  |
|-------------------|--------------------|--|
| 006               | permanent          | ✓ Digital output connectivity with the NS102 |
| 004               | permanent          | ✓ Digital input connectivity with the NS102A |
| 006               | permanent          | ✓ Security and removable memory card         |
| 009               | permanent          | ✓ Internal solid state memory                |
| 012               | permanent          | ✓ LO in/out for phase coherency              |
| 021               | permanent          | ✓ Upgrade BBG memory from 32 Msa to 256 Msa  |
| 022               | permanent          | ✓ Upgrade BBG memory from 32 Msa to 512 Msa  |
| 023               | permanent          | ✓ Upgrade BBG memory from 32 Msa to 1 Gsa    |
| 099               | permanent          | ✓ Expanded license key upgradability         |
| 1EA               | permanent          | ✓ High power output                          |

For details on each key, use key help as described on [page 34](#).

## Hardware Assembly Installation and Removal Softkeys

Utility > More 2 of 2 > Service



For details on each key, use key help as described on [page 34](#).

**NOTE:** Functionality of inactive keys on this page will be implemented in a future release.



---

## 3 Basic Operation

This chapter introduces fundamental front panel operation. For information on remote operation, refer to the *Programming Guide*.

- [Presetting the Signal Generator](#) on page 34
- [Viewing Key Descriptions](#) on page 34
- [Entering and Editing Numbers and Text](#) on page 35
- [Setting Frequency and Power \(Amplitude\)](#) on page 37
- [Setting ALC Bandwidth Control](#) on page 39
- [Configuring a Swept Output](#) on page 40
- [Modulating the Carrier Signal](#) on page 48
- [Working with Files](#) on page 50
- [Reading Error Messages](#) on page 62

## Presetting the Signal Generator



To return the signal generator to a known state, press either **Preset** or **User Preset**.

*Preset* is the factory preset; *User Preset* is a custom preset\*\* (see also, [page 21](#)).

To reset persistent settings (those unaffected by preset, user preset, or power cycle\*), press: **Utility > Power On/Presets > Restore System Defaults**.

### \*Caution

To avoid the loss of data, GPIB settings, or current user instrument states that have not been permanently saved to non-volatile memory, the instrument should always be powered down either via the instrument's front panel power button or the appropriate SCPI command. Instrument's installed in rack systems and powered down with the system rack power switch rather than the instrument's front panel switch display a Error -310 due to the instrument not being powered down correctly.

\*\*You can create more than one user preset by giving each saved state file a different name (see [Figure 3-9 on page 60](#)).

## Viewing Key Descriptions



The Help hardkey enables you to display a description of any hardkey or softkey.

To display help text:

1. Press **Help**.
2. Press the desired key.  
The help displays and the key's normal function does not execute.



## Entering and Editing Numbers and Text

### Entering Numbers and Moving the Cursor

Use the number keys and decimal point to enter numeric data.

Up/down arrow keys increase/decrease a selected (highlighted) numeric value, and move the cursor vertically.

Page up/down keys move tables of data up and down within the display area.

Left/right arrow keys move the cursor horizontally.

Use the **Select** hardkey to choose part of an entry, as when entering alpha characters. In some menus, the **Select** key also acts as a terminator, and is equivalent to the **Enter** softkey.

To specify a negative value, enter the negative sign either before or after the numeric value (this key is a toggle).

Backspace moves the cursor to the left, deleting characters as it goes.



**Note:** Rotating the knob increases or decreases a numeric value, changes a highlighted digit or character, or steps through lists or items in a row.

See also, [Front Panel Knob Resolution](#) on page 19

For details on each key, see [page 34](#).

### Entering Alpha Characters

Data entry softkeys appear in various menus. If their meaning is not clear in context, use the help key (described on [page 34](#)) to display an explanation. Use the softkey next to the alpha table for help on the table.


Selecting data that accepts alpha characters, displays one of the menus shown at right.

Use the arrow keys or knob to highlight the desired letter, then press the **Select** hardkey (or the softkey next to the alpha table). To correct errors, use **Bk Sp** or **Clear Text**.

To terminate the entry, press the **Enter** softkey.

A subset of this menu appears for hexadecimal characters. The character menu displays only the letters A through F (use the numeric keypad for other values).

**Note:** File names are limited to 25 characters.



to move the cursor within the active value rather than within the alpha table, turn the alpha table off.

Add/edit comments for saved instrument state files (see [page 57](#)).

### Example: Using a Table Editor

Table editors simplify configuration tasks. The following procedure describes basic table editor functionality using the List Mode Values table editor.

1. Preset the signal generator: Press **Preset**.
2. Open the table editor: Press **Sweep > More > Configure List Sweep**.

The signal generator displays the editor shown in the following figure.

**Active Function Area**  
Displays the active item as you edit it.

**Cursor**  
Highlighting indicates the selected item. To make this the active (editable) item, either press **Select**, or simply enter the desired value.

**Table Editor Name**  
List Mode Values

**Current / Total Number of Pages**  
Pg 1/11

**Table Items**  
Table items are also called data fields.

**Table Editor Softkeys**  
Used to load, navigate, modify, and store table item values. For details on each key, use the key help: Press the **Help** hardkey and then the desired key.

Indicates that another menu is available; to display the second menu, press **More**.


| Frequency               | Amplitude   | List Table            |          |  |
|-------------------------|-------------|-----------------------|----------|--|
| 6.000 000 000 00 GHz    | -144.00 dBm | Edit Item             |          |  |
| <b>List Node Values</b> |             |                       |          |  |
| Pg 1/11                 |             |                       |          |  |
| Frequency               | Power       | Waveform              | Quell    |  |
| 1 6.000000000000 GHz    | -144.00     | -- CW (no modulation) | 2.000 ms |  |
| 2 6.000000000000 GHz    | -144.00     | -- CW (no modulation) | 2.000 ms |  |
| 3 6.000000000000 GHz    | -144.00     | -- CW (no modulation) | 2.000 ms |  |
| 4 6.000000000000 GHz    | -144.00     | -- CW (no modulation) | 2.000 ms |  |
| 5 6.000000000000 GHz    | -144.00     | -- CW (no modulation) | 2.000 ms |  |
| 6 6.000000000000 GHz    | -144.00     | -- CW (no modulation) | 2.000 ms |  |
| 7 6.000000000000 GHz    | -144.00     | -- CW (no modulation) | 2.000 ms |  |
| 8 6.000000000000 GHz    | -144.00     | -- CW (no modulation) | 2.000 ms |  |
| 9 6.000000000000 GHz    | -144.00     | -- CW (no modulation) | 2.000 ms |  |
| 10 6.000000000000 GHz   | -144.00     | -- CW (no modulation) | 2.000 ms |  |

3. Highlight the desired item: use the arrow keys or the knob to move the cursor.
4. (Optional) Display the selected item in the active function area: Press **Select**.
5. Modify the value:
  - If the value is displayed in the active function area, use the knob, arrow keys, or numeric keypad to modify the value.
  - If the value is not displayed in the active function area, use the numeric keypad to enter the desired value (which then appears in the active function area).
6. Terminate the entry:
  - If available, press the desired units.
  - If units are not displayed, press either **Enter** (if available) or **Select**.

The modified item is displayed in the table.

## Setting Frequency and Power (Amplitude)

Figure 3-1 Frequency and Amplitude Softkeys



### Example: Configuring a 700 MHz, –20 dBm Continuous Wave Output

1. Preset the signal generator.

The signal generator displays its maximum specified frequency and minimum power level (the front panel display areas are shown on [page 9](#)).

2. Set the frequency to 700 MHz: Press **Freq > 700 > MHz**.

The signal generator displays 700 MHz in both the FREQUENCY area of the display and the active entry area.

3. Set the amplitude to –20 dBm: Press **Amptd > –20 > dBm**.


The display changes to –20 dBm in the AMPLITUDE area of the display, and the amplitude value becomes the active entry. Amplitude remains the active function until you press another function key.

4. Turn on the RF Output: Press **RF On/Off**.

The RF Output LED lights, and a 700 MHz, –20 dBm CW signal is available at the RF OUTPUT connector.


### Using an External Reference Oscillator

When using an external reference, you can select either narrow or wide bandwidth mode.




For details on each key, use key help as described on [page 34](#).

Figure 3-2 Using an External Reference Oscillator



## Setting ALC Bandwidth Control

Figure 3-3 Amplitude Softkeys



For details on each key, use key help as described on page 34.

Refer to the SCPI Command Reference.

To display the next menu, press **More**.


## Configuring a Swept Output

The signal generator has two methods of sweeping through a set of frequency and amplitude points:

*Step sweep* ([page 42](#)) provides a linear or logarithmic progression from one selected frequency, amplitude, or both, to another, pausing at linearly or logarithmically spaced points (steps) along the sweep. The sweep can progress forward, backward, or manually.

*List sweep* ([page 44](#)) enables you to enter frequencies and amplitudes at unequal intervals, in nonlinear ascending, descending, or random order. List sweep also enables you to copy the current step sweep values, include an Arb waveform in a sweep (on a vector instrument), and save list sweep data in the file catalog ([page 55](#)).

Figure 3-4 Sweep Softkeys




## Routing Signals

Sweep > More > More > Route Connectors

### Step Sweep

Step sweep provides a linear or logarithmic progression from one selected frequency, or amplitude, or both, to another, pausing at linearly or logarithmically spaced points (steps) along the sweep. The sweep can progress forward, backward, or be changed manually.


Figure 3-5 Signal Routing Softkeys



For details on each key, use key help as described on [page 34](#).



Figure 3-6 Sweep Softkeys



### Example: Configuring a Continuous, Linear Step Sweep

**Output:** A signal that continuously sweeps from 500 to 600 MHz and from -20 to 0 dBm, with a dwell time of 500 ms at each of six equally-spaced points.

1. Preset the instrument and open the Sweep/List menu: Press **Preset** > **SWEEP**.

Because continuous is the default sweep repeat selection, and linear is the default step spacing selection, you do not need to set these parameters.

2. Open the step sweep menu: Press **Configure Step Sweep**.

3. Set the following parameters:

|   |  |
|---|--|
| Start frequency 500 MHz:                          | Press <b>Freq Start</b> > <b>500</b> > <b>MHz</b>                |
| Stop frequency 600 MHz:                           | Press <b>Freq Stop</b> > <b>600</b> > <b>MHz</b>                 |
| Amplitude at the beginning of the sweep, -20 dBm: | Press <b>Amptd Start</b> > <b>-20</b> > <b>dBm</b>               |
| Amplitude at the end of the sweep, 0 dBm:         | Press <b>Amptd Stop</b> > <b>0</b> > <b>dBm</b> .                |
| 6 sweep points:                                   | Press <b># Points</b> > <b>6</b> > <b>Enter</b>                  |
| Dwell time at each point, 500 milliseconds:       | Press <b>More</b> > <b>Step Dwell</b> > <b>500</b> > <b>msec</b> |

4. Sweep both frequency and amplitude: Press **Return** > **Return** > **Sweep** > **Freq Off On** > **Amptd Off On**.

A continuous sweep begins, from the start frequency/amplitude to the stop frequency/amplitude. The SWEEP annunciator displays, and sweep progress is shown in the frequency display, the amplitude display, and the progress bar.


5. Turn the RF output on: Press **RF On/Off**.

The RF LED lights, and the continuous sweep is available at the RF Output connector.

## List Sweep

List sweep enables you to enter frequencies and amplitudes at unequal intervals in nonlinear ascending, descending, or random order. List sweep also enables you to copy the current step sweep values, include a waveform in a sweep (on a vector instrument), and save list sweep data in the file catalog (page 55). Dwell time is editable at each point. For fastest switching speeds, use list sweep.


Figure 3-7 List Sweep Configuration Softkeys and Display



**Example: Configuring a List Sweep Using Step Sweep Data**


1. Set up the desired step sweep, but do not turn the sweep on. This example uses the step sweep configured on [page 43](#).
2. In the SWEEP menu, change the sweep type to list:  
Press **SWEEP > Sweep Type List Step** to highlight List.

The display shows sweep list parameters, as shown below.



3. Open the List Sweep menu: Press **More > Configure List Sweep**.
4. Clear any previously set values from the menu and load the points defined in the step sweep into the list: Press **More > Preset List > Preset with Step Sweep > Confirm Preset**.

The display updates with the values loaded from the step sweep, as shown.



**Vector Models:**

Presetting the list clears any previously selected waveforms.

For information on selecting a list sweep waveform, see [Example: Editing List Sweep Points](#) on page 46.

5. Sweep frequency and amplitude: Press **SWEEP (hardkey) > Sweep > Freq Off On > Amptd Off On**.  
Setting the sweep turns on the sweep function; a continuous sweep begins. On the display, the SWEEP annunciator appears, and the progress bar shows the progression of the sweep.
6. If not already on, turn the RF output on: Press **RF On/Off**.  
The RF Output LED lights, and a continuous sweep is available at the RF OUTPUT connector.

**Example: Editing List Sweep Points**

If you are not familiar with table editors, refer to [page 36](#).

1. Create the desired list sweep. This example uses the list sweep created in the previous example.
2. If sweep is on, turn it off. Editing list sweep parameters with sweep on can generate an error.
3. Ensure that the sweep type is set to list: Press **SWEEP > Sweep Type List Step** to highlight List.
4. In the List Mode Values table editor, change the point 1 dwell time (defined in row 1) to 100 ms:
  - a. Press **More > Configure List Sweep**.
  - b. Highlight the point 1 dwell time.
  - c. Press **100 > msec**.

The next item in the table (the frequency value for point 2) highlights.

5. Change the selected frequency value to 445 MHz: Press **445 > MHz**.
6. Add a new point between points 4 and 5: Highlight any entry in row 4 and press **Insert Row**.

This places a copy of row 4 below row 4, creating a new point 5, and renumbers subsequent rows.

7. Shift frequency values down one row, beginning at point 5: Highlight the frequency entry in row 5, then press **More > Insert Item**.

This places a copy of the highlighted frequency value in row 6, shifting the original frequency values for rows 6 and 7 down one row. The new row 8 contains only a frequency value (the power and dwell time entries do not shift down).

8. Change the still active frequency value in row 5 to 590 MHz: Press **590 > MHz**. The power in row 5 is now the active parameter.
9. Insert a new power value (-2.5 dBm) for point 5, and shift down the original power values for points 5 and 6 by one row: Press **Insert Item > -2.5 > dBm**.
10. To complete the entry for point 8, insert a duplicate of the point 7 dwell time by shifting a copy of the existing value down: Highlight the dwell time in row 7 and press **Insert Item**.
11. *For an analog instrument, go to step 14.* For a vector instrument, continue with step 12.
12. Select a waveform for point 2:
  - a. Highlight the waveform entry for point 2 and press the **More > Select Waveform**.  
The signal generator displays the available waveforms, as shown in the following example.

|                          |                                 |                  |                                  |   |                           |
|--------------------------|---------------------------------|------------------|----------------------------------|---|---------------------------|
| <b>FREQUENCY</b>         |                                 | <b>AMPLITUDE</b> |                                  | <b>Arb Waveform</b>                         |                           |
| 6.000 000 000 00 GHz     |                                 | -144.00 dBm      |                                  | Select Waveform<br>(WFM1:SINE_TEST_1<br>FM) | Either select a waveform, |
|                          |                                 |                  |                                  | Display Waveform<br>And Markers             | or                        |
| <b>Select<br/>Pg 1/1</b> | <b>Segment On<br/>BBG Media</b> | <b>Points</b>    | <b>Sequence On<br/>Int Media</b> | <b>Segs</b>                                 |                           |
|                          | RAMP_TEST_WFM                   | 200 Sa           | ANTENNA2M                        | 2097152                                     |                           |
|                          | SINE_TEST_WFM                   | 200 Sa           |                                  |   |                           |
|                          |                                 |                  |                                  | Waveform<br>Segments                        |                           |
|                          |                                 |                  |                                  | CW<br>(no modulation)                       | select no modulation.     |
|                          |                                 |                  |                                  | Goto Row                                    |                           |

- b. Highlight the desired waveform (in this example, SINE\_TEST) and press either the **Select** hardkey or the **Select Waveform** softkey.

13. As desired, repeat step 12 for the remaining points for which you want to select a waveform. The following figure shows an example of how this might look.

| List | Mode | Values         | Frequency | Power   | Waveform          | Dwell      |
|------|------|----------------|-----------|---------|-------------------|------------|
| 1    |      | 6.0000000000   | GHz       | -144.00 | WFM:SINE_TEST_WFM | 100.000 ms |
| 2    |      | 445.0000000000 | MHz       | -144.00 |                   | 100.000 ms |
| 3    |      | 6.0000000000   | GHz       | -144.00 |                   | 2.000 ms   |
| 4    |      | 6.0000000000   | GHz       | -144.00 |                   | 2.000 ms   |
| 5    |      | 590.0000000000 | MHz       | -2.50   |                   | 2.000 ms   |
| 6    |      | 6.0000000000   | GHz       | -2.50   |                   | 2.000 ms   |
| 7    |      | 6.0000000000   | GHz       | -144.00 |                   | 2.000 ms   |
| 8    |      | 6.0000000000   | GHz       | -144.00 |                   | 2.000 ms   |
| 9    |      | 6.0000000000   | GHz       | -144.00 |                   | 2.000 ms   |
| 10   |      | 6.0000000000   | GHz       | -144.00 |                   | 2.000 ms   |

02/24/2012 11:10 Page 1 of 2

14. Turn sweep on:

Press **Return** > **Return** > **Return** > **Sweep** > **Freq Off On** > **Amptd Off On** > **Waveform Off On**.

15. If it is not already on, turn the RF output on:

Press **RF On/Off**.

The SWEEP annunciator appears on the display, indicating that the signal generator is sweeping, and the progress bar shows the progression of the sweep.

---

**NOTE** If the instrument is in manual sweep (page 48), the active row (row 6 in the figure above) is the selected (manual) point, and the signal generator outputs the settings for that selection when the RF output is on.

---

### Example: Using a Single Sweep

1. Set up either a step sweep (page 43) or a list sweep (page 45).

2. In the List/Sweep menu, set the sweep repeat to single:

Press **Sweep Repeat Single Cont** to highlight Single.

Sweep does not occur until you trigger it.

Note that the WINIT annunciator appears on the display, indicating that the sweep is waiting to be initiated.

3. If not already on, turn the RF output on: Press **RF On/Off**.

4. Initiate the sweep: Press **Single Sweep**.

A single repetition of the configured sweep is available at the RF Output connector.

As the signal generator sweeps, the SWEEP annunciator replaces WINIT on the display, and the progress bar shows the progression of the sweep.

At the end of the sweep, there is no progress bar, and the WINIT annunciator replaces SWEEP.

### Example: Manual Control of Sweep

1. Set up either a step sweep (page 43) or a list sweep (page 45).
2. In the Sweep/List menu, select a parameter to sweep: Press **Sweep** > *parameter* > **Return**.
3. Select manual mode: Press **More** > **Manual Mode Off On**.

When you select manual mode, the current sweep point becomes the selected manual point.

4. If it is not already on, turn the RF output on: Press **RF On/Off**.
5. Select the desired point to output: Press **Manual Point** > *number* > **Enter**.

The progress bar changes to indicate the selected point.

6. Use the knob or arrow keys to move from point to point. As you select each point, the RF output changes to the settings in that selection.

The SWMAN annunciator indicates that the sweep is in manual mode.

The currently sweeping parameter stops and displays the selected point.

When you enter a manual point, the progress bar moves to and stops at the selected point.

The parameters of the selected sweep point (point 3 of 6 in this example) define the signal available at the RF Output connector.

When you turn manual mode on, the current sweep point becomes the manual point.

| FREQUENCY                     |                          | AMPLITUDE                |                         | Sweep/List                 |  |
|-------------------------------|--------------------------|--------------------------|-------------------------|----------------------------|--|
| 6.000 000 000 00 GHz          |                          | -144.00 dBm              |                         | Configure List Sweep ▶     |  |
| SWMAN                         |                          | Manual Point: 100        |                         | Sweep Trigger (Free Run) ▶ |  |
| Sweep/List Status Information |                          | Current Point : 100/104  |                         | Point Trigger (Free Run) ▶ |  |
| Sweep : Freq+Amptd            | Sweep Type : List        | Sweep Speed : 273pts/sec | Manual Mode : On        | Manual Mode Off <b>On</b>  |  |
| Frequency Points: 104         | Amplitude Points: 104    | Sweep Direction: Up      | Sweep Repeat : Cont     | Manual Point 100           |  |
| Waveform Points : 1           | Dwell Points : 104       | Sweep Trigger : FreeRun  | Point Trigger : FreeRun | More 2 of 3                |  |
| Dwell Type : List             | Atten Hold At : 115.00dB | Timer Period : 1.000msec | Step Dwell : 2.000msec  | 02/24/2012 11:18           |  |

## Modulating the Carrier Signal

To modulate the carrier signal, you must have both

- an active modulation format *and*
- modulation of the RF output enabled

### Example

1. Preset the signal generator.
2. Turn on AM modulation: Press **AM** > **AM Off On** (requires Option UNT).

You can turn on the modulation format before or after setting signal parameters.

The modulation format generates, but does not yet modulate the carrier signal.

Once the signal generates, an annunciator showing the name of the format appears, indicating that a modulation format is active.

3. Enable modulation of the RF output: Press the **Mod On/Off** key until the LED lights.

If you enable modulation without an active modulation format, the carrier signal does not modulate until you subsequently turn on a modulation format.

Annunciator indicates active AM modulation

| FREQUENCY                            |            | AMPLITUDE       |                    | AM |  |
|--------------------------------------|------------|-----------------|--------------------|----|--|
| 6.000 000 000 00 GHz                 |            | -144.00 dBm     |                    | AM |  |
| Analog Modulation Status Information |            |                 |                    |    |  |
| AN1                                  | FuncGen1   | Depth:0.1%      | Wfm:Sine(400.0Hz)  |    |  |
| AN2                                  | FuncGen1   | Depth:0.1%      | Wfm:Sine(400.0Hz)  |    |  |
| ANWB                                 | I Input    | Depth:0,SV=100% | Wfm:Sine(400.0Hz)  |    |  |
| FM1                                  | FuncGen1   | Dev:1.0000kHz   | Wfm:Sine(400.0Hz)  |    |  |
| FM2                                  | FuncGen1   | Dev:1.0000kHz   | Wfm:Sine(400.0Hz)  |    |  |
| QM1                                  | FuncGen1   | Dev:0.000rad    | Wfm:Sine(400.0Hz)  |    |  |
| QM2                                  | FuncGen1   | Dev:0.000rad    | Wfm:Sine(400.0Hz)  |    |  |
| LFOut                                | IntMonitor | Ampl:0.000V     | Monitored:FuncGen1 |    |  |

Mod On/Off

A lit LED indicates that any active modulation format can modulate the carrier.

AM modulation format on.

**NOTE** To turn modulation *off*, press the **Mod On/Off** key until the LED turns off.

When the **Mod On/Off** key is off, the carrier signal is not modulated, even with an active modulation format.

4. To make the modulated carrier available at the RF output connector, press the **RF On/Off** key until the LED lights.

**See also:** [“Using Analog Modulation \(Option UNT\)” on page 63](#)  
[“Using Pulse Modulation \(Option UNW or 320\)” on page 113](#)  
[“I/Q Modulation” on page 188](#)

## Simultaneous Modulation

---

**NOTE** The Agilent X-Series signal generators are capable of simultaneous modulation. All modulation types (AM, FM,  $\phi$ M, and Pulse) may be simultaneously enabled. But, there are some exceptions. Refer to [Table 3-1](#).

---

**Table 3-1 Simultaneous Modulation Type Combinations**

|          | AM <sup>a</sup> | FM                    | $\phi$ M              | Pulse <sup>b</sup> |
|----------|-----------------|-----------------------|-----------------------|--------------------|
| AM       | --              | x                     | x                     | x                  |
| FM       | x <sup>c</sup>  | --                    | <i>not applicable</i> | x                  |
| $\phi$ M | x <sup>c</sup>  | <i>not applicable</i> | --                    | x                  |
| Pulse    | x               | x                     | x                     | --                 |

<sup>a</sup>Linear AM and Exponential AM *cannot* be enabled simultaneously. Refer to [Chapter 4](#).

<sup>b</sup>Pulse modulation requires Option UNW. Refer to [Chapter 6](#).

<sup>c</sup>FM and  $\phi$ M *cannot* be enabled simultaneously.

## Working with Files

- [File Softkeys](#) on page 51
- [Viewing a List of Stored Files](#) on page 52
- [Storing a File](#) on page 53
- [Loading \(Recalling\) a Stored File](#) on page 55
- [Moving a File from One Media to Another](#) on page 56
- [Working with Instrument State Files](#) on page 57
- [Selecting the Default Storage Media](#) on page 61

The signal generator recognizes several types of files, such as instrument state files, license files, and list sweep files. Files can be stored either in the signal generator's internal storage or on the USB media. This section provides an overview of how to navigate the signal generator's file menus, and how to view, store, load, and move files.

The Agilent MXG and EXG non-volatile internal memory is allocated according to a Microsoft compatible file allocation table (FAT) file system. Refer to the *Programming Guide*.


See also: [Storing, Loading, and Playing a Waveform Segment](#) on page 132.





### ARB File Softkeys

Waveform files and their associated marker and header information.



**Note:** Available file types depend on the installed options.

For details on each key, use key help as described on [page 34](#).

### Viewing a List of Stored Files

The information in this section is provided with the assumption that default storage media is set to Auto, as described on [page 61](#).

#### Viewing a List of Files Stored in the Signal Generator

1. If USB media is connected, disconnect it. The signal generator's storage media switches to internal, so you can now use the file catalogs to see files stored in the signal generator.
2. Select the desired file catalog: Press **> Catalog Type > desired catalog** (in this example, **All**). The selected files appear in alphabetical order by file name, as shown in the following figure.

The selected file catalog and the storage media

| FREQUENCY                           |        | AMPLITUDE   |                | Catalog            |             |
|-------------------------------------|--------|-------------|----------------|--------------------|-------------|
| 6.000 000 000 00 GHz                |        | -144.00 dBm |                | Catalog Type (All) |             |
| All                                 |        |             |                |                    |             |
| Catalog of All Files in Int Storage |        |             |                | 32kB used          | 29.26B free |
| File Name                           | Type   | Size        | Modified       |                    |             |
| 1 0_00                              | STATE  | 616 B       | 12/14/11 11:16 | Delete File        |             |
| 2 802_11AC_160MHZ_256Q.WFM          | SNVWFM | 106kB       | 10/28/11 13:27 | Copy File          |             |
| 3 802_11AC_80MHZ_256Q.WFM           | SNVWFM | 53.1kB      | 10/28/11 13:27 | Rename File        |             |
| 4 ANTENNA2M                         | SEQ    | 24MB        | 10/30/11 20:14 | Delete All Files   |             |
| 5 FIR_1                             | FIR    | 268 B       | 02/20/12 16:50 |                    |             |
| 6 FMRAUDIO_1_5G                     | NWMPK  | 381MB       | 10/30/11 19:38 |                    |             |
| 7 FMRAUDIO_1_5G                     | NWJFM  | 1.49GB      | 10/30/11 19:19 |                    |             |
| 8 FMRAUDIO_1_5G                     | NWHD   | 173 B       | 10/30/11 19:38 |                    |             |
| 9 FSK1_FILE                         | FSK    | 34 B        | 11/09/11 11:16 |                    |             |
| 10 FSK2_FILE                        | FSK    | 34 B        | 11/09/11 11:16 |                    |             |
|                                     |        |             |                | 02/24/2012 15:44   | More 1 of 2 |

### Viewing a list of Files Stored on USB Media

With USB media connected, you can view files on USB media using either the file catalogs, which can display only a selected type of file, or the USB File Manager, which displays all files.


Using the File Catalogs:

- With the USB media connected, select the desired file catalog: press **> Catalog Type > desired catalog**. The selected files appear in alphabetical order by file name.

Using the USB File Manager:

- With USB media connected, open the USB File Manager: press **File > More > USB File Manager**. The instrument displays the default directory on the USB Media, as shown in the following figure. Note that when you attach USB media, the display goes directly to this menu.


Use the **Page Up** and **Page Down** hardkeys to scroll through the contents of the



### Storing a File

Several menus enable you to store instrument parameters. For example, you can store instrument states, lists, and waveforms.

- An instrument state file contains instrument settings. For this type of file, use the **Save** hardkey shown in [Figure 3-8 on page 57](#).
- For other types of data, use the **Load/Store** softkey (shown below) that is available through the menu used to create the file.



| <u>File Type</u> | <u>Save From</u> |
|------------------|------------------|
| List             | Sweep menu       |
| State            | Save menu        |
| Waveform         | Mode menu        |
| User Flatness    | Amplitude menu   |
| User Preset      | User Preset menu |
| Pulse Train      | Pulse Train menu |

**Text Entry**

Enter

Clear Text

Editing Mode  
Insert Replace

Show Alpha Table  
Off On

ABCDEFGHIJKLN  
 NOPQRSTUUVWXYZ  
 \_.\$%&\*+[]

Use this menu to enter the file name, as described on [page 35](#).


**File Length** (including extension)  
 Internal Media: 25 characters  
 USB Media: 39 characters

For details on each key, use key help as described on [page 34](#).

### Loading (Recalling) a Stored File

There are several ways to load (recall) a stored file.

- For an instrument state file, use the **Recall** hardkey shown in [Figure 3-8 on page 57](#).
- For other types of data, use the Load/Store softkey (shown below) that is available through the menu used to create the file.




### Loading a File From USB Media

To load a file from USB media, use the USB file manager shown below.

**File > Catalog Type > <type> > More > USB File Manager**  
 or  
**File > More > USB File Manager**  
 or  
 Insert the USB media

| File Type     | Extension | Pressing Select with file highlighted... |
|---------------|-----------|--|
| List          | .list     | loads list and starts sweep              |
| State         | .state    | load instrument state                    |
| Waveform      | .waveform | loads and plays waveform                 |
| User Flatness | .uflat    | loads and applies user flatness          |
| User Preset   | .uprst    | loads and executes user preset           |
| License       | .lic      | installs purchased license               |
| Pulse Train   | .ptrain   | loads and applies pulse train            |




For details on each key, use key help as described on [page 34](#).

## Moving a File from One Media to Another

Use the USB Media Manager to move files between USB and internal media.

File > Catalog Type > <type> > More > USB File Manager  
or  
File > More > USB File Manager  
or  
Insert the USB Flash Drive (UFD)




For details on each key, use key help as described on page 34.

## Working with Instrument State Files

- [Saving an Instrument State](#) on page 58
- [Saving a User Preset](#) on page 58
- [Recalling an Instrument State](#) on page 58
- [Recalling an Instrument State and Associated Waveform File](#) on page 59
- [Recalling an Instrument State and Associated List File](#) on page 59
- [Moving or Copying a Stored Instrument State](#) on page 60

**Figure 3-8 Save and Recall Softkeys**



For details on each key, use key help as described on [page 34](#).

When saved to the signal generator, instrument settings (states) save to instrument state memory\*. Instrument state memory is divided into 10 sequences (0 through 9); each sequence comprises 100 registers (00 through 99).

Delete softkeys in the **Save** and **Recall** menus enable you to delete the contents of a specific register, or the contents of all sequences in the state file catalog.

The signal generator requires that you confirm a deletion.

### \*Caution

To avoid the loss of data, GPIB settings, or current user instrument states that have not been permanently saved to non-volatile memory, the instrument should always be powered down either via the instrument's front panel power button or the appropriate SCPI command. instrument's installed in rack systems and powered down with the system rack power switch, rather than the instrument's front panel switch display a Error -310 due to the instrument not being powered down correctly.

### The following information is *not* stored in a state file:

|                               |                      |                 |                 |                       |
|-------------------------------|----------------------|-----------------|-----------------|-----------------------|
| System Security Level         | Sweep lists          | Hostname        | Remote Language | Step increment values |
| System Security Level Display | Pulse Train lists    | IP Address      | FTP Server      | ARB Files             |
| System Security Level State   | Display State On/Off | Subnet Mask     | Manual DHCP     | MAC                   |
| Web Server (HTTP)             | Files                | Default Gateway | VXI-11 SCPI     | User Power Correction |
| Sockets SCPI (TELNET)         | I/Q Calibration Data |                 |                 |                       |

### Saving an Instrument State

1. Preset the signal generator and set the following:
  - Frequency: 800 MHz
  - Amplitude: 0 dBm
  - RF: on
2. (Optional, vector models only) Associate a waveform file with these settings:
  - a. Press **Mode > Dual ARB > Select Waveform**.
  - b. Highlight the desired file and press **Select Waveform**. If the file is not listed, you must first move it from internal or external media to BBG media, see [page 132](#).
3. Select the desired memory sequence (for this example, 1): Press **Save > Select Seq > 1 > Enter**.
4. Select the desired register (in this example, 01): Press **Select Reg > 1 > Save Reg**.

If a waveform is currently selected, saving the instrument state also saves a pointer to the waveform file *name*.

5. Add a descriptive comment to sequence 1 register 01:

Press **Add Comment to Seq[1] Reg[01]**, enter the comment and press **Enter**. The comment appears in the Saved States list when you press **Recall**. If the instrument state has an associated waveform, entering the waveform name in the comment makes it easy to identify which instrument state applies to which waveform.

### Saving a User Preset

A user preset is a special type of instrument state file.

1. Preset the signal generator and set as desired.
2. Press **User Preset > Save User Preset**.

This saves a state file named USER\_PRESET, which the signal generator recognizes as containing user preset information.

You can set up several preset conditions under different names:

1. After you save a user preset, rename it to something other than USER\_PRESET (see [page 60](#)).
2. Save as many user presets as you wish, renaming the USER\_PRESET file each time.
3. Give the desired file the name USER\_PRESET.

### Recalling an Instrument State

1. Preset the signal generator.
2. Press **Recall**.

The **Select Seq** softkey shows the last sequence used, and the display lists any states stored in the registers in that sequence; **RECALL Reg** is the active entry.

3. Select the desired instrument state:

If the desired state is listed in the currently selected sequence, press *desired number* > **Enter**.  
If not, press Press **Select Seq > desired number > Enter > RECALL Reg > desired number > Enter**.



### Recalling an Instrument State and Associated Waveform File

1. Ensure that the desired waveform file exists, and that it is in BBG media ([page 132](#)).

If the waveform file is not in BBG media, this procedure generates an error.

Recalling an instrument state with an associated waveform file recalls only the waveform *name*. It does not recreate the waveform file if it was deleted, or load the file into BBG media if it is in internal or USB media.

2. Recall the desired instrument state (see previous example).
3. View the waveform file name recalled with the instrument state: press **Mode > Dual ARB**.

The name is displayed as the selected waveform.

4. Turn on the waveform file: Press **Mode > Dual ARB > ARB Off On**.

### Recalling an Instrument State and Associated List File

Recalling an instrument state recalls only the list sweep setup. It does not recall the frequency and/or amplitude values. Because you must load the list file from the file catalog, when you store a list file, be sure to give it a descriptive name (up to 25 characters).

1. Recall the desired instrument state (see previous example).
2. Load the desired list file:
  - a. Press **Sweep > More > Configure List Sweep > More > Load/Store**.
  - b. Highlight the desired file and press **Load From Selected File > Confirm Load From File**.

### Editing The Comment on an Instrument Comment


Use the following steps to change a comment on an instrument state saved using the **Save** key. This is *not* the file name that appears in the State catalog (which is the file's memory location).

1. Press **Save**
2. Highlight the desired register
3. Press **Edit Comment In Seq[n] Reg [nn]**.
4. Press **Re-SAVE Seq[n] Reg[nn]**.

This overwrites previously saved instrument state settings with the new comment.

### Moving or Copying a Stored Instrument State

Figure 3-9 Instrument State File Catalog



The signal generator recognizes only the file named USER\_PRESET as user preset information ([page 58](#)).

A user-created state file's default name is its memory location (sequence and register).


To move the file, rename it to the desired sequence and register; you can not give a file the same name as an existing file. If you rename a state file to something other than a valid sequence/register name, the file does not appear in either the Save or Recall menu.

## Selecting the Default Storage Media

You can configure the signal generator to store user files to either the internal storage or to external USB media. To automatically switch between USB media and internal storage, depending on whether USB media is attached, select **Automatically Use USB Media If Present**. To avoid storing any confidential information in the instrument, select **Use Only USB Media**. To avoid storing any confidential information to USB media, select **Use Only Internal Storage**.

This selection is unaffected by power-cycle or preset.

File > More >



For details on each key, use key help as described on [page 34](#).


## Reading Error Messages

If an error condition occurs, the signal generator reports it to both the front panel display error queue and the SCPI (remote interface) error queue. These two queues are viewed and managed separately; for information on the SCPI error queue, refer to the *Programming Guide*.

| Characteristic                 | Front Panel Display Error Queue   |
|--------------------------------|---|
| Capacity (#errors)             | 30  |
| Overflow Handling              | Drops the oldest error as each new error comes in.  |
| Viewing Entries                | Press: <b>Error</b> > <b>View Next</b> (or <b>Previous</b> ) <b>Error Page</b>  |
| Clearing the Queue             | Press: <b>Error</b> > <b>Clear Error Queue(s)</b>   |
| Unresolved Errors <sup>a</sup> | Re-reported after queue is cleared.   |
| No Errors                      | When the queue is empty (every error in the queue has been read, or the queue is cleared), the following message appears in the queue:<br>No Error Message(s) in Queue 0 of 0 |

<sup>a</sup>Errors that must be resolved. For example, unlock.

### Error Message Format



The annunciator indicates an unviewed message.

new indicates a message generated since messages were last viewed.

Message number and longer description

Error messages appear in the lower left corner of the display as they occur.

| Mod   | State | Depth/Dev | Source   | Rate    | Wavefo |
|-------|-------|-----------|----------|---------|--------|
| AM    | Off   | 0.1%      | Internal | 400.0Hz | Sine   |
| FM    | On    | 1.000kHz  | Internal | 400.0Hz | Sine   |
| PM    | Off   | 0.000rad  | Internal | 400.0Hz | Sine   |
| Pulse | Off   | 2.00us    | Internal | 4.00us  | Free   |
| Burst | Off   |           | Int      |         |        |
| I/Q   | Off   |           | Internal |         |        |

| FREQUENCY   | AMPLITUDE   | Error Info               |
|---|-------------|--------------------------|
| 2.000 000 000 00 GHz  | -144.00 dBm | View Previous Error Page |
| ERR   | ERR         | View Next Error Page     |
| Error Queue   |             | Clear Error Queue(s)     |
| -221, Settings conflict: Enabled modulation source conflicts with previously enabled modulation source. Previous modulation disabled. |             | 1 of 1 (new)             |

\*\*\* PROTO CODE \*\* NOT FOR CUSTOMER USE \*\*\* 04/06/2006 10:12

---

## 4 Using Analog Modulation (Option UNT)

---

**NOTE** The Mod On/Off hardkey and LED functionality are only valid for signal generators with Option UNT installed.

---

Before using this information, you should be familiar with the basic operation of the signal generator. If you are not comfortable with functions such as setting the power level and frequency, refer to [Chapter 3, “Basic Operation,” on page 33](#) and familiarize yourself with the information in that chapter.

- [Using an Internal Modulation Source](#) on page 66
- [Using an External Modulation Source](#) on page 67
- [Removing a DC Offset](#) on page 67
- [Using Wideband AM](#) on page 67
- [Configuring the LF Output \(Option 303\)](#) on page 69

## Analog Modulation Waveforms

The signal generator can modulate the RF carrier with four types of analog modulation: amplitude, frequency, phase, and pulse. For pulse modulation information, refer to [Chapter 6, “Using Pulse Modulation \(Option UNW or 320\),” on page 113.](#)

Available internal waveforms include:


|          |   |
|----------|---|
| Sine     | sine wave with adjustable amplitude and frequency           |
| Triangle | triangle wave with adjustable amplitude and frequency       |
| Square   | square wave with adjustable amplitude and frequency         |
| Pos Ramp | positive going ramp with adjustable amplitude and frequency |
| Neg Ramp | negative going ramp with adjustable amplitude and frequency |

## Analog Modulation Sources

The signal generator provides the following internal and external modulation input sources. Internal modulation sources generate the five waveforms listed above unless noted otherwise.

|                 |  |
|-----------------|--|
| Ext1 & Ext2     | an externally applied signal is used as the modulation input. Connect the signal to the EXT 1 or EXT 2 connector on the rear panel of the instrument.  |
| Func Gen 1      | sine wave from the internal function generator. Instruments with Option 303 have additional waveform choices listed above.   |
| Func Gen 2      | Func Gen 2 has the same capability as Func Gen 1. Available on instruments with Option 303.  |
| Dual Func Gen   | dual waveforms with individually adjustable frequencies and a percent-of-peak-amplitude setting for the second tone. Available on instruments with Option 303.   |
| Swept Func Gen  | swept waveforms with adjustable start and stop frequencies, sweep time, and sweep trigger settings. Available on instruments with Option 303.  |
| Noise Gen 1 & 2 | noise with adjustable amplitude generated as a peak-to-peak value (RMS value is approximately 80% of the displayed value). Uniform and Gaussian distribution is available. Available on instruments with Option 303. |

Figure 4-1 Analog Modulation Softkeys



## Using an Internal Modulation Source

1. Preset the signal generator.
2. Set the carrier (RF) frequency.
3. Set the RF amplitude.
4. Configure the modulation:

| AM  | FM  | ΦM  |
|---|---|---|
| <p>a. Press <b>AM</b></p> <p>b. Set the AM type (Linear or Exponential):<br/><b>AM Type</b> to highlight desired type.</p> <p>c. Set the AM Mode (Normal or Deep).<br/>Default is Deep. To select <b>Normal</b> enable <b>More</b> to highlight desired type.</p> <p>d. Set the AM Depth: <b>AM Depth</b> &gt; <i>value</i><br/>Default 0.01%<br/>Range 0.01 to 100%</p> <p>e. Set the rate:<br/><b>More</b> &gt; <b>Setup AM Source</b> &gt; <b>AM Rate</b> &gt; <i>value</i> &gt; <i>frequency unit</i></p> | <p>a. Press <b>FM/ΦM</b></p> <p>b. Set the deviation:<br/><b>FM Dev</b> &gt; <i>value</i> &gt; <i>frequency unit</i></p> <p>c. Set the rate:<br/><b>More</b> &gt; <b>Setup FM Source</b> &gt; <b>FM Rate</b> &gt; <i>value</i> &gt; <i>frequency unit</i></p> | <p>a. Press <b>FM/ΦM</b> &gt; <b>FM ΦM</b></p> <p>b. Set the BW (normal or high):<br/><b>FM ΦM</b> to highlight desired type</p> <p>c. Set the deviation:<br/><b>ΦM Dev</b> &gt; <i>value</i> &gt; <b>pi rad</b></p> <p>d. Set the rate:<br/><b>More</b> &gt; <b>Setup ΦM Source</b> &gt; <b>ΦM Rate</b> &gt; <i>value</i> &gt; <i>frequency unit</i></p> |

5. Turn on the modulation:

| AM                             | FM                             | ΦM                             |
|--------------------------------|--------------------------------|--------------------------------|
| <b>AM Off On</b> softkey to On | <b>FM Off On</b> softkey to On | <b>ΦM Off On</b> softkey to On |

The appropriate modulation annunciator displays, indicating that you enabled modulation.

6. Turn on the RF output.



The RF output LED lights, indicating that the signal is transmitting from the RF output connector.

If the modulation does not seem to be working properly, refer to [“No Modulation at the RF Output” on page 310](#).

See also [“Modulating the Carrier Signal” on page 48](#).



## Using an External Modulation Source



## Removing a DC Offset

To eliminate an offset in an externally applied FM or  $\Phi$ M signal, perform a DCFM or DC $\Phi$ M Calibration.

**NOTE** You can perform this calibration for internally generated signals, but DC offset is not usually a characteristic of an internally generated signal.

1. Set up and turn on the desired modulation.
2. Press **FM/ΦM** > **FM Source** > **Ext1 or Ext2** > **More** > **Setup FM Source** > **Ext DC Cal**.

Performing the calibration with a DC signal applied removes any deviation caused by the DC signal, and the applied DC level becomes the new zero reference point. When you disconnect the DC signal, perform the calibration again to reset the carrier to the correct zero reference.


## Using Wideband AM

Wideband AM uses the I input of the I/Q modulation system. When the wideband AM is turned on, the I/Q is turned on and the I/Q source is set to external. If the I/Q is turned off or the I/Q source is set to internal, then the wideband AM turns off.

**NOTE** For frequencies between 9kHz and 5 MHz, Wideband AM turns off.

**Figure 4-2 Wideband AM Softkey Menu**

AM > AM Path 1 2 WB



Enables and disables the wideband AM feature.

Note: If the I/Q is turned off or the I/Q source is set to internal, then the wideband AM turns off.

For details on each key, use key help as described on [page 34](#).

When the Wideband AM is enabled, these fields are active.

### Setting the Wideband AM

1. Set up and enable the desired modulation type.
2. Press **AM > AM Path 1 2 WB** to **WB**.

## Configuring the LF Output (Option 303)

The signal generator has a low frequency (LF) output. The LF output's source can be switched between an internal modulation source or an internal function generator.

Using internal modulation (**Int Monitor**) as the LF output source, the LF output provides a replica of the signal from the internal source that is being used to modulate the RF output. The specific modulation parameters for this signal are configured through the AM, FM, or  $\Phi$ M menus. The internal source (AM, FM, or  $\Phi$ M) must be configured for the LF Out to provide a signal.

Using function generator as the LF output source, the function generator section of the internal modulation source drives the LF output directly. Frequency and waveform are configured from the LF output menu, not through the AM, FM, or  $\Phi$ M menus. You can select the waveform shape from the following choices:

Available internal waveforms include:

|          |   |
|----------|---|
| Sine     | sine wave with adjustable amplitude and frequency           |
| Triangle | triangle wave with adjustable amplitude and frequency       |
| Square   | square wave with adjustable amplitude and frequency         |
| Pos Ramp | positive going ramp with adjustable amplitude and frequency |
| Neg Ramp | negative going ramp with adjustable amplitude and frequency |
| Pulse    | pulse with adjustable period and width                      |

### LF Out Modulation Sources

The signal generator provides the following modulation input sources. Internal modulation sources generate the five waveforms listed above unless noted otherwise.

|                 |  |
|-----------------|--|
| Int Monitor     | uses AM, FM or $\Phi$ M settings.  |
| Func Gen 1      | waveforms from the internal function generator   |
| Func Gen 2      | waveforms from the internal function generator   |
| Dual Func Gen   | dual waveforms with individually adjustable frequencies and a percent-of-peak-amplitude setting for the second tone. Available on instruments with Option 303.   |
| Swept Func Gen  | swept waveforms with adjustable start and stop frequencies, sweep time, and sweep trigger settings. Available on instruments with Option 303.  |
| Noise Gen 1 & 2 | noise with adjustable amplitude generated as a peak-to-peak value (RMS value is approximately 80% of the displayed value). Uniform and Gaussian distribution is available. Available on instruments with Option 303. |
| DC              | selects a DC voltage level as the LF output BNC source   |

---

**NOTE** The **LF Out Off On** softkey controls the operating state of the LF output. However when the LF output source selection is **Int Monitor**, you have three ways of controlling the output. You can use the modulation source (AM, FM, or  $\Phi$ M) on/off key, the LF output on/off key, or the **Mod On/Off** softkey.

The **RF On/Off** hardkey does not apply to the LF OUTPUT connector.

## Configuring the LF Output with an Internal Modulation Source

In this example, the internal FM modulation is the LF output source. See [Figure 4-3](#).

**NOTE** Internal modulation (**Int Monitor**) is the default LF output source.

### Configuring the Internal Modulation as the LF Output Source

1. Press **Preset**.
2. Press the **FM/ΦM** hardkey.
3. Press **FM Dev > 75 > kHz**.
4. Press **More > Setup FM Source > FM Rate > 10 > kHz**.
5. Press **Return > Return > FM Off On**.


You have set up the FM signal with a rate of 10 kHz and 75 kHz of deviation. The FM annunciator is activated indicating that you have enabled frequency modulation.

### Configuring the Low Frequency Output

1. Press the **LF Out** hardkey.
2. Press **LF Out Amplitude > 3 > V**.
3. Press **LF Out Off On**.

You have configured the LF output signal for a 3 volt sine wave (default wave form) output which is frequency modulated using the **Int Monitor** source selection (default source).

**Figure 4-3** Configure the LF Out Source with FM



## Configuring the LF Output with a Function Generator Source

In this example, the function generator is the LF output source.

### Configuring the Function Generator as the LF Output Source

1. Press **Preset**.
2. Press the **LF Out** hardkey.
3. Press **LF Out Source > Func Gen 1**.

### Configuring the Waveform

1. Press **Setup LF Out Source > LF Out Waveform > Sine**.
2. Press **LF Out Freq > 500 > Hz**.
3. Press **Return**.

This returns you to the top LF Output menu.

### Configuring the Low Frequency Output


1. Press **LF Out Amplitude > 3 > V**.

This sets the LF output amplitude to 3 V.

2. Press **LF Out Off On**.

Figure 4-4 shows that the LF output is now transmitting a signal using the function generator that is providing a 3 V sine waveform.

Figure 4-4 LF Out Status Display



For details on each key, use key help as described on [page 34](#).

Using Analog Modulation (Option UNT)  
Configuring the LF Output (Option 303)

---

## 5 Optimizing Performance


Before using this information, you should be familiar with the basic operation of the signal generator. If you are not comfortable with functions such as setting the power level and frequency, refer to [Chapter 3, “Basic Operation,” on page 33](#) and familiarize yourself with the information in that chapter.

- [Using the Dual Power Meter Display on page 74](#)
- [Using Flatness Correction on page 82](#)
- [Using Internal Channel Correction on page 91](#)
- [Using External Leveling on page 94](#)
- [Using Unleveled Operating Modes on page 102](#)
- [Using an Output Offset, Reference, or Multiplier on page 105](#)
- [Using Free Run, Step Dwell, and Timer Trigger on page 109](#)
- [Using a USB Keyboard on page 112](#)

## Using the Dual Power Meter Display

The dual power meter display can be used to display the current frequency and power of either one or two power sensors. The display outputs the current frequency and power measured by the power sensors in the larger center display and in the upper right corner of the display. Refer to [Figure 5-2](#), [Figure 5-2](#), and [Figure 5-3](#).

**Figure 5-1 Dual Power Meter Display with Power Sensors A and B Calibrated**



For details on each key, use key help as described on [page 34](#).



Figure 5-2 Dual Power Meter Display Menu





Figure 5-3 Configuring the Power Sensor Channels



## Example: Dual Power Meter Calibration

In the following example a U2004A USB Power Sensor is connected to channel A and a N1912A P-Series Power Meter and 8482A Power Sensor are connected to channel B and are zeroed and calibrated, as required.

On the signal generator:

1. Setup for Step Sweep. “Configuring a Swept Output” on page 40.


---

**CAUTION** Verify RF Output power is off before continuing.

---

2. Connecting the Channel A power sensor: Connect USB sensor to the signal generator. The MXG/EXG should display a message across the bottom that reads similar to:  
USB TMC488 device (USB POWER SENSOR,MY47400143) connected


**Figure 5-4** MXG/EXG Displays Connection to U2000 USB Power Sensor



3. Press **Aux Fctn** > **Power Meter Measurements** > **Channel A Setup** > **Connection Settings** > **Connection Type** > **USB Device (None)** > USB POWER SENSOR (MY47400143)
4. Press **Return** > **Zero Sensor**


A diagnostic dialog box appears the *initial* time that a U2000 Series power sensor with a different serial number is connected to the signal generator (refer to [Figure 5-5](#)). After the U2000 has been recognized by the signal generator, the U2000 power sensor is saved as a softkey in the instrument and the dialog box in [Figure 5-5](#) won't be displayed (press DONE, if you see this message).

**Figure 5-5** Diagnostic Dialog Box for USB Sensor



A Running Calibration(s) bar is displayed on the signal generator. Refer to [Figure 5-6](#) on page 78.


**Figure 5-6** Running Calibration(s) Bar (Zeroing Sensor)



For details on each key, use key help as described on [page 34](#).

**NOTE** The U2000 Series USB Power Sensor, does *not* require a 50 MHz calibration. If a calibration is attempted with the U2000 Series Power Sensors, the signal generator displays a message reading:  
The U2000 series power sensor does not require a 50 MHz calibration. Refer to [Figure 5-7](#) on page 78.

**Figure 5-7** Diagnostic Dialog Box Displayed for U2000 Power Sensor




For details on each key, use key help as described on [page 34](#).

5. Press **Return** > **Return** > **Channel A** to On

The current power meter sensor reading should be displayed in the ChA portion of the instrument's display and in the upper right portion of the display under Power Meter. Refer to [Figure 5-8](#).

Figure 5-8 Channel A Power Sensor Displayed on MXG/EXG



For details on each key, use key help as described on page 34.


- On the N1912A P-Series Power Meter (*Channel B power sensor*): Connect the N1912A P-Series Power Meter to the LAN.
- Connect the power meter sensor to channel B of the power meter.

**NOTE** It is recommended, but not required to use the channel B on the N1912A. This provides continuity with the signal generator's dual display. For this example, the U2004A has already used up the channel A position on the signal generator.

- Connect the power sensor input to the 50 MHz reference of the power meter.
- Press **Channel B Setup**
- Press **Connection Settings > Sockets**
- Press **IP Address > IP address > Enter**

**NOTE** The IP address of the power meter should be displayed in the ChB section of the display.

Figure 5-9 Channel B Power Sensor with IP Address Entered



For details on each key, use key help as described on page 34.

- Press **Return > Channel Settings > External Power Meter Channel** to B.

13. On the signal generator: Press Channel B to On and then back to Off again. This initializes the signal generator to the external power meter.

14. Press **Return** > **Zero Sensor**

A diagnostic dialog box is displayed each time an external power meter is being used and the Zero Sensor or Calibrate Sensor softkey is pressed (refer to [Figure 5-10 on page 80](#)).

Verify the power sensor is connected to the 50 MHz reference of the power meter.

**Figure 5-10 Diagnostic Dialog Box for Channel B**



For details on each key, use key help as described on [page 34](#).


15. Press **Done**

The Running Calibration(s) bar is displayed: Zeroing Sensor Please wait....

16. After Running Calibration(s) bar disappears: Press **Calibrate Sensor**

Diagnostic Dialog box is displayed that prompts for verifying the connection of the power sensor to the power meter 50 MHz reference (refer to [Figure 5-11 on page 80](#)).

**Figure 5-11 Diagnostic Dialog Box for Calibration**




For details on each key, use key help as described on [page 34](#).

17. Press **Done**

Calibration progress bar is displayed. Refer to [Figure 5-12 on page 81](#).

**Figure 5-12 Running Calibration(s) Bar (Calibrating Sensor)**




For details on each key, use key help as described on [page 34](#).

18. Press **Return** > **Channel B** to On

19. The current power meter sensor reading should be displayed on the signal generator in the ChB portion of the display and in the upper right corner of the display under Power Meter and to the left of the Power Meter power sensor reading.

**Figure 5-13 Channel B Power Sensor Displayed on MXG/EXG**



For details on each key, use key help as described on [page 34](#).

20. The power sensors are now ready to be connected in a measurement setup.

## Using Flatness Correction

User flatness correction allows the digital adjustment of RF output amplitude for up to 1601 sequential linearly or arbitrarily spaced frequency points to compensate for external losses in cables, switches, or other devices. Using an Agilent N1911A/12A, E4419A/B, or U2000 Series power meter/sensor to calibrate the measurement system, a table of power level corrections can automatically be created for frequencies where power level variations or losses occur. Supported connection types to the power meter/sensor are Sockets LAN, VXI-11 LAN, USB, and GPIB via VXI-11 LAN using a LAN-GPIB gateway (e.g. E5810A Gateway or equivalent).

---

**NOTE** A power meter with GPIB requires using the Connection Type **VXI-11** softkey, as well as a LAN-GPIB gateway, to control a power meter. Refer to the Agilent Connectivity Guide USB/LAN/GPIB Connectivity Guide (E2094-90009), Agilent X-Series FAQs “How do I connect to the LAN?”, and to the E5810A User’s Guide or equivalent, LAN/GPIB gateway device.

---

If you do not have an Agilent N1911A/12A or E4419A/B power meter, or U2000A/01A/02A/04A power sensor, or if your power meter does not have a LAN, GPIB, or USB interface, the correction values can be manually entered into the signal generator.

To allow different correction arrays for different test setups or different frequency ranges, you may save individual user flatness correction tables to the signal generator’s memory catalog and recall them on demand.


Follow the steps in the next sections to create and apply user flatness correction to the signal generator’s RF output (see [page 86](#)).

Afterward, follow the steps in “[Recalling and Applying a User Flatness Correction Array](#)” on [page 90](#) to recall a user flatness file from the memory catalog and apply it to the signal generator’s RF output.



Figure 5-14 User Flatness Correction Softkeys

For details on each key, use key help as described on page 34.



## Creating a User Flatness Correction Array

In this example, you will create a user flatness correction array. The flatness correction array contains ten frequency correction pairs (amplitude correction values for each specified frequency), from 500 MHz to 1 GHz.

An Agilent N1911A/12A or E4419A/B power meter and E4413A power sensor are used to measure the RF output amplitude at the specified correction frequencies and transfer the results to the signal generator. (A U2000 Series power meter/sensor could be used in lieu of the power meter and E4413A power sensor.) The signal generator reads the power level data from the power meter, calculates the correction values, and stores the correction pairs in the user flatness correction array.

If you do not have the required Agilent power meter, or if your power meter does not have a LAN, GPIB, or USB interface, you can enter correction values manually.

### Required Equipment

- Agilent N1911A/12A or E4419A/B power meter (a power meter is *not* required with the U2000A/01A/02A/04A Power Sensor)
- Agilent E4413A E Series CW power sensor or U2000A/01A/02A/04A Power Sensor
- GPIB, LAN, or USB interface cables, as required
- adapters and cables, as required

---

**NOTE** For operating information on a particular power meter/sensor, refer to its operating guide.

---

### Connect the Equipment

Connect the equipment as shown in [“Connect the Equipment” on page 85](#).


---

**NOTE** During the process of creating the user flatness correction array, the power meter is remotely controlled by the signal generator.

---

## Connect the Equipment


- Agilent N1911A/12A or E4419A/B power meter<sup>a</sup>
- Agilent U2000A/01A/02A/04A power Sensor<sup>a</sup>
- LAN, GPIB, or USB interface cables, as required
- adapters and cables, as required



<sup>a</sup>For operating information, refer to the power meter/sensor documentation.

**Figure 5-15 Configure Power Meter Menu Softkeys**

AMPTD > More > User  
Flatness > Configure Power  
Meter



**Basic Procedure**

1. Create a user flatness array.
  - a. Configure the power meter/sensor
  - b. Connect the equipment
  - c. Configure the signal generator
  - d. Enter the user flatness correction values
2. Optionally, save the user flatness correction data.
3. Apply user flatness correction to the RF Output.

### Configure the U2000A/01A/02A/04A Power Sensor

1. Connect the power sensor to the signal generator's front panel USB port. Refer to [“Connect the Equipment” on page 85](#).
2. Zero the power sensor using the signal generator softkeys.

---

**CAUTION** Verify the signal generator RF Output power is set to the desired amplitude before performing the power meter zero. *No RF Output amplitude check is done by the signal generator during zero.*

---

**NOTE** The signal generator's RF Output LED remains unchanged during zeroing of the power sensor (e.g. if the RF Output LED was on prior to starting the Zeroing of the power sensor, the LED remains on throughout the zero/calibration). But, actually the instrument's firmware has turned *off* the RF Output's power.

For operating information on your particular power sensor, refer to its operation guide.

---

### Configure the E4419A/B and N1911A/12A Power Meter

1. Select SCPI as the remote language for the power meter.
2. Zero and calibrate the power sensor to the power meter, using the softkeys on the signal generator *or* the front panel of the power meter.
3. Enter the power sensor calibration factors into the power meter as required.
4. Enable the power meter's cal factor array.

---

**NOTE** The signal generator's RF Output LED remains unchanged during zeroing of the power sensor (e.g. if the RF Output LED was on prior to starting the Zeroing of the power sensor, the LED remains on throughout the zero/calibration). But, actually the instrument's firmware has turned *off* the RF Output's power.

For operating information on your particular power meter/sensor, refer to its operating guide.

---

### Example: A 500 MHz to 1 GHz Flatness Correction Array with 10 Correction Values

#### Create the User Flatness Array

1. Configure the signal generator:
  - a. Preset the signal generator.
  - b. Set the signal generator's connection type to the power meter/sensor:
    - i. Press **AMPTD** > **More** > **User Flatness** > **Configure Power Meter** > **Connection Type** > *connection type*.
    - ii. If connection type is USB:
      1. Zero Sensor
      2. Go to step **c**.

*else*

If Sockets LAN or VXI-11 LAN: Press **Power Meter IP Address** > *power meter's or LAN-GPIB gateway IP address* > **Enter**.

- iii. If Sockets LAN: Press **Power Meter IP Port** > *IP port* > **Enter**.

*else*

If VXI-11: Press **PM VXI-11 Device Name** > *device name* > **Enter**.

When connecting directly to the power meter, enter the *device name* as specified in the power meter's documentation. Typically, this is "inst0" and is case sensitive for some power meters. Refer to your power meter's documentation, the Agilent Connectivity Guide USB/LAN/GPIB Connectivity Guide (E2094-90009), and Agilent X-Series FAQs "How do I connect to the LAN?"

When connecting via a LAN-GPIB gateway, enter the SICL address of the power meter. Typically, this is "gpib0,13", where "gpib0" is the GPIB SICL interface name of the gateway and "13" is the GPIB address of the power meter. Refer to the Agilent Connectivity Guide USB/LAN/GPIB Connectivity Guide (E2094-90009), Agilent X-Series FAQs "How do I connect to the LAN?", and to the E5810A User's Guide or equivalent, LAN/GPIB gateway device.

- c. Open the User Flatness table editor and preset the cal array:  
Press **Return** > **Configure Cal Array** > **More** > **Preset List** > **Confirm Preset with Defaults**.
- d. In the Step Array menu, enter the desired flatness-corrected start and stop frequencies, and the number of points:

Press **More** > **Configure Step Array** >

**Freq Start** > **500** > **MHz** >

**Freq Stop** > **1** > **GHz** >

**# of Points** > **10** > **Enter**

- e. Populate the user flatness correction array with the step array configured in the previous step:

Press **Return** > **Load Cal Array From Step Array** > **Confirm Load From Step Data**.

- f. Set the output amplitude to 0 dBm.
- g. Turn on the RF output.

2. Connect the power meter to the RF output and enter the correction values:

| With a Power Meter Over LAN, GPIB, or USB   | Manually   |
|---|--|
| <p>i. Create the correction values:<br/>Press <b>More &gt; User Flatness &gt; Do Cal.</b></p> <p>The signal generator begins the user flatness calibration, and displays a progress bar.</p> <p>The amplitude correction values load automatically into the user flatness correction array.</p> <p>ii. View the stored amplitude correction values:<br/>Press <b>Configure Cal Array.</b></p> | <p>i. Open the User Flatness table editor and highlight the frequency value in row 1:<br/>Press <b>More &gt; User Flatness &gt; Configure Cal Array.</b></p> <p>The RF output changes to the frequency value of the table row containing the cursor.</p> <p>ii. Note the value measured by the power meter.</p> <p>iii. Change the sign on the delta value (e.g. <i>the delta value of the 0 dBm reference value (step f), and the measured value from ii is -.34, change the value to +.34</i>).</p> <p>iv. Highlight the correction value in row 1.</p> <p>v. Press <b>Select &gt; enter the delta calculated in step iii &gt; dB.</b><br/>(e.g. For this example enter +.34)</p> <p>The signal generator adjusts the output amplitude based on the correction value entered.</p> <p>vi. Repeat steps <b>ii – v</b> until the power meter reads 0 dBm.</p> <p>vii. Highlight the frequency value in the next row.</p> <p>viii. Repeat steps <b>ii</b> through <b>vii</b> for the remaining rows.</p> |

The user flatness correction array title displays User Flatness: (UNSTORED), without a name, indicating that the current user flatness correction array data has *not* been saved to the file catalog.

### Optional: Save the User Flatness Correction Data

1. Press **Load/Store > Store to File.**
2. Enter a file name (for this example, FLATCAL1) and press **Enter.**

The user flatness correction array file is now stored in the file catalog as a USERFLAT file. Any user flatness correction files saved to the catalog can be recalled, loaded into the correction array, and applied to the RF output to satisfy specific RF output flatness requirements.

3. Press **Return.**

### Enable the Flatness Correction at the RF Output

- Press **Return > Flatness Off On.**

The UF annunciator appears in the AMPLITUDE area of the display, and the correction data in the array is applied to the RF output.

## Recalling and Applying a User Flatness Correction Array

The following example assumes that a user flatness correction array has been created and stored. If not, perform the [Example: A 500 MHz to 1 GHz Flatness Correction Array with 10 Correction Values](#) on page 87.

1. Preset the signal generator.
2. Recall the desired User Flatness Correction file:
  - a. Press **AMPTD** > **More** > **User Flatness** > **Configure Cal Array** > **More** > **Preset List** > **Confirm Preset**.
  - b. Press **Load/Store**.
  - c. Highlight the desired file.
  - d. Populate the user flatness correction array with the data contained in the selected file:  
Press **Load From Selected File** > **Confirm Load From File**.  
The user flatness correction array title displays User Flatness: *Name of File*.
3. Apply the correction data in the array to the RF output: Press **Return** > **Flatness Off On** to **On**.



## Using Internal Channel Correction

The internal channel correction feature corrects the 100 MHz baseband bandwidth flatness and phase for arbitrary center frequencies. This feature is off by default, as the switching speed performance of the instrument is impacted when this feature is on.

This calibration should be run when the ambient temperature has varied by at least  $\pm 5$  degrees Celsius from the ambient temperature at which the previous calibration was run.

---

**NOTE** There is an internal calibration routine that can be run to collect correction data for both the baseband and RF magnitude and phase errors over the entire RF frequency range on any unit with options 653 and 656. The internal channel correction cannot be turned on until after the correction has been executed once.

---

When this feature is off, the box will behave as it always has. When this feature is on, the internal I/Q path is active, the I/Q Correction Optimized Path is RF Output, and the frequency is changed by more than 1 kHz, the firmware will calculate a channel correction filter  $\pm 50$  MHz about the specified frequency. For List/Sweep, the calculation will be done prior to the first sweep using the specified frequencies when either waveform sweep is active or the baseband is on and the instrument is optimized for the internal path. This calculation will cache corrections for up to the maximum number of cache points (256). For list/sweep, the sweep will pause and recalculate the correction caches before running again.

---

**CAUTION** In the case of arbitrary frequency switching, once the correction cache is full (256 unique frequency points), the oldest frequency corrections will be forgotten as new frequencies are selected.


Whenever I/Q Timing Skew, I/Q Delay, Quadrature Angle Adjustment, or the Int Equalization Filter is adjusted, all caches are forgotten.

---

Additional characteristics of the internal channel correction:

- When the internal channel correction is on, arbitrary frequency switching while the baseband is on will take up to an additional 290 ms (72 ms typical) the first time that frequency is specified. After the first time that a frequency is selected, switching to that frequency again takes an additional 1 ms.
- If a frequency sweep is activated, then the calculation and caching will occur up front for the first 256 unique frequencies, and all additional unique frequencies will have the characteristics of arbitrary frequency switching.
- If the I/Q Correction Optimized Path softkey is set to Ext I/Q, then only the baseband corrections will be applied and the frequency switching will be unaffected.
- If active, the ACP Internal I/Q Channel Optimization filter and the Equalization filter, will be convolved with the internal channel correction. A hamming window is applied and the resulting filter will be truncated to 256 taps.

Figure 5-16 Internal Channel Correction Softkeys



## Configure Internal Channel Correction

The following is a basic configuration for using the signal generator's internal channel correction. Refer to [Figure 5-16](#).

On the signal generator:

1. Set the center frequency:

Press **Freq > 3 > GHz**

2. Set the I/Q to internal (default):

Press **I/Q > I/Q Source > Internal**


3. Press **I/Q** to On

4. Perform internal channel correction:

Press **More > Int Channel Correction Off On** to **On**


## Using External Leveling

**CAUTION** While operating in external leveling mode, if either the RF or the DC connection between the signal generator and the detector is broken, maximum signal generator power can occur. This maximum power may overstress a power-sensitive device under test.



External leveling lets you move the ALC feedback source closer to the device under test (DUT) so that it accounts for most of the power uncertainties inherent to the cabling and components in a test setup. Refer to [Figure 5-17](#).

**Figure 5-17 ALC Circuitry**



The external detector outputs a negative voltage to the signal generator’s rear panel **ALC INPUT** connector based on the power level at the detector. As the RF power level at the coupler’s/power splitter input changes, the external detector returns a compensating negative voltage. The ALC circuit uses this negative voltage to level the RF output power by raising and lowering the signal’s power, thus ensuring a constant power level at the point of detection (external detector). Since the point of detection does not occur at the output of the device to which the detector is connected, there is some power loss that is not compensated for by the external detector. For example on a coupler, the coupled port siphons some of the signal’s energy to drive the external detector. In addition the coupler experiences some insertion loss between the coupled port and the output.

[Figure 5-19 on page 97](#) shows the input power versus output voltage characteristics for typical Agilent Technologies diode detectors. Using this chart, you can determine the leveled power at the diode detector input by measuring the external detector output voltage. For a coupler, you must then add the coupling factor to determine the leveled output power.

When using an external detector, the signal generator’s power range may vary from the values shown in the data sheet. This is primarily due to the efficiency of the detector. Always ensure that the detector, coupler/power splitter are specified for the power and frequency range of interest. To determine the signal generator’s actual power range during external leveling, see [“Determining the Signal Generator’s Amplitude Range” on page 99](#).

With external leveling, the displayed amplitude value can vary significantly from the actual output power of the coupler/power splitter to which the external detector is connected (see [Figure 5-18](#)). This is because the coupler/power splitter has its own signal characteristics (insertion loss, coupling factor, and so forth), which are unknown to the signal generator, so it is typically unable to display an accurate amplitude value. Also components between the signal generator and the external detector can affect the output power of the coupler/power splitter. You can compensate for this power display difference by using the

**Ext Leveling Amptd Offset** softkey or the **Amptd Offset** softkey. The difference between the two softkeys is that the **Ext Leveling Amptd Offset** functions only while external leveling is active. For more information on using the external leveling offset feature, see “[Adjusting the Signal Generator Display’s Amplitude Value](#)” on page 101.

**Figure 5-18 Power Value Differences with External Leveling**





Figure 5-19 Typical Diode Detector Response at 25° C



### Option 1EQ Output Attenuator Behavior and Use

When using the internal detector, the Option 1EQ output attenuator enables signal generator power levels down to  $-127$  dBm at the RF Output connector. It accomplishes this by adding attenuation to the output signal after the ALC detection circuit. The output power value (shown in the Amplitude area of the display) is the resultant of the **Set Atten** and **Set ALC Level** values (see [page 94](#)). With the external detector selected, the output attenuator no longer attenuates the output signal since the

feedback for the detection circuit has been moved beyond the output attenuator. Because the attenuator no longer affects the amplitude of the output signal, the output amplitude is determined by only the **Set ALC Level** softkey.

With external leveling selected, the signal generator enables attenuator hold and the power range approximates the range of a standard option (no attenuator) signal generator (see the *Data Sheet*). As stated earlier, the actual output power may vary due to the external detector and the coupler/power splitter performance characteristics.

---

**NOTE** When the internal detector (**Internal** selection) is reselected, the signal generator does not turn the attenuator hold off.

---

Even though the output attenuator no longer affects the output power, it is still useful to drive the ALC circuit to its mid-power point of approximately 0 dBm, which is optimal for the internal leveling circuitry and typically provides the best amplitude flatness results. This is useful with negative power values of -5 dBm or less. For example, to drive the ALC to approximately mid-power with a -20 dBm power setting, add 25 dB of attenuation. This sets the ALC circuit to 5 dBm (-20 + 25).

---

**NOTE** If there is too much attenuation, it will drive the ALC circuit too high and cause the signal generator to go unlevelled. Ensure that you decrease the attenuation as you increase the power level.

---

## Configure External Leveling

### Basic Setup Process

- If working with a single frequency signal, perform Steps 1 through 5.
  - If working with multiple frequencies:
    - a. Perform Steps 1 through 4.
    - b. Perform a user flatness correction, see [“Using Flatness Correction” on page 82](#).
  - If working with a sweep:
    - a. Perform Steps 1 through 4.
    - b. Setup the sweep, see [“Configuring a Swept Output” on page 40](#).
1. Setup the equipment, see [“Equipment Setup” on page 98](#)
  2. Configure the carrier signal, see [“Configuring the Carrier” on page 99](#)
  3. Select external leveling, see [“Selecting External Leveling” on page 99](#).
  4. Determine the output amplitude range, see [“Determining the Signal Generator’s Amplitude Range” on page 99](#)
  5. Set the displayed power value, see [“Adjusting the Signal Generator Display’s Amplitude Value” on page 101](#)

### Equipment Setup


Set up the equipment as shown in [Figure 5-20 on page 99](#). Place the external detector (detector and coupler/power splitter) as close as possible to the DUT.



### Recommended Equipment

- Agilent 8474E negative detector
- Agilent 87301D directional coupler
- cables and adapters, as required

**Figure 5-20 Typical External Leveling Setup using a Directional Coupler**



### Configuring the Carrier

1. Press **Preset**.
2. Set the carrier frequency.
3. Set the power level to 0 dBm:
  - If the signal generator has Options 1E1 and 520, set the output attenuator to zero dBm:
    - a. Press **AMPTD > Atten/ALC Control > Atten Hold Off On** to On.
    - b. Press **Set Atten > 0 > dB**.
    - c. Press **Set ALC Level > 0 > dBm**.

### Selecting External Leveling

Press **AMPTD > Leveling Control > Leveling Mode > Pwr Meter Cont.**

### Determining the Signal Generator's Amplitude Range

The maximum output amplitude is frequency dependent. So if you are using multiple frequency points and there is a need to know the maximum output amplitude for each frequency point, refer to the "Amplitude" section of the *X-Series Data Sheet*. Then use this procedure to determine the maximum amplitude for each band.

With external leveling and Option 1EQ, the signal generator's power range approximates that of a standard option instrument (no Option 1EQ). But Option 1EQ does let you use the attenuator to drive the ALC to its mid-power point when using negative amplitude values. However adding attenuation does decrease the upper range limit. For more information, see [“Option 1EQ Output Attenuator Behavior and Use” on page 97](#).

1. If Option 1EQ is installed, adjust the attenuator to the desired level.

---

**NOTE** If the Option 1EQ output attenuator value is too high (approximately  $\geq 55$  dB), it will cause an unlevel condition to occur when the RF output is turned on.

---

- a. Press **AMPTD > Atten/ALC Control > Atten Hold On > Set Atten.**
  - b. Enter the attenuator value.
2. Turn on the RF output: Press **RF On/Off** to On
  3. Set the **AMPTD** step increment value to one dB.
    - Press **AMPTD > Incr Set > 1 > dB.**
  4. Determine the minimum amplitude value:
    - a. Set the amplitude to  $-25$  dBm.
    - b. Using the down arrow key, decrease the amplitude until the UNLEVEL annunciator appears.
    - c. Using the up arrow key, increase the amplitude until the UNLEVEL annunciator is gone.  
The value showing when the UNLEVEL annunciator is gone is the minimum amplitude range value.
  5. Determine the maximum amplitude value:
    - a. Set the amplitude to a value that does not cause the signal generator to go unlevelled.
    - b. Using the up arrow key, increase the amplitude until it goes unlevelled or an error message indicating that the upper limit has been reached shows at the bottom of the display.
    - c. Decrease the amplitude value:
      - If the unlevelled annunciator appeared, decrease the amplitude until the annunciator is gone. The value where the annunciator disappears is the maximum upper range value.
      - If the signal generator displays Error: 501, Attenuator hold setting over range at the bottom of the display, the value showing is the maximum upper range value.  
To remove the error message, press the down arrow key until the message is gone. The error appears when an attempt is made to increase the amplitude beyond the maximum value as it relates to the current attenuator setting.

### Adjusting the Signal Generator Display's Amplitude Value

When using external leveling, the signal generator's displayed amplitude value will not match the leveled power of the signal at the output of the coupler/splitter. To compensate for this difference, the signal generator provides two methods for configuring the displayed power value so that it closely matches the measured value at the output of the coupler/splitter.

1. Connect and configure a measurement instrument:
  - a. Connect the output of the coupler/splitter to either a power meter or a signal analyzer.
  - b. Configure the power meter/signal analyzer for measuring the power level of the signal.
2. Adjust the signal generator's displayed amplitude value:
  - If using the **Ext Leveling Amptd Offset** Softkey:
 

This softkey uses 16 dB as its zero reference. The 16dB is the coupling factor of the internal detector.

    - a. On the signal generator, press **AMPTD > Leveling Control > Ext Leveling Amptd Offset**.
    - b. While viewing the carrier amplitude value on the signal generator display, use the RPG knob (detent knob) to adjust the offset value until the integer part of the displayed amplitude value is the same as the integer portion of the measured value.
 

Each detent position adjusts the value by 1 dB.
    - c. Using the number keypad, make the necessary fractional adjustments to the display amplitude value.
  - If using the **Amptd Offset Softkey**:
    - a. On the signal generator, press **AMPTD > Leveling Control > More > Amptd Offset**.
    - b. Calculate the difference between the signal generators displayed Amplitude value and the measured value.
    - c. Using the numeric keypad, enter this difference as the **Amptd Offset** softkey value.



## Power Search Mode

---

**NOTE** The power search mode cannot be used with bursted signals input via the external IQ inputs.

---

The MXG/EXG has three power search modes (for internal and external I/Q modulation) and four power search references (for external I/Q modulation only). Refer to [Figure 5-21 on page 102](#).

Power search executes a routine that temporarily activates the ALC, calibrates the power of the current RF output, and then disconnects the ALC circuitry.

### Power Search Modes (Applies to External and Internal I/Q Modulation)

- Auto – A power search is executed at each frequency or power change, and at each change to the AM, burst, pulse, or I/Q modulation state.
- Span – When **Power Search** is set to Span, pressing **Do Power Search** executes the power search calibration routine over a range of user-defined frequencies. The power search is stored and used when the signal generator is tuned within a user-defined range. After the Span softkey is pressed, select either **Full** or **User**. If **User** is selected, then the start and stop frequencies need to be selected.
- Manual – When **Power Search** is set to Manual, pressing **Do Power Search** executes the power search calibration routine for the current RF frequency and amplitude. In this mode, if there is a change in RF frequency or amplitude, you will need to press **Do Power Search** again.

### Power Search References (Only applies to Internal I/Q Modulation)

The four Power Search References control the power search function. These four references select the reference voltage used while the RF signal is being I/Q modulated. (Power search references are not used for analog modulation: FM,  $\phi$ M, or pulse modulation.)

---

**CAUTION** If the power search reference has the incorrect RMS voltage, the output power will be incorrect. Refer to [Figure 5-22, "Calculating the Output Power Error for a Single Waveform Sample Point"](#) and [Figure 5-23, "Calculating the RMS Voltage of the Waveform."](#)

---



---

**NOTE** A successful power search is dependent on a valid power search reference.

---

- Fixed – Reference level is 0.5 Vrms.  
This reference functions with internal, external IQ and bursted signals. This is the instrument's default setting.
- RMS – User provided reference level 0–1.414 Vrms placed in the Waveform Header. Refer to ["Saving a Waveform's Settings & Parameters" on page 139](#).  
This reference functions with internal IQ and bursted signals.
- Manual – User provided reference level 0–1.414 Vrms.  
This reference functions with internal, external IQ and bursted signals.
- Modulated – Uses the I/Q modulation signal as the reference level.  
This reference functions with internal or external IQ. It is not functional with bursted signals or a signal with varying Vrms.

**Figure 5-22 Calculating the Output Power Error for a Single Waveform Sample Point**

$$\text{The Output Power Error} = 20 \times \log_{10}((V1)/(V2))$$

Where:

V1 is the actual waveform RMS voltage

V2 is the entered RMS voltage

Note: If the RMS voltage value entered is lower than the actual RMS voltage, the output power will be higher than desired. If the RMS voltage value entered is higher than the actual RMS voltage, the output power will be lower than desired.

**Figure 5-23 Calculating the RMS Voltage of the Waveform**

$$\text{RMS value for the waveform} = \sqrt{\sum_{n=1}^N (i_n^2 + q_n^2) \cdot \frac{1}{N}}$$

N = # of Samples

The signal generator can calculate the RMS value automatically. If more than two contiguous IQ data points are zero, the signal generator calculation ignores those zero points. Also, because the RMS calculation, that is done by the signal generator, is slow and may not be appropriate for your application, it is recommended that the user calculate and enter in their measured RMS value for the waveform file.

SCPI Commands:

```
[ :SOURCE ] :RADio:ARB:HEADER:RMS <"file_name">, <val> | UNSpecified
[ :SOURCE ] :RADio:ARB:HEADER:RMS? <"file_name">
```

For a programming example of determining the RMS voltage of a waveform, refer to the *Programming Guide* and to the *Documentation CD* that came with this instrument.

The RMS and MANUAL references are the most powerful selections. The user provides the reference level. The IQ signal can be bursted (radar) or have different RMS levels (Wireless Signals). Once the RMS/MANUAL reference level is set, the power search runs independent of the current Vrms value of the waveform.

The RMS and MANUAL references, with a reference level of 1.0 Vrms are equivalent to a calculated rms value of 1 and can be measured using SINE\_TEST\_WFM.

The FIXED, RMS, and MANUAL references use a DAC to apply the reference voltage and do not require the IQ signal to be present.

---

**NOTE** The MXG/EXG reference voltage is designed to operate between 0.1 Vrms to 1 Vrms nominally, but it can overrange to 1.414 Vrms. (The RMS can overrange to 1.414, if the constant values are loaded manually and all “1”s are entered for the I and Q values.) See also “Saving a Waveform’s Settings & Parameters” on page 139.

---



---

**CAUTION** The minimum reference level that results in a successful power search is dependent on RF Frequency, RF Amplitude, and Temperature. An MXG/EXG power search using a reference level of 0.1 Vrms for 0 dBm at 1 GHz may fail.

---

## Power Search Settings

For the power search routine to execute, the instrument must be in the following conditions:

- The I/Q modulation enabled On.
- The RF output enabled On.
- The Automatic Leveling Circuitry deactivated (Off).
- The RF Blanking set to On.

This function prevents power spikes during the power search (refer to [“Using the RF Blanking Marker Function” on page 156.](#))

- When using summing for the internal Arb and the external I/Q, all four power reference modes are available (e.g. Fixed, RMS, Manual, and Modulated).
- When using the external IQ inputs, use the MANUAL reference mode, and make sure the external I/Q signal is present when executing a power search. If the external I/Q signal is not present, the power search will fail.

### Example: Automatic Power Search

1. Preset the signal generator.
2. Set the desired frequency.
3. Set the desired amplitude.
4. Turn the RF output on.
5. Deactivate the signal generator’s automatic leveling control:

Press **AMPTD > ALC Off On** to highlight Off

Deactivating the signal generator’s automatic leveling control is a significant instrument change that automatically initiates a power search.

When set to Auto, power search automatically executes when a significant instrument setting changes. The Do Power Search feature enables you to decide when to execute a power search to compensate for changes, such as temperature drift or a change in the external input.

## Using an Output Offset, Reference, or Multiplier

### Setting an Output Offset

Using an output offset, the signal generator can output a frequency or amplitude that is offset (positive or negative) *from* the entered value.


RF Output = entered value – offset value

Displayed Value = output frequency + offset value

To set an offset:

- *Frequency:* Press **Freq > Freq Offset > offset value > frequency unit.**


- *Amplitude:* Press **Amptd** > **More** > **Amptd Offset** > *offset value* > **dB**.



### Examples

| Parameter                      | Example #1 | Example #2 | Example #3 | Comments  |
|--------------------------------|------------|------------|------------|---|
| Entered (and displayed) Value: | 300 MHz    | 300 MHz    | 2 GHz      | The entered value must be positive.   |
| Offset:                        | 50 MHz     | -50 MHz    | -1 GHz     | An offset value can be positive or negative.  |
| Output Frequency:              | 250 MHz    | 350 MHz    | 3 GHz      | The signal generator alerts you if the output frequency or amplitude is out of range. |

When using the signal generator as a local oscillator (LO), you can use the offset to display the frequency of interest, as illustrated below:



### Setting an Output Reference

Using an output reference, the signal generator can output a frequency or amplitude that is offset (positive or negative) *by* the entered value *from* a chosen reference value.

$$\text{RF Output} = \text{reference value} + \text{entered value}$$

To set a reference:

1. Set the frequency or amplitude to the value you want as the output reference level.
2. *Frequency:* Press **Frequency** > **Freq Ref Set**  
The frequency displays 0.00 Hz, indicating that this is the RF output frequency “zero level.”




All frequencies entered are interpreted as being relative to this reference frequency.

*Amplitude:* Press **Amptd** > **More** > **Amptd Ref Set**

The amplitude displays 0.00 dB, indicating that this is the RF output amplitude “zero level.”

All amplitudes entered are interpreted as being relative to this reference amplitude.



## Examples

| Parameter                      | Example #1 | Example #2 | Example #3 | Comments  |
|--------------------------------|------------|------------|------------|---|
| Reference:                     | 50 MHz     | 50 MHz     | 2 GHz      | A reference value must be positive.   |
| Entered (and displayed) Value: | 2 MHz      | -2 MHz     | -1 GHz     | The entered value can be positive or negative.  |
| Output Frequency:              | 52 MHz     | 48 MHz     | 1 GHz      | The signal generator alerts you if the output frequency or amplitude is out of range. |

To set a new frequency or amplitude reference, turn the frequency reference off, and then follow the steps above.

## Setting a Frequency Multiplier

Using a frequency multiplier, the signal generator can display a frequency that is the multiple (positive or negative) of the output value.


Displayed Value = multiplier value × output frequency

Output Frequency = displayed value ÷ multiplier value

To set a frequency multiplier:

1. Press **Frequency** > **Freq Multiplier** > *multiplier value* > **x**.
2. Set the desired frequency.  
The display equals the output frequency times the multiplier value.


Indicates that a frequency multiplier is on



**Examples**


| Parameter                      | Example #1 | Example #2 | Example #3 | Comments  |
|--------------------------------|------------|------------|------------|---|
| Frequency Multiplier:          | 3          | -3         | 4          | The multiplier range can be set from:<br>+0.001 to +1000<br>-1000 to -0.001 |
| Entered (and displayed) Value: | 600 MHz    | -600 MHz   | 8 GHz      |   |
| Output Frequency:              | 200 MHz    | 200 MHz    | 2 GHz      | The signal generator alerts you if the output frequency is out of range.    |

When using the signal generator as the input to a system, you can set the frequency multiplier so that the signal generator displays the output of the system, as illustrated below using a doubler:



When measuring mixers, the frequency multiplier and frequency offset are often used together. In the upconverter example below, the multiplier is set to -1 and the offset is set to 3 GHz so that the

signal generator displays  $f_{RF}$ .




| Selected Multiplier | Selected Offset | Entered/Displayed Frequency ( $f_{RF}$ ) | Signal Generator Output ( $f_{LO}$ ) |
|---------------------|-----------------|--|--------------------------------------|
| -1                  | 3000 MHz        | 2200 MHz                                 | 800 MHz                              |
| -1                  | 3000 MHz        | 2400 MHz                                 | 600 MHz                              |

## Using the Frequency and Phase Reference Softkeys

The MXG/EXG can be set to have either a user-determined frequency or phase reference.

Figure 5-24 Frequency Reference and Frequency Offset Softkeys



## Using Free Run, Step Dwell, and Timer Trigger

Free Run, Step Dwell (time), and Timer Trigger can be used to adjust the time spent at any point in a Step Sweep or a List Sweep. There are two possible measurement combinations:

*Free Run with Step Dwell time* (Figure 5-25 on page 111) the signal generator waits for the signal to settle and then waits for the Step Dwell time, then it jumps to the next frequency point. In addition, the time to complete the entire sweep can vary. There is *always* a minimum value of Step Dwell for each frequency point. The minimum Step Dwell timing for any point is fixed at a value of 100 us. The time between frequency points is the sum of the settling time, plus the Step Dwell time. The settling time is dependent on frequency, amplitude, band crossings, and other factors, so the time between frequency points can vary.

*Timer Trigger instead of Free Run* (Figure 5-25 on page 111) the signal generator generates equally spaced triggers, and it moves to the next point at each trigger. This has the advantage that the time between points is consistent and the overall sweep time is consistent. But, if the trigger is too fast, the signal may not have time to settle before jumping to the next point.

### **Understanding Free Run, Step Dwell, and Timer Trigger Setup**


If the signal is to be settled for a minimum specific time at each point and it is *not* important if the point to point time is consistent, use **Free Run** and **Set Dwell** time.

If the signal's point to point time requires consistency but the specific settling time at each point can vary, then use the Timer Trigger. Avoid using too fast of a sweep which does *not* allow the signal generator to settle.

If the signal needs to be settled for a specific minimum time *and* consistent point to point time is required, then you should set the Timer Trigger to be the sum of the switching time (900 us or 5 ms, depending on options) *plus* the minimum settled time that is needed to make the measurement.

If the measurement requires external equipment synchronization, consider using hardware triggers.

Figure 5-25 Free Run, Set Dwell, and Timer Trigger Softkeys



For details on each key, use key help as described

## Using a USB Keyboard

You can use a USB keyboard to remotely control the RF output state, the modulation state, and to select a memory sequence and register.

The register selection, RF output state, and modulation state are affected by power cycle or preset, but the USB keyboard control state and the sequence selection are not.

**CAUTION** To avoid the loss of data, GPIB settings, or current user instrument states that have not been permanently saved to non-volatile memory, the signal generator should always be powered down either via the instrument's front panel power button or the appropriate SCPI command. Signal generators installed in rack systems and powered down with the system rack power switch rather than the instrument's front panel switch display a Error -310 due to the instrument not being powered down correctly.

| USB Keyboard Key         | Signal Generator Function      |
|--------------------------|--------------------------------|
| Delete, Enter            | RF On/Off                      |
| Insert                   | Mod On/Off                     |
| Home, Up Arrow           | Next Sequence                  |
| End, Down Arrow          | Previous Sequence              |
| Page Up, Right Arrow, +  | Recall Next State Register     |
| Page Down, Left Arrow, - | Recall Previous State Register |

Deletes every register in every sequence.

NOTE: You cannot recover the registers after deleting them.

Turning the USB keyboard control off disables the USB keyboard; it has no effect on the Auto Recall softkeys.

For details on each key, use key help as described on see [page 34](#).


---

## 6 Using Pulse Modulation (Option UNW or 320)

Before using this information, you should be familiar with the basic operation of the signal generator. If you are not comfortable with functions such as setting the power level and frequency, refer to [Chapter 3, “Basic Operation,” on page 33](#) and familiarize yourself with the information in that chapter.

- [Pulse Characteristics](#) on page 115
- [The Basic Procedure](#) on page 117
- [Example](#) on page 117
- [Pulse Train \(Option 320 – Requires: Option UNW\)](#) on page 119

Figure 6-1 Pulse Softkeys





## Pulse Characteristics

**NOTE** When using very narrow pulses that are below the signal generator's ALC pulse width specification, or leveled pulses with an unusually long duty cycle, it is often useful to turn ALC off (see [page 102](#)).

| Pulse Source       | Type  | Period <sup>a</sup>              | Width & Delay <sup>a</sup>  | Uses Trigger Event <sup>b</sup> |
|--------------------|---|----------------------------------|---|---------------------------------|
| Square             | Internal free run pulse train with 50% duty cycle.      | Determined by user defined rate. | —   | —                               |
| Free Run (default) | Internal free run pulse train                           | User Defined                     | User Defined  | —                               |
| Triggered          | Internal pulse train                                    | —                                | User Defined  | ✓                               |
| Adjustable Doublet | Two internal pulse trains for each trigger event.       | —                                | User Defined:<br>First pulse is relative to the rising edge of trigger signal.<br>Second pulse is relative to the rising edge of first pulse.<br>See <a href="#">Figure 6-2 on page 116</a> | ✓                               |
| Trigger Doublet    | Two internal pulse trains for each trigger event.       | —                                | The first pulse follows the trigger signal.<br>Second pulse is user defined.<br>See <a href="#">Figure 6-3 on page 116</a>  | ✓                               |
| Gated              | Internal gated pulse train                              | —                                | User Defined  | ✓                               |
| External           | External pulse signal at the rear panel Pulse connector | —                                | —   | —                               |
| Pulse Train        | Internal pulse train                                    | User Defined                     | User Defined:<br>See <a href="#">Figure 6-4 on page 119</a>   | ✓                               |


<sup>a</sup>All delays, widths, and periods have a resolution of 10 ns.

<sup>b</sup>A signal at the rear panel pulse connector must be held high for at least 20 ns to trigger an internally generated pulse.


Rear panel inputs are described on [page 12](#)



**Figure 6-2 Adjustable Doublet**



**Figure 6-3 Trigger Doublet**



## The Basic Procedure

1. Preset the signal generator.
2. Set the carrier (RF) frequency.
3. Set the RF amplitude.
4. Configure the modulation:
  - a. Set the pulse source: Press **Pulse > Pulse Source > selection**
  - b. Set the parameters for the selected pulse source:

| Square     | Free Run (default) | Triggered   | Adjustable Doublet | Trigger Doublet | Gated        | Pulse Train <sup>a</sup> | External |
|------------|--------------------|-------------|--------------------|-----------------|--------------|--------------------------|----------|
| Pulse Rate | —                  | —           | —                  | —               | —            | —                        | —        |
| —          | Pulse Period       | —           | —                  | —               | Pulse Period | —                        | —        |
| —          | Pulse Delay        | Pulse Delay | Pulse Delay        | Pulse Delay     | —            | Pulse Delay              | —        |
| —          | Pulse Width        | Pulse Width | Pulse Width        | Pulse Width     | Pulse Width  | —                        | —        |
| —          | —                  | —           | Pulse 2 Delay      | —               | —            | —                        | —        |
| —          | —                  | —           | Pulse 2 Width      | —               | —            | —                        | —        |
| —          | —                  | —           | —                  | —               | —            | Pulse On <sup>b</sup>    | —        |
| —          | —                  | —           | —                  | —               | —            | Pulse Off <sup>b</sup>   | —        |

<sup>a</sup> Requires Option 320.

<sup>b</sup> Up to 2047 pulse cycles (elements) composed of both Pulse On and Pulse Off can be user defined.

5. Turn on the modulation: **Pulse Off On** softkey to On.  
The the PULSE annunciator lights, indicating that you enabled modulation.
6. Output the modulated signal from the signal generator: Press the front panel **RF On Off** key.  
The RF output LED lights, indicating that the signal is transmitting from the RF output connector.  
See also, [“Modulating the Carrier Signal” on page 48.](#)

## Example

The following example uses the factory preset pulse source and delay.

**Output:** A 2 GHz, 0 dBm carrier modulated by a 24  $\mu$ s pulse that has a period of 100  $\mu$ s.

1. Preset the signal generator.
2. Set the frequency to 2 GHz.
3. Set the amplitude to 0 dBm.

4. Set the pulse period to 100 microseconds: Press **Pulse > Pulse Period > 100 > usec.**
5. Set the pulse width to 24 microseconds: Press **Pulse > Pulse Width > 24 > usec**
6. Turn on both the pulse modulation and the RF output.

The PULSE annunciator displays and the RF output LED lights.

If the modulation does not seem to be working properly, refer to [“No Modulation at the RF Output”](#) on page 310.

## Pulse Train (Option 320 – Requires: Option UNW)

The Option 320 Pulse Train feature enables the specification of up to 2047 independent pulse cycles, each of which has an "On Time", during which the RF output is measurable at the RF output connector, and an "Off Time", during which the RF output is attenuated. Each pulse cycle is similar in function to other X-Series signal generator Pulse modes—the Pulse Train feature has up to 2047 cycles, instead of only a maximum of two (with Doublets). There are also repeat counts available for each pulse. These repetitions count against the total count of 2047 cycles.

The instrument can import pulse trains from a .csv (comma separated values) file or some other common ASCII format. It can also export to ASCII/CSV files as well. Export allows specification of the decimal separator and a column separator. The import allows specification of the decimal separator (to allow for ",") but the column separator is auto-detected. Refer to "Pulse Train Menu Softkeys" on page 119 and "Display Pulse Train Menu Softkeys" on page 121.

Figure 6-4 Pulse Train Menu Softkeys

Pulse > Pulse Source > More > Pulse Train

For details on each key, use key help as described on page 34.

Display area indicates Pulse Train is the current pulse source.

Trigger Immediately causes the pulse train to run once.

Free-Run continuously plays the pulse train, ignoring all triggers.

Triggered runs the pulse train (after waiting the Pulse Delay) each time an external trigger is supplied to the PULSE BNC, the **Trigger Immediately** softkey is pressed, or the Trigger SCPI command is sent.

Gated runs the pulse train while an external trigger is supplied (level triggered) to the PULSE BNC connector. The state of the GATED trigger is detected only when the playback is transitioning to or in idle. This means that, once started, playback is always completed, even if the GATE trigger changes to the inactive state.


### SCPI Commands:

```
[[:SOURCE]]:PULM:INTernal:TRain:TRIGger FRUN|{TRIGgered}|GATED
[[:SOURCE]]:PULM:INTernal:TRain:TRIGger:IMMEDIATE
```

Refer to the *SCPI Command Reference*.

Figure 6-5 Edit Pulse Train Menu Softkeys

For details on each key, use key help as described on page 34.



**SCPI Commands:**

```
[[:SOURCE]]:PULM:INTernal:TRain:LIST:PRESet
[:SOURCE]:PULM:INTernal:TRain:OFFTime <20ns - 42sec>
[:SOURCE]:PULM:INTernal:TRain:OFFTime?
[:SOURCE]:PULM:INTernal:TRain:OFFTime:POINTs?
[:SOURCE]:PULM:INTernal:TRain:ONTime <20ns - 42sec>
[:SOURCE]:PULM:INTernal:TRain:ONTime?
[:SOURCE]:PULM:INTernal:TRain:ONTime:POINTs?
[:SOURCE]:PULM:INTernal:TRain:REPetition <1-2047>
[:SOURCE]:PULM:INTernal:TRain:REPetition?
[:SOURCE]:PULM:INTernal:TRain:REPetition:POINTs?
```


Refer to the *SCPI Command Reference*.

**SCPI Commands (continued):**

```
:MEMory:CATalog:PTRain?
:MEMory:DElete:PTRain
:MEMory:EXPort[:ASCIi]:PTRain <"filename">
:MEMory:EXPort[:ASCIi]:SEPARATOR:COLumn
TAB|SEMIColon|{COMMa}|SPACE
:MEMory:EXPort[:ASCIi]:SEPARATOR:COLumn?
:MEMory:EXPort[:ASCIi]:SEPARATOR:DECimal
{DOT}|COMMa
:MEMory:EXPort[:ASCIi]:SEPARATOR:DECimal?
:MEMory:IMPort[:ASCIi]:PTRain <"filename">
:MEMory:IMPort[:ASCIi]:SEPARATOR:DECimal
{DOT}|COMMa
:MEMory:IMPort[:ASCIi]:SEPARATOR:DECimal?
:MMEMory:LOAD:PTRain <"filename">
:MMEMory:STORE:PTRain <"filename">
```

Figure 6-6 Display Pulse Train Menu Softkeys

Pulse > Pulse Source > More > Pulse Train > Edit Pulse Train > Display Pulse Train




This softkey shifts the time offset from the left hand side of the display to the one specified. Increments and decrements are 1/20th of the visible pulse train.

Use these softkeys to optimize the view of the different characteristics of the pulse train.

This value can be adjusted with the Time Offset softkey.

These are the division markers currently set at 10.00 us/div for the currently displayed view. Use the zoom softkeys to change the time/div value.



This is the initial pulse cycle (row 1) note that the On Time portion of this pulse is not showing due to the 2 us offset.

4th pulse cycle (element) or row 4.

5th, 6th, and 7th pulse cycles (elements) or rows 5, 6, and 7.

Final pulse cycle (element) in the displayed pulse train above. 8th pulse cycle or row number 8.

For details on each key, use key help as described on [page 34](#).

**Figure 6-7 Pulse Train: Import From Selected File Softkeys**

Pulse > Pulse Source > More > Pulse Train > Edit Pulse Train > More

For details on each key, use key help as described on [page 34](#).

| Pulse Train | On Time  | Off Time | Repeat |
|-------------|----------|----------|--------|
| 1           | 2.000 us | 2.000 us | 1      |
| 2           | 3.000 us | 2.000 us | 2      |
| 4           | 2.000 us | 2.000 us | 1      |
| 5           | 3.000 us | 2.000 us | 3      |
| 6           | 3.000 us | 2.000 us | 1      |
| 9           | 2.000 us | 2.000 us | 1      |

Load/Store [page 53](#)

Import/Export

Insert Item

Delete Item

Delete All Rows

These softkeys delete individual On Time or Off Time elements as well as the Repeat cycle counts.

Deleting all Pulse Cycle rows (elements) must be confirmed.

| File Name      | Type   | Size   | Modified       |
|----------------|--------|--------|----------------|
| 1 DISPLAY.BMP  | BINARY | 76918  | 22/09/06 22:36 |
| 2 DRAM1PH.LIC  | BINARY | 524    | 22/09/06 22:36 |
| 3 LAUNCH32.EXE | BINARY | 925696 | 22/09/06 22:36 |
| 4 PTRAIN.CSV   | BINARY | 55     | 04/05/10 08:47 |
| 5 PTRAIN.TXT   | BINARY | 55     | 04/05/10 08:43 |
| 6 PTRAIN2.CSV  | BINARY | 15     | 04/05/10 09:08 |
| 7 WMPINFO.XML  | BINARY | 296    | 22/09/06 22:37 |

Import From Selected File

Export To File [page 123](#)

Delete File

Goto Row [page 123](#)

Import Decimal Separator  
 Dot  Comma

Selects whether the decimal point is a "." or a "," during import of CSV/ASCII files.

This value is persistent across preset/recall and power cycles.

```

0000007.0000007.2
0000004.0000003.3
0000002.0000002.2
    
```

This file's data structure uses decimals in the numbers and so requires the Import Decimal Separator to be set to Dot.

SCPI Commands:  
:MEMory:IMPort[:ASCIi]:SEParato  
r:DECimal DOT|COMMA  
:MEMory:IMPort[:ASCIi]:SEParato  
r:DECimal?

Note: Column separated values are auto-detected by the instrument.

| Pulse Train | On Time  | Off Time | Repeat |
|-------------|----------|----------|--------|
| 1           | 2.000 us | 1.000 us | 2      |
| 3           | 4.000 us | 2.000 us | 3      |
| 6           | 2.000 us | 3.000 us | 2      |
| 8           | -----    | -----    | -----  |

Pulse train imported as CSV

After confirming import of the file the new file's pulse train values are displayed.



Figure 6-8 Pulse Train: Export to File Softkeys

Pulse > Pulse Source > More > Pulse Train > Edit Pulse Train > More

Note: Files can be FTP'd to the BIN (Binary) folder in the instrument, or a USB stick can be used to download the files to the instrument. Refer to page 55.

**Import/Export**

Import From Selected File → page 122

Export To File →

Delete File ▶

Goto Row →

Import Decimal Separator  
Dot Comma

**Export to File**

Export Column Separator (Comma)

Export Decimal Separator Dot Comma

**Column Separator**

Comma

Semicolon

Tab

Space

Selects whether the decimal point is a "." or "," during export of the CSV/ASCII files. This value is persistent across preset/recall and power cycles.

SCPI Commands:  
:MEMory:EXPort[:ASCIi]:SEParator:DECi mal DOT|COMMa

Selects whether the column separator is a tab, ",", "." or "a "" during export of the CSV/ASCII files. This value is persistent across preset/recall and power cycles.

SCPI Commands:  
:MEMory:EXPort[:ASCIi]:SEParator:COLumn TAB|SEMicolon|COMMa|SPACE

The Export to File softkey menu, writes out a CSV/ASCII file to the BINARY directory. You may supply your own extender as part of the filename.

Example:  
MEM:EXP:PTR "myfile.csv".  
SCPI Command:  
:MEMory:EXPort[:ASCIi]:PTRain <"filename">

**Text Entry**

Export to: PTRAIN.TXT

Enter

Clear Text

Editing Mode  
Insert Replace

Show Alpha Table  
Off On

Use the text editor keys to rename the file to be exported to the BIN (Binary) folder.

Note: Since there is already a file named PTRAIN.CSV the new filename should be different, to avoid overwriting the original PTRAIN.CSV file.

For details on each key, use key help as described on page 34.

Using Pulse Modulation (Option UNW or 320)  
Pulse Train (Option 320 – Requires: Option UNW)

---

## 7 Basic Digital Operation—No BBG Option Installed

Before using this information, you should be familiar with the basic operation of the signal generator. If you are not comfortable with functions such as setting power level and frequency, refer to [Chapter 3, “Basic Operation,” on page 33](#) and familiarize yourself with the information in that chapter.

See also [“Adding Real-Time Noise to a Dual ARB Waveform” on page 229](#).


## I/Q Modulation

The following factors contribute to the error vector magnitude:

- Differences in amplitude, phase, and delay between the I and Q channels
- DC offsets

The I/Q menu provides adjustments and calibration to compensate for some of the differences in the I and Q signals or to add impairments. See [I/Q Modulation](#) on page 188 for additional information. See also “Modulating the Carrier Signal” on page 48.

**Figure 7-1 I/Q Display and Softkeys**



The following table shows common uses for the adjustments.

**Table 7-1 I/Q Adjustments Uses**

| I/Q Adjustment   | Effect              | Impairment     |
|------------------|---------------------|----------------|
| Offset           | Carrier Feedthrough | dc offset      |
| Quadrature Angle | EVM error           | phase skew     |
|                  | I/Q Images          | I/Q path delay |

## Configuring the Front Panel Inputs

The MXG/EXG accepts externally supplied analog I and Q signals through the front panel I Input and Q Input for modulating onto the carrier.

1. Connect I and Q signals to the front panel connectors. For voltage levels, refer to [“Front Panel Overview” on page 5](#).
  - a. Connect an analog I signal to the signal generator’s front panel I Input.
  - b. Connect an analog Q signal to the signal generator’s front panel Q Input.
2. Turn on the I/Q modulator: Press **I/Q Off On** to On.
3. Configure the RF output:
  - a. Set the carrier frequency.
  - b. Set the carrier amplitude.
  - c. Turn the RF output on.
4. Make adjustments to the I/Q signals ([page 126](#)) as needed.



---

## 8 Basic Digital Operation (Option 653/655/656/657)

Before using this information, you should be familiar with the basic operation of the signal generator. If you are not comfortable with functions such as setting power level and frequency, refer to [Chapter 3, “Basic Operation,” on page 33](#) and familiarize yourself with the information in that chapter.

The features described in this chapter are available only in vector signal generators with Option 653 or 655 (N5172B) or Option 656 or 657 (N5182B).

- [Waveform File Basics](#) on page 130
- [Storing, Loading, and Playing a Waveform Segment](#) on page 132
- [Waveform Sequences](#) on page 135
- [Saving a Waveform’s Settings & Parameters](#) on page 139
- [Using Waveform Markers](#) on page 145
- [Triggering a Waveform](#) on page 162
- [Clipping a Waveform](#) on page 169
- [Scaling a Waveform](#) on page 178
- [Setting the Baseband Frequency Offset](#) on page 184
- [I/Q Modulation](#) on page 188
- [I/Q Adjustments](#) on page 192
- [I/Q Calibration](#) on page 194
- [Using the Equalization Filter](#) on page 196
- [Using Finite Impulse Response \(FIR\) Filters in the Dual ARB Real-Time Modulation Filter](#) on page 198
- [Modifying a FIR Filter Using the FIR Table Editor](#) on page 204
- [Setting the Real-Time Modulation Filter](#) on page 208
- [Multiple Baseband Generator Synchronization](#) on page 209
- [Understanding Option 012 \(LO In/Out for Phase Coherency\) with Multiple Baseband Generator Synchronization](#) on page 216
- [Waveform Licensing](#) on page 221

See Also:

- [Adding Real-Time Noise to a Dual ARB Waveform](#) on page 229
- [Real-Time Phase Noise Impairment](#) on page 238
- [Multitone and Two-Tone Waveforms \(Option 430\)](#) on page 297

## Waveform File Basics

There are two types of waveform files:

- A *segment* is a waveform file that you download to the signal generator.  
For information on creating and downloading waveform files, refer to the *Programming Guide*.
- A *sequence* is a file you create in the signal generator that contains pointers to one or more waveform files (segments, other sequences, or both).  
For information on creating sequences, see [page 135](#).

## Signal Generator Memory

The signal generator has two types of memory:

- *Volatile* memory, baseband generator (BBG) media, where waveform files are played from or edited.
- *Non-volatile* memory, either internal (int) or external (USB) media, where waveform files are stored.

## Dual ARB Player

---

**NOTE** The MXG/EXG's ARB Waveform File Cache is limited to 128 files. Consequently, once the 128 file cache limit has been reached, the waveform switching speed will be much slower for additional files loaded into the volatile waveform memory (BBG).


---

The dual ARB waveform player enables you to play, rename, delete, store, and load (external or internal) waveform files in addition to building waveform sequences. The dual ARB waveform player also provides markers ([page 145](#)), triggering ([page 162](#)), clipping ([page 169](#)), and scaling ([page 178](#)) capabilities.

Most procedures in this section start from the Dual ARB menu, shown below.



Figure 8-1 Dual ARB Softkeys



For details on each key, use key help as described on page 34.

## Storing, Loading, and Playing a Waveform Segment


**NOTE** The MXG/EXG’s ARB Waveform File Cache is limited to 128 files. Consequently, once the 128 file cache limit has been reached, the waveform switching speed will be much slower for additional files loaded into the volatile waveform memory (BBG).

Before using this information, you should be familiar with the signal generator’s file menus. If you are not, refer to “Working with Files” on page 50 and familiarize yourself with that information.

See also: “Waveform Sequences” on page 135.

The signal generator has two types of waveform media: non-volatile (internal or USB), and volatile (BBG). BBG media is also called “working” media, because before you can play, edit, or include a waveform file in a sequence, the waveform file must be loaded into BBG media.

**Figure 8-2 Waveform Segment Softkeys**



For details on each key, use key help as described on page 34.

### Loading a Waveform Segment into BBG Media

Waveforms must reside in BBG media before they can be played, edited, or included in a sequence. Cycling power or rebooting the signal generator deletes the files in BBG media.

**NOTE** Each time the instrument powers up, two factory-supplied segments are automatically created in BBG media: RAMP\_TEST\_WFM and SINE\_TEST\_WFM.

There are additional sample waveforms that are available in the internal storage and that can be loaded into memory. Refer to [www.agilent.com](http://www.agilent.com) and search on “Factory Default N5182B” and “waveforms”.

1. Press **Mode** > **Dual ARB** > **Select Waveform** > **Waveform Segments**.

2. Press **Load Store** to highlight Load, then use the arrow keys to highlight the desired waveform segment.
3. If there is already a copy of this segment in the currently selected media and you do not want to overwrite it, rename the waveform segment before you load it (refer to the previous procedure).
4. Press **Load Segment From** *currently selected Media*.  
To load *all* files from the currently selected media into BBG media, press **Load All From** *currently selected Media*.

## Storing/Renaming a Waveform Segment to Internal or USB Media

Use the following steps to store a copy of a file in BBG memory to the currently selected media (page 61). If you have not downloaded a waveform segment, either refer to the *Programming Guide*, or use one of the factory-supplied segments.

1. Press **Mode > Dual ARB > Select Waveform > Waveform Segments**.
2. Press **Load Store** to highlight Store.
3. Using the arrow keys, highlight the waveform segment you want to store.
4. Optionally, rename the segment.


If there is already a copy of this segment in the currently selected media and you do not want to overwrite it, rename the waveform segment before you store it:

- a. Press **More > Rename Segment > Clear Text**.
  - b. Enter a name for the waveform segment.
  - c. Press **Enter > More**.
  - d. Highlight the waveform segment that was renamed.
5. Press **Store Segment to** *currently selected Media*.
  6. Repeat [Step 3](#) through [Step 5](#) for all segments that you want to store.  
To save *all* segments from BBG media to the currently selected media, press **Store All to** *currently selected Media*.

## Playing a Waveform Segment

1. Press **Mode > Dual ARB > Select Waveform**.
2. In the Segment on BBG Media column, highlight the waveform segment you want to play.
3. Press **Select Waveform**.
4. Set **ARB Off On** to On.

This plays the selected waveform segment. Both the I/Q and ARB annunciators turn on, and the waveform modulates the RF carrier.




5. Configure the RF Output:

Set the RF carrier frequency and amplitude, and turn on the RF output.

The waveform segment is now available at the signal generator's RF Output connector.

# Waveform Sequences

Figure 8-3 Waveform Sequence Softkeys




For details on each key, use key help as described on page 34.

A waveform sequence is a file that contains pointers to one or more waveform segments or other waveform sequences, or both. This lets the signal generator play multiple waveform segments, or other sequences, or both thereby eliminating the need to stop waveform playback just to select another waveform.

The segments that a waveform sequence points to are *not* automatically stored when you store the sequence; you must also store the individual segments or they are lost when you turn off or reboot the signal generator. If the segments are located in internal/external media, you must load them into BBG media prior to selecting a waveform sequence (see page 132). If you attempt to play a sequence without the segments loaded into BBG media, the signal generator reports: ERROR: 629, File format invalid. If this happens and the segments are not stored in internal/external media, you must recreate the segments using the same file names that the sequence points to before you can play the sequence.

## Creating a Sequence

A waveform sequence can contain up to 1,024 segments and have both segments and other sequences (nested sequences). The signal generator lets you set the number of times the segments and nested sequences repeat during play back. But there is a difference between repeating a segment versus repeating a nested sequence. Each segment can repeat up to 65,535 times, but no matter how many times a segment repeats, it counts as a single segment. However each repetition of a nested sequence counts as additional segments.



The maximum number of times that a nested sequence can repeat is based on the number of segments in the nested sequence and the remaining number of allowed segments (1,024). For example, with a sequence that contains 24 segments and one nested sequence with 4 segments, the nested sequence is limited to 250 repetitions:

$$24 + (4 \times 250) = 1,024 \text{ maximum number of segments per sequence}$$

Even though there is a limiting factor on the maximum number of times that a nested sequence can repeat, each segment within the nested sequence can repeat up to 65,535 times.

### Example

Use the following procedure to create and store a waveform sequence using one repetition each of two different segments.

*Assumption:* The waveform segments are in BBG media (volatile memory). For information on loading waveform segments into BBG media, see [page 132](#).

1. Select the first segment:
  - a. Press **Mode** > **Dual ARB** > **More** > **Waveform Sequences** > **Build New Waveform Sequence** > **Insert Waveform**.
  - b. Highlight the desired waveform segment and press **Insert**.
2. Select the second segment:
  - a. Highlight the next desired waveform segment and press **Insert**.
  - b. Press **Done Inserting**

3. Name and store the waveform sequence to the Seq file catalog:
  - a. Press **More > Name and Store**.
  - b. Enter a file name and press **Enter**.

See also, “[Viewing the Contents of a Sequence](#)” on page 137 and “[Setting Marker Points in a Waveform Segment](#)” on page 152.

## Viewing the Contents of a Sequence

There are two ways to view the contents of a waveform sequence:

### Through the Waveform Sequences Softkey

1. Press **Mode > Dual ARB > More > Waveform Sequences**.
2. Highlight the desired sequence.
3. Press **Show Waveform Sequence Contents**.

### Using the Select Waveform Softkey

1. Press **Mode > Dual ARB > Select Waveform**.
2. In the Sequence On column, highlight the desired waveform sequence.
3. Press **Show Waveform Sequence Contents**.

## Editing a Sequence

When editing a waveform sequence, you can:

- change the number of times each segment or nested sequence plays
- delete segments or nested sequences from the sequence
- add segments or nested sequences to the sequence
- toggle markers on and off (described on [page 158](#))
- save changes either to the current waveform sequence or as a new sequence

If you exit the sequence editing menu before saving changes, the changes are lost.

Sequences save to the Seq file catalog.

---

**CAUTION** If you edit and resave a segment used in a sequence, the sequence does not automatically update the RMS value in its header. You must select and update the sequence header information ([page 139](#)).

---

Use the following steps to edit a sequence that has two different segments so that the first segment repeats 100 times and the second segment repeats 200 times, then save the changes.

*Assumption:* A waveform sequence that has two different segments has been created and stored (see previous example on [page 136](#)).

1. Select the sequence:  
Press **Mode > Dual ARB > More > Waveform Sequences > *highlight the desired sequence* > Edit Selected Waveform Sequence**.

2. Change the first segment so that it repeats 100 times:  
Highlight the first segment entry and press **Edit Repetitions > 100 > Enter**.

The cursor moves to the next entry.

3. Change the repetition for the selected entry to 200:  
Press **Edit Repetitions > 200 > Enter**.

4. Save the changes made in the previous steps:  
Press **More > Name and Store > Enter**.

To save the changes as a *new* sequence:

- a. Press **More > Name and Store > Clear Text**.
- b. Enter a file name (for example, SINE100+RAMP200).
- c. Press **Enter**.

The edited sequence saves as a new waveform sequence.

## Playing a Sequence

If you have not created a waveform sequence, refer to “Creating a Sequence” on page 136.


---

**NOTE** To play a waveform segment individually or as part of a waveform sequence, the segment must reside in BBG media. See also, “Loading a Waveform Segment into BBG Media” on page 132.

---

1. Select a waveform sequence:
  - a. Press **Mode > Dual ARB > Select Waveform**.
  - b. Highlight a waveform sequence (for this example, SINE100+RAMP200) from the Sequence On column.
  - c. Press **Select Waveform**.

The display shows the currently selected waveform (for example, Selected Waveform: SEQ:SINE100+RAMP200).





2. Generate the waveform:  
Press **ARB Off On** to On.

This plays the selected waveform sequence. During the waveform sequence generation, both the I/Q and ARB annunciators turn on, and the waveform modulates the RF carrier.


3. Configure the RF output:
  - a. Set the RF carrier frequency.
  - b. Set the RF output amplitude.
  - c. Turn on the RF output.

The waveform sequence is now available at the signal generator's RF OUTPUT connector.

## Saving a Waveform's Settings & Parameters


This section describes how to edit and save a file header. When you download only a waveform file (I/Q data, which the signal generator treats as a waveform segment), the signal generator automatically generates a file header and a marker file with the same name as the waveform file. Initially the file header has no signal generator settings saved to it, and the marker file consists of all zeros. For a given waveform, you can save signal generator settings and parameters in its file header and marker settings in its marker file (page 145); when you load a stored waveform file into BBG media, the file header and marker file settings automatically apply to the signal generator so that the dual ARB player sets up the same way each time the waveform file plays.

**Figure 8-4 Header Utilities Softkeys**



When you create a waveform sequence (as described on page 136), the signal generator automatically creates a waveform sequence header that takes priority over the individual waveform segment headers. During a waveform sequence playback, the segment headers are ignored, except to verify that all required options are installed. Storing a waveform sequence also stores its file header.

Some of the current signal generator settings shown in the file header appear as part of the softkey labels, and others appear in the dual ARB summary display, shown in the following example.



**Table 8-1 File Header Entries**

| 32-Character Description     | A description entered for the header, such as a the waveform's function (saved/edited with the <b>Edit Description</b> softkey, see <a href="#">Figure 8-4</a> ).  |
|------------------------------|--|
| <b>Sample Rate</b>           | The waveform playback rate. This is the ARB sample clock rate, set in the Arb Setup menu (shown in <a href="#">Figure 8-1 on page 131</a> ).   |
| <b>Runtime Scaling</b>       | The Runtime scaling value is applied in real-time while the waveform is playing. This setting can be changed only for files playing in the dual ARB player (see <a href="#">page 181</a> ).  |
| <b>RMS</b>                   | When the modulator attenuation setting (see <a href="#">page 131</a> ) is set to Auto, this value is used to calculate the I/Q modulator attenuation setting to optimize ACPR. Value: 0 to 1.414213562.  |
| <b>Marker 1...4 Polarity</b> | Marker polarity can be positive or negative (described on <a href="#">page 158</a> ).  |
| <b>ALC Hold Routing</b>      | Which marker, if any, implements the ALC hold function (described on <a href="#">page 147</a> ), which holds the ALC at its current level when the marker signal is low. All waveforms generated in the signal generator have a marker on the first sample point. To see the results from the three routing selections, you may need to select a range of sample (marker) points (see " <a href="#">Setting Marker Points in a Waveform Segment</a> " on <a href="#">page 152</a> ). |

**Table 8-1 File Header Entries (Continued)**

|                           |   |
|---------------------------|---|
| <b>RF Blank Routing</b>   | Which marker, if any, implements the RF blanking function (described on <a href="#">page 156</a> ) when the marker signal is low. RF blanking also uses ALC hold. There is no need to select the ALC Hold Routing for the same marker when you are using the RF Blank Routing function. When the marker signal goes high, RF blanking discontinues. |
| <b>Mod Attenuation</b>    | The I/Q modulator attenuation setting (set in the Arb Setup menu shown in <a href="#">Figure 8-1</a> on <a href="#">page 131</a> ).   |
| <b>BB Freq Offset</b>     | The baseband frequency offset, in Hz (see <a href="#">page 184</a> ).   |
| <b>AWGN: State</b>        | Indicated whether real-time noise is on (1) or off (0) (see <a href="#">page 229</a> ).   |
| <b>AWGN: C/N Ratio</b>    | Carrier to noise ration, in dB (see <a href="#">page 234</a> ).   |
| <b>AWGN: Carrier BW</b>   | Bandwidth over which the noise power is integrated, in Hz (see <a href="#">page 234</a> ).  |
| <b>AWGN: Noise BW</b>     | Bandwidth of the noise, in Hz (see <a href="#">page 234</a> ).  |
| <b>AWGN: Carrier RMS</b>  | The carrier RMS across the carrier bandwidth (see <a href="#">page 234</a> ).   |
| <b>Phase Noise State</b>  | Indicated whether phase noise is on (1) or off (0) (see <a href="#">page 238</a> ).   |
| <b>Phase Noise F1</b>     | The start frequency for the level mid-frequency characteristics (see <a href="#">page 238</a> ).  |
| <b>Phase Noise F2</b>     | The end frequency for the level mid-frequency characteristics (see <a href="#">page 238</a> ).  |
| <b>Phase Noise Lmid</b>   | The amplitude for the level mid-frequency characteristics (see <a href="#">page 238</a> ).  |
| <b>Modulation Filter</b>  | The real-time modulation filter type selected (see <a href="#">page 208</a> ).  |
| <b>Over-Range Protect</b> | Indicated whether DAC Over-Range Protection is on (1) or off (0) (see <a href="#">page 242</a> ).   |
| <b>Unique Waveform Id</b> | 0 = no Id; once an Id is assigned, it cannot be changed.  |
| <b>License Required</b>   | Indicates whether a license is required to play the waveform. See also: " <a href="#">Viewing Options and Licenses</a> " on <a href="#">page 30</a>   |
| <b>Can be Read Out</b>    | Indicates whether the waveform can be queried through SCPI or FTP.  |

## Viewing and Modifying Header Information

The following example uses the factory-supplied waveform file RAMP\_TEST\_WFM.

1. From BBG media, select the waveform RAMP\_TEST\_WFM:
  - a. Press **Mode > Dual ARB > Select Waveform**.
  - b. In the Segment On column, highlight the waveform RAMP\_TEST\_WFM.
  - c. Press **Select Waveform**.
2. Open the Header Utilities menu:  
Press **More > Header Utilities**

The [Figure 8-5](#) shows the default file header for the factory-supplied waveform RAMP\_TEST\_WFM. The Header Field column lists the file header parameters; use the **Page Down** key to see them all.

The Saved Header Settings column shows that most of the settings are Unspecified. Unspecified means that there is no setting saved for that particular parameter.

The Current Inst. Settings column shows the current signal generator settings. In this example, these are the settings that you will save to the file header.

**NOTE** If a setting is unspecified in the file header, the signal generator uses its current value for that setting when you select and play the waveform.

**Figure 8-5 Example File Header**

Mode > Dual ARB > More > Header Utilities

The screenshot shows the 'Header Utilities' menu with the following options: Edit Description, Edit RMS, Edit AWGN RMS Override, Clear Header, and Save Setup To Header. The 'File Header Information' table is as follows:

| Header Field      | Saved Header Settings | Current Inst. Settings |
|-------------------|-----------------------|------------------------|
| Description       | Ramp (I down, Q up)   |                        |
| Sample Rate       | Unspecified           | 200.00000000MHz        |
| Runtime Scaling   | 78.78 %               | 78.78 %                |
| RMS               | 0.814852207           | N/A                    |
| Marker 1 Polarity | Unspecified           | Pos                    |
| Marker 2 Polarity | Unspecified           | Pos                    |
| Marker 3 Polarity | Unspecified           | Pos                    |
| Marker 4 Polarity | Unspecified           | Pos                    |
| ALC Hold Routing  | Unspecified           | None                   |

Annotations in the image include: 'The name of the waveform file.' pointing to the file name 'U001:RAMP\_TEST\_U001'; 'The description can be up to 32-characters.' pointing to the Description field; 'Opens a menu for manually defining the carrier RMS value to use for calculating the AWGN: Carrier RMS value in the Header Field.' pointing to the Edit RMS option; 'Resets the saved header settings entries to default settings' pointing to the Clear Header option; 'Default header settings' pointing to the Saved Header Settings column; and 'Current signal generator settings' pointing to the Current Inst. Settings column.

To calculate the RMS waveform voltage:  
 Press **Calculate**  
 Then refer to Header Field information.  
 Note: For greater accuracy, if the waveform has long rise/fall times, a DC offset, or noise\* already added to the waveform (for a bursted signal), it is recommended that the Edit RMS and Edit AWGN RMS Override softkeys are used for the best measurement accuracy.  
 \*Option 403 Real-time AWGN does not affect the Header Field RMS value. But, noise added to the waveform prior to downloading and playing in the signal generator does affect the Header Field RMS value.

3. Save the information in the Current Inst. Settings column to the file header:

Press **Save Setup To Header**.

Both the Saved Header Settings column and the Current Inst. Settings column now display the same values; the Saved Header Settings column lists the settings saved in the file header.

4. Edit and Update Settings

a. Return to the ARB Setup menu:  
 Press **Return > More > ARB Setup**.

From this menu you can access some of the signal generator settings that are saved to the file header. Figure 8-1 on page 131 shows the ARB Setup softkeys used in the following steps.

- b. Set the ARB sample clock to 5 MHz:  
 Press **ARB Sample Clock > 5 > MHz**.
- c. Set waveform runtime scaling to 60%:  
 Press **Waveform Runtime Scaling > 60 > %**.

- d. Return to the Header Utilities menu:  
 Press **Return** > **More** > **Header Utilities**.

As shown in the following figure, the Current Inst. Settings column now reflects the changes to the current signal generator setup, but the *saved* header values have not changed.

| Header Field      | Saved Header Settings | Current Inst. Settings |
|-------------------|-----------------------|------------------------|
| Description       | Ramp (I down, Q up)   |                        |
| Sample Rate       | 200.000000000MHz      | 5.000000000MHz         |
| Runtime Scaling   | 78.78 %               | 60.00 %                |
| RMS               | 0.814852207           | N/A                    |
| Marker 1 Polarity | Pos                   | Pos                    |
| Marker 2 Polarity | Pos                   | Pos                    |
| Marker 3 Polarity | Pos                   | Pos                    |
| Marker 4 Polarity | Pos                   | Pos                    |
| ALC Hold Routing  | None                  | None                   |

- e. Save the current settings to the file header:  
 Press the **Save Setup To Header** softkey.

The settings from the Current Inst. Settings column now appear in the Saved Header Settings column. This saves the new current instrument settings to the file header.

If you change any of the signal generator settings listed in the file header after you select the waveform file, the changed setting(s) appear in the file header's Current Inst. Settings column and are used instead of the saved header settings. To reapply the saved header settings, reselect the waveform for playback.

### Viewing & Editing a Header without Selecting the Waveform

As described on page 141, you can view and edit a waveform's header information after you select the waveform; you can also edit waveform header information without selecting a waveform, or for another waveform than the one that is currently selected.

1. Access the file header utilities menu:  
 Press **Mode** > **Dual ARB** > **More** > **Header Utilities** > **More** > **Select Different Header**.

The signal generator displays an alphabetical list of the waveform files in the media that was last selected. The following figure shows an example of the factory-supplied waveforms in BBG media.

The screenshot shows the main display of the signal generator. At the top, the frequency is set to 6.000 000 000 00 GHz and the amplitude is 0.00 dBm. Below this is a table titled 'Catalog of BBG Segment Files in BBG Memory'. The table has columns for File Name, Type, Size, and Modified. Two files are listed: 'RAMP\_TEST\_WFM' and 'SINE\_TEST\_WFM', both of type 'WFM1' and size '800 B'. To the right of the table is a 'Header File' menu with options: 'Select Header', 'Catalog Type (BBG Segments)', 'Stored Segments', 'Sequence', and 'BBG Segments'. A callout points to the 'Catalog Type (BBG Segments)' option, which is expanded to show the three options: 'Stored Segments', 'Sequence', and 'BBG Segments'. Another callout points to the 'BBG Segments' option, which is labeled 'Files in BBG media'. A third callout points to the 'Header File' menu, which is labeled 'Active waveform catalog'. A fourth callout points to the top of the screen, which is labeled 'Active media'.

**Type:**  
 WFM1 = Volatile Segment  
 NVWFM = Non-Volatile Segment  
 SEQ = Sequence

For details on each key, use key help as described on [page 34](#).

2. If the desired catalog is not displayed, select it.
3. Highlight the desired waveform file and press **Select Header**.  
 The signal generator displays the file header for the selected waveform file.
4. To edit the header, press **More**, and proceed as described in [Step 4 on page 142](#) ([Viewing and Modifying Header Information](#) section).

## Using Waveform Markers

The signal generator provides four waveform markers to mark specific points on a waveform *segment*. When the signal generator encounters an enabled marker, an auxiliary signal is routed to a rear panel event output that corresponds to the marker number.

- Event 1 is available at both the EVENT 1 BNC connector (see [page 16](#)), and a pin on the AUXILIARY I/O connector (see [page 17](#)).
- Event 2 is available at the TRIG 1 & TRIG 2 connectors (see [page 13](#)), and a pin on the AUXILIARY I/O connector (see [page 17](#)).
- Events 3 and 4 are available at pins on the AUXILIARY I/O connector (see [page 17](#)).

You can use an auxiliary output signal to synchronize another instrument with the waveform, or as a trigger signal to start a measurement at a given point on a waveform.

You can also configure markers to initiate ALC hold or RF Blanking (which includes ALC hold). Refer to “Using Waveform Markers” on [page 145](#) for details.

When you download a waveform file that does not have a marker file associated with it, the signal generator creates a marker file without any marker points. Factory-supplied segments (RAMP\_TEST\_WFM and SINE\_TEST\_WFM) have a marker point on the first sample for all four markers.

The following procedures demonstrate how to use markers while working in the dual ARB player. These procedures also discuss two types of points: a *marker point* and a *sample point*. A marker point is a point at which a given marker is set on a waveform; you can set one or more marker points for each marker. A *sample point* is one of the many points that compose a waveform.

There are three basic steps to using waveform markers:

[Clearing Marker Points from a Waveform Segment](#) on [page 151](#)

[Setting Marker Points in a Waveform Segment](#) on [page 152](#)


[Controlling Markers in a Waveform Sequence](#) on [page 158](#)

This section also provides the following information:

- [Waveform Marker Concepts](#) on [page 146](#)
- [Accessing Marker Utilities](#) on [page 150](#)
- [Viewing Waveform Segment Markers](#) on [page 151](#)
- [Viewing a Marker Pulse](#) on [page 155](#)
- [Using the RF Blanking Marker Function](#) on [page 156](#)
- [Setting Marker Polarity](#) on [page 158](#)

## Waveform Marker Concepts

The signal generator's Dual ARB provides four waveform markers for use on a waveform segment. You can set each marker's polarity and marker points (on a single sample point or over a range of sample points). Each marker can also perform ALC hold, or RF Blanking and ALC hold.



When the signal generator encounters an enabled marker (described on [page 158](#)), an auxiliary output signal is generated and routed to the rear panel.

Event 1 is available at the EVENT 1 BNC connector (see [page 16](#)), and at a pin on the AUXILIARY I/O connector (see [page 17](#)).

Events 2 through 4 are available at pins on the AUXILIARY I/O connector (see [page 17](#)).

## Marker Signal Response

The signal generator aligns the marker signals with the I and Q signals at the baseband generator. However some settings such as amplitude, filters, and so forth within the RF output path can create delays between the marker EVENT output signal and the modulated RF output. When using the marker EVENT output signal, observe the signals (marker relative to modulated RF) for any latency, and if needed, reset the marker point positions, include delay ([page 192](#)), or both.

## Marker File Generation

Downloading a waveform file (as described in the *Programming Guide*) that does not have a marker file associated with it causes the signal generator to automatically create a marker file, but does *not* place any marker points.

## Marker Point Edit Requirements

Before you can modify a waveform segment's marker points, the segment must reside in BBG media (see "Loading a Waveform Segment into BBG Media" on [page 132](#)).

## Saving Marker Polarity and Routing Settings

Marker polarity and routing settings remain until you reconfigure them, preset the signal generator, or cycle power. To ensure that a waveform uses the correct settings when it is played, set the marker polarities or routing (RF Blanking and ALC Hold) and save the information to the file header ([page 139](#)).

---

**NOTE** When you use a waveform that does not have marker routings and polarity settings stored in the file header, and the previously played waveform used RF Blanking, ensure that you set RF Blanking to **None**. Failure to do so can result in no RF output or a distorted waveform.

---



### ALC Hold Marker Function

While you can set a marker function (described as **Marker Routing** on the softkey label) either before or after you set marker points ([page 152](#)), setting a marker function before setting marker points may cause power spikes or loss of power at the RF output.

Use the ALC hold function by itself when you have a waveform signal that incorporates idle periods, burst ramps, or when the increased dynamic range encountered with RF blanking ([page 156](#)) is not desired.


The ALC hold marker function holds the ALC circuitry at the *average* value of the sampled points set by the marker(s). For both positive and negative marker polarity, the ALC samples the RF output signal (the carrier plus any modulating signal) when the marker signal goes high:

- Positive: The signal is sampled during the on marker points.
- Negative: The signal is sampled during the off marker points.

---

**NOTE** Because it can affect the waveform's output amplitude, do not use the ALC hold for longer than 100 ms. For longer time intervals, refer to "[Power Search Mode](#)" on [page 103](#).

---




---



**CAUTION** Incorrect ALC sampling can create a sudden unlevelled condition that may create a spike in the RF output, potentially damaging a DUT or connected instrument. To prevent this condition, ensure that you set markers to let the ALC sample over an amplitude that accounts for the higher power levels encountered within the signal.

---

### Example of Correct Use


Waveform: 1022 points  
Marker range: 95–97  
Marker polarity: Positive

This example shows a marker set to sample the waveform's area of highest amplitude. Note that the marker is set well before the waveform's area of lowest amplitude. This takes into account any response difference between the marker and the waveform signal.



The ALC samples the waveform when the marker signal goes high, and uses the average of the sampled waveform to set the ALC circuitry.


Here the ALC samples during the *on* marker points (positive polarity).



### Example of Incorrect Use

Waveform: 1022 points  
Marker range: 110–1022  
Marker polarity: Positive

This example shows a marker set to sample the low part of the same waveform, which sets the ALC modulator circuitry for that level; this usually results in an unlevelled condition for the signal generator when it encounters the high amplitude of the pulse.




### Example of Incorrect Use

Waveform: 1022 points

Marker range: 110–1022


Marker polarity: Negative

This figure shows that a negative polarity marker goes low during the marker *on* points; the marker signal goes high during the *off* points. The ALC samples the waveform during the *off* marker points.



Sample range begins on first point of signal

Sampling both on and off time sets the modulator circuitry incorrectly for higher signal levels. Note the increased amplitude at the beginning of the pulse.




Negative range set between signal and off time


## Accessing Marker Utilities

Mode > Dual ARB > More > Marker Utilities

For details on each key, use key help as described on [page 34](#).



The display below shows the I and Q components of the waveform, and



## Viewing Waveform Segment Markers

Markers are applied to waveform segments. Use the following steps to view the markers set for a segment (this example uses the factory-supplied segment, SINE\_TEST\_WFM).

1. In the second Arb menu ([page 150](#)), press **Marker Utilities > Set Markers**.
2. Highlight the desired waveform segment (in this example, SINE\_TEST\_WFM).
3. Press **Display Waveform and Markers > Zoom in Max**.  
The maximum zoom in range is 28 points.

Experiment with the Zoom functions to see how they display the markers.

The display can show a maximum of 460 points; displayed waveforms with a sample point range greater than 460 points may not show the marker locations.

## Clearing Marker Points from a Waveform Segment

When you set marker points they do not replace points that already exist, but are set *in addition* to existing points. Because markers are cumulative, before you set points, view the segment ([page 151](#)) and remove any unwanted points. With all markers cleared, the level of the event output signal is 0V. To clear marker points on a segment, the segment must reside in BBG media ([page 132](#)).

### Clearing All Marker Points

1. In the second Arb menu ([page 150](#)), press **Marker Utilities > Set Markers**.
2. Highlight the desired waveform segment (in this example, SINE\_TEST\_WFM).
3. Highlight the desired marker number: Press **Marker 1 2 3 4**.
4. For the selected marker number, remove all marker points in the selected segment:
  - a. Press **Set Marker Off Range of Points**.

Notice that the softkeys for the first and last marker points correspond with the length of the waveform. The factory-supplied waveform (SINE\_TEST\_WFM) contains 200 samples. To clear all set marker points, the range must equal to the length of the waveform.

- b. Press **Apply To Waveform > Return**.
5. Repeat from [Step 3](#) for any remaining marker points that you want to remove from the other markers.

### Clearing a Range of Marker Points


The following example uses a waveform with marker points (Marker 1) set across points 10–20. This makes it easy to see the affected marker points. The same process applies whether the existing points are set over a range or as a single point ([page 152](#)).

1. In the second Arb menu ([page 150](#)), press **Marker Utilities > Set Markers**, then select Marker 1.
2. Set the first sample point that you want off (for this example, 13):  
Press **Set Marker Off Range Of Points > First Mkr Point > 13 > Enter**.
3. Set the last marker point in the range that you want off to a value less than or equal to the number of points in the waveform, *and* greater than or equal to the value set in [Step 2](#) (for this example, 17):

Press **Last Mkr Point > 17 > Enter > Apply To Waveform > Return.**

This turns off all marker points for the active marker within the range set in [Steps 2 and 3](#), as shown at right.

How to view markers is described on [page 151](#).



### Clearing a Single Marker Point

Use the steps described in [“Clearing a Range of Marker Points”](#) on [page 151](#), but set both the first and last marker point to the value of the point you want to clear. For example, if you want to clear a marker on point 5, set both the first and last value to 5.

### Setting Marker Points in a Waveform Segment

To set marker points on a segment, the segment must reside in BBG media ([page 132](#)).

When you set marker points, they do not replace points that already exist, but are set *in addition* to existing points. Because markers are cumulative, before you set marker points within a segment, view the segment ([page 151](#)) and remove any unwanted points ([page 151](#)).

### Placing a Marker Across a Range of Points

1. In the second Arb menu ([page 150](#)), press **Marker Utilities > Set Markers.**

2. Highlight the desired waveform segment.

3. Select the desired marker number: Press **Marker 1 2 3 4**

4. Set the first sample point in the range (in this example, 10):


Press **Set Marker On Range Of Points > First Mkr Point > 10 > Enter.**

5. Set the last marker point in the range to a value less than or equal to the number of points in the waveform, *and* greater than or equal to the first marker point (in this example, 20):

Press **Last Mkr Point > 20 > Enter.**

6. Press **Apply To Waveform > Return.**

This sets a range of waveform marker points. The marker signal starts on sample point 10, and ends on sample point 20, as shown in the following figure.



How to view markers is described on [page 151](#)

### Placing a Marker on a Single Point

#### *On the First Point*

1. In the second Arb menu ([page 150](#)), press **Marker Utilities > Set Markers**.
2. Highlight the desired waveform segment.
3. Select the desired marker number:  
Press **Marker 1 2 3 4**.
4. Press **Set Marker On First Point**.

This sets a marker on the first point in the segment for the marker number selected in [Step 3](#).

#### *On Any Point*

Use the steps described in [“Placing a Marker Across a Range of Points” on page 152](#), but set both the first and last marker point to the value of the point you want to set. For example, if you want to set a marker on point 5, set both the first and last value to 5.

### Placing Repetitively Spaced Markers

The following example sets markers across a range of points and specifies the spacing (skipped points) between each marker. You must set the spacing *before* you apply the marker settings; you cannot apply skipped points to a previously set range of points.

---

**NOTE** The skipped points value is limited to the size of the range of points.


---

1. Remove any existing marker points ([page 146](#)).
2. In the second Arb menu ([page 150](#)), press **Marker Utilities > Set Markers**.
3. Highlight the desired waveform segment.
4. Select the desired marker number:  
Press **Marker 1 2 3 4**.
5. Set the first sample point in the range (in this example, 5):  
Press **Set Marker On Range Of Points > First Mkr Point > 5 > Enter**.
6. Set the last marker point in the range. (The last marker point value must always be less than or equal to the number of points in the waveform, *and* greater than or equal to the first marker point, in this example, 25):  
Press **Last Mkr Point > 25 > Enter**.
7. Enter the number of sample points that you want skipped (in this example, 1):  
Press **# Skipped Points > 1 > Enter**.
8. Press **Apply To Waveform > Return**.

This causes the marker to occur on every other point (one sample point is skipped) within the marker point range, as shown at right.

How to view markers is described on [page 151](#).

One application of the skipped point feature is the creation of a clock signal as the EVENT output.






## Viewing a Marker Pulse

When a waveform plays (page 138), you can detect a set and enabled marker's pulse at the rear panel event connector/Aux I/O pin that corresponds to that marker number. This example demonstrates how to view a marker pulse generated by a waveform segment that has at least one marker point set (page 152). The process is the same for a waveform sequence.


This example uses the factory-supplied segment, SINE\_TEST\_WFM in the dual ARB Player. Factory-supplied segments have a marker point on the first sample point for all four markers, as shown.



How to view markers is described on page 151

1. In the first Arb menu (page 131), press **Select Waveform**.
2. Highlight the SINE\_TEST\_WFM segment and press **Select Waveform**.
3. Press **ARB Off On** to On.
4. Connect the signal generator's rear panel Q OUT output to the oscilloscope's channel 1 input.
5. Connect the signal generator's rear panel EVENT 1 output to the oscilloscope's channel 2 input.



When marker 1 is present, the Agilent MXG/EXG outputs a signal through EVENT 1 as shown in the following example.



## Using the RF Blanking Marker Function

While you can set a marker function (described as **Marker Routing** on the softkey label in the Marker Utilities menu) either before or after setting the marker points ([page 152](#)), setting a marker function before you set marker points may change the RF output. RF Blanking includes ALC hold (described on [page 147](#), note **Caution** regarding unlevelled power). The signal generator blanks the RF output when the marker signal goes low. This example is a continuation of the previous example, [Viewing a Marker Pulse](#).

1. Using the factory-supplied segment SINE\_TEST\_WFM, set Marker 1 across points 1–180 ([page 152](#)).
2. From the **Marker Routing** softkey menu, assign RF Blanking to Marker 1:  
In the second Arb menu ([page 150](#)), press **Marker Utilities** > **Marker Routing** > **Pulse/RF Blank** > **Marker 1**.



## Setting Marker Polarity

Setting a negative marker polarity inverts the marker signal.

1. In second Arb menu ([page 150](#)), press **Marker Utilities** > **Marker Polarity**.
2. For each marker, set the marker polarity as desired.
  - The default marker polarity is positive.
  - Each marker polarity is set independently.

See also, “[Saving Marker Polarity and Routing Settings](#)” on [page 146](#).

As shown on [page 156](#):

Positive Polarity: *On* marker points are high ( $\approx 3.3V$ ).


Negative Polarity: *On* marker points are low (0V).

RF blanking always occurs on the low part of the signal regardless of the polarity setting.

## Controlling Markers in a Waveform Sequence

In a waveform segment, an enabled marker point generates an auxiliary output signal that is routed to the rear panel EVENT output (described in “[Rear Panel Overview](#)” on [page 12](#)) corresponding to that marker number. For a waveform sequence, you enable or disable markers on a segment-by-segment basis; this enables you to output markers for some segments in a sequence, but not for others. Unless you change the sequence marker settings or cycle the power, the marker setting for the last segment edited in the sequence applies to all segments in the next sequence that you build. For information on building a waveform sequence, see “[Creating a Sequence](#)” on [page 136](#).

Figure 8-6 Waveform Sequence Menus for Enabling/Disabling Segment Markers



### Enabling and Disabling Markers in a Waveform Sequence

Select the waveform segments within a waveform sequence to enable or disable each segment’s markers independently. You can enable or disable the markers either at the time of creating the sequence or after the sequence has been created and stored. If the sequence has already been stored, you must store the sequence again after making any changes. Enabling a marker that has no marker points has no effect on the auxiliary outputs. To set marker points on a segment, see “Setting Marker Points in a Waveform Segment” on page 152. This example assumes that a waveform sequence exists.

1. Ensure that all waveform segments for the sequence reside in BBG media (see page 132).
2. From the second Arb menu, press **Waveform Sequences**.
3. Highlight the desired waveform sequence.
4. Press **Edit Selected Waveform Sequence > Enable/Disable Markers**.
5. Toggle the markers:
  - a. Highlight the first waveform segment.
  - b. As desired, press **Toggle Marker 1**, **Toggle Marker 2**, **Toggle Marker 3**, and **Toggle Marker 4**.

An entry in the Mkr column (see figure below) indicates that the marker is enabled for that segment; no entry in the column means that all markers are disabled for that segment.

- c. In turn, highlight each of the remaining segments and repeat Step b.
6. Press **Return > More > Name and Store**.
7. Either rename the sequence using the text entry keys (see page 133) or just press **Enter** to save the sequence with the existing name.

The markers are enabled or disabled per the selections, and the changes saved to the sequence file.

The following figure shows a sequence built using one of the factory-supplied waveform segments; a factory-supplied segment has a marker point on the first sample for all four markers. In this example, marker 1 is enabled for the first segment, marker 2 is enable for the second segment, and markers 3 and 4 are enabled for the third segment.

| Pg 1/1 | Segment On<br>BBG Media | Sequence On<br>Int Media | (UNSTORED)<br>Pg 1/1 | Waveform            | SINE+RAMP<br>Reps | Mkr | Toggle Marker 3 |
|--------|-------------------------|--------------------------|----------------------|---------------------|-------------------|-----|-----------------|
|        | RAMP_TEST_WFM1          | ANTENNA2M                |                      | WF11:SINE_TEST_WFM1 | 1                 | 1   |                 |
|        | SINE_TEST_WFM1          | SINE+RAMP                |                      | WF11:SINE_TEST_WFM1 | 1                 | 2   |                 |
|        |                         | SINE100+RAMP200          |                      | WF11:SINE_TEST_WFM1 | 1                 | 34  |                 |

Sequence marker column


This entry shows that markers 3 and 4 are enabled for this segment.

For each segment, only the markers enabled for that segment produce a rear panel auxiliary output signal. In this example, the marker 1 auxiliary signal appears only for the first segment, because it is disabled for the remaining segments. The marker 2 auxiliary signal appears only for the second segment, and the marker 3 and 4 auxiliary signals appear only for the third segment.

## Using the EVENT Output Signal as an Instrument Trigger

One of the uses for the EVENT output signal (marker signal) is to trigger a measurement instrument. You can set up the markers to start the measurement at the beginning of the waveform, at any single point in the waveform, or on multiple points in the waveform. To optimize the use of the EVENT signal for measurements, you may also need to adjust the sample rate. The location of the sample rate setting is shown in the figure at right.

For details on each key, use key help as described on [page 34](#).



The EVENT output signal can exhibit jitter of up to  $\pm 4$  ns on the rising and falling edge. This jitter can be minimized in either of two ways.

**Method 1:** Use a sample clock of  $125 \text{ MHz}/N$  where  $N$  is a positive integer and where  $125 \text{ MHz}/N$  can be represented exactly on the display.

For example: 125 MHz, 62.5 MHz, 31.25 MHz, 25 MHz, and so on.


If the result cannot be represented exactly on the display, jitter will be present.

For example:  $N = 6$  will result in jitter, because  $125 \text{ MHz}/6 = 20.833 \text{ Mhz}$ , which is truncated when displayed.

**Method 2:** Select a sample clock and waveform length that spaces the markers by a multiple of 8 ns. For example: A 200 point waveform with a marker on the first point and a sample clock of 50 MHz provides a marker every  $4 \mu\text{s}$ . Because  $4 \mu\text{s}$  is a multiple of 8 ns, the jitter is minimized.


When the EVENT output signal exhibits jitter and it is used as a measurement trigger, it can cause the waveform to falsely appear as having jitter. If this condition occurs, you can adjust the sample rate to a value (see above) that does not cause the jitter appearance. To maintain the integrity of the original waveform with a sample rate change, you will have to also recalculate the sample values. The following figures illustrate the marker signal jitter and its affect on the waveform.

EVENT output signal exhibits jitter due to a non-optimal sample rate




Oscilloscope triggering on waveform

Waveform appears to exhibit jitter when triggered using EVENT signal with jitter.



Oscilloscope triggering on EVENT signal


The jitter is gone with an optimal sample rate



Oscilloscope triggering on EVENT signal

## Triggering a Waveform

Figure 8-7 Triggering Softkeys



For details on each key, use key help as described on [page 34](#).

Triggers control data transmission by controlling when the signal generator transmits the modulating signal. You can configure trigger settings so that data transmission occurs once (Single mode), continuously (Continuous mode), or starts and stops repeatedly (Gated and Segment Advance modes).

A trigger signal contains both positive and negative states; you can use either for triggering.

When you initially select a trigger mode or when you change from one triggering mode to another, you may lose the carrier signal at the RF output until the modulating signal is triggered. This is because the signal generator sets the I and Q signals to zero volts prior to the first trigger event. To maintain the carrier signal at the RF output, create a data pattern with the initial I and Q voltages set to values other than zero.

When you initially turn the Arb ON or select a trigger mode or when you change from one triggering mode to another, you may temporarily lose the carrier signal for a few tens of milliseconds at the RF output. The Arb will present the idle IQrms value of the next Arb waveform to the IQ modulator. This ensures that the RF carrier output is at the correct amplitude level while the Arb waits for a trigger. When that trigger is received, the Arb begins playing the waveform and the modulated RF carrier exhibits no undesirable transients.

There are two parts to configuring a waveform trigger:


- *Type* determines the behavior of the waveform when it plays (see [Trigger Type](#) on page 163).
- *Source* determines how the signal generator receives the trigger that starts the modulating waveform playing (see [Trigger Source](#) on page 164).



## Trigger Type

Type defines the trigger mode: how the waveform plays when triggered.

**NOTE** The example below shows Dual ARB Mode, but trigger functionality is similar for other modulation modes. Available trigger types vary depending on the modulation mode selected.



For details on each key, use key help as described on [page 34](#).

- **Continuous** mode repeats the waveform until you turn the signal off or select a different waveform, trigger mode, or response (Free Run, Trigger & Run, Reset & Run).
- **Single** mode plays the waveform once.

**NOTE** In **Single No Retrigger**, do not use **Continuous Reset & Run** mode due to the variable latency of this setup.

**No Retrigger:** If a trigger is received early it will be ignored. The gap in your playback is dependent on the trigger period, after which time the RF will start up again where it is expected.


**Buffered Trigger:** An early trigger will cause the waveform to play to the end and then start again. The RF will not be aligned with this early trigger.

**Restart on Trigger:** The ARB will reset itself and trigger again but there will some gap in the playback while this is occurring. It will reset itself for every trigger it receives.

- **Segment Advance** mode plays a segment in a sequence only if triggered. The *trigger source* controls segment-to-segment playing (see [Example: Segment Advance Triggering](#) on page 165). A trigger received during the last segment loops play to the *first* segment in the sequence.
- **Gated** mode triggers the waveform at the first active triggering state, then repeatedly starts and stops playing the waveform in response to an externally applied gating signal. See [Example: Gated Triggering](#) on page 166.

## Trigger Source

Mode >  
 Dual ARB >  
 Trigger Source



For details on each key, use key help as described on [page 34](#).

## External Trigger Polarity

- In Continuous, Single, and Segment Advance modes, use the **Ext Polarity** softkey to set the external trigger polarity.
- In Gated mode, the **Active Low** and **Active High** softkeys ([page 163](#)) determine the external trigger polarity.

## Example: Segment Advance Triggering

Segment advance triggering enables you to control the segment playback within a waveform sequence. This type of triggering ignores the repetition value (page 137). For example if a segment has repetition value of 50 and you select Single as the segment advance triggering mode, the segment still plays only once. The following example uses a waveform sequence that has two segments.

If you have not created and stored a waveform sequence, refer to “Creating a Sequence” on page 136.

1. Preset the signal generator.
2. Configure the RF output:
  - Set the desired frequency.
  - Set the desired amplitude.
  - Turn on the RF output.
3. Select a waveform sequence for playback:
  - a. Press **Mode > Dual ARB > Select Waveform**.
  - b. In the Sequence On column, highlight a waveform sequence file.
  - c. Press **Select Waveform**.
4. Set the triggering as follows:
  - Trigger Type: continuous Segment Advance  
Press **Trigger Type > Segment Advance > Continuous**.
  - Trigger source: Trigger hardkey  
Press **Trigger Source > Trigger Key**.
5. Generate the waveform sequence:  
Press **ARB Off On** until On highlights.
6. (Optional) Monitor the waveform:  
Connect the RF OUTPUT of the signal generator to the input of an oscilloscope, and configure the oscilloscope so that you can see the signal.
7. Trigger the first waveform segment to begin playing continuously:  
Press the **Trigger** hardkey.
8. Trigger the second segment:  
Press the **Trigger** hardkey.


Pressing the **Trigger** hardkey causes the currently playing segment to finish and the next segment to start.

If the last segment in the sequence is playing, pressing the **Trigger** hardkey causes the *first* segment in the waveform sequence to start when the last segment finishes.

## Example: Gated Triggering

Gated triggering enables you to define the on and off states of a modulating waveform.

1. Connect the output of a function generator to the signal generator's rear panel PAT TRIG IN connector, as shown in the following figure. This connection is applicable to all external triggering methods. The optional oscilloscope connection enables you to see the effect that the trigger signal has on the RF output.




2. Preset the signal generator.
3. Configure the RF output:
  - Set the desired frequency.
  - Set the desired amplitude.
  - Turn on the RF output.
4. Select a waveform for playback (sequence or segment):
  - a. Press **Mode** > **Dual ARB** > **Select Waveform**.
  - b. In the Segment On or Sequence On column, highlight a waveform.
  - c. Press **Select Waveform**.
5. Set the triggering as follows:
  - Trigger type: Gated  
Press **Trigger Type** > **Gated**.
  - Active state: Low  
Press **Active Low**.
  - Trigger source: External  
Press **Trigger Source** > **Ext**.
  - Input connector: Rear panel Patt Trig In BNC  
Press **Ext Source** > **Patt Trig In 1**.
6. Generate the waveform: Press **Return** > **ARB Off On** until On highlights.

7. On the function generator, configure a TTL signal for the external gating trigger.

8. (Optional) Monitor the waveform:


Configure the oscilloscope to display both the output of the signal generator, and the external triggering signal. You will see the waveform modulating the output during the gate *active* periods (low in this example).

The following figure shows an example display.



## Example: External Triggering

Use the following example to set the signal generator to output a modulated RF signal 100 milliseconds after a change in TTL state from low to high occurs at the PATT TRIG IN rear panel BNC connector




1. Connect the signal generator to the function generator as shown above.
2. Configure the RF output:
  - Set the desired frequency.
  - Set the desired amplitude.
  - Turn on the RF output.
3. Select a waveform for playback (sequence or segment):
  - a. Press **Mode > Dual ARB > Select Waveform**.
  - b. In the Segment On or Sequence On column, highlight a waveform.
  - c. Press **Select Waveform**.
4. Generate the waveform:  
Press **ARB Off On** until On highlights.
5. Set the waveform trigger as follows:
  - a. Trigger Type: single  
Press **Trigger Type > Single > No Retrigger**
  - b. Trigger Source: external  
Press **Trigger Source > Ext**
  - c. Input connector: Rear panel Patt Trig In BNC  
Press **Ext Source > Patt Trig In 1**.
  - d. External Trigger Polarity: positive  
Press **Ext Polarity** until Pos highlights
  - e. External Delay: 100 ms  
Press **More > Ext Delay** until On highlights  
Press **Ext Delay Time > 100 > msec**
6. Configure the Function Generator:
  - Waveform: 0.1 Hz square wave
  - Output Level: 3.5V to 5V.

## Clipping a Waveform

Digitally modulated signals with high power peaks can cause intermodulation distortion, resulting in spectral regrowth that can interfere with signals in adjacent frequency bands. The clipping function enables you to reduce high power peaks by clipping the I and Q data to a selected percentage of its highest peak, thereby reducing spectral regrowth.

- [How Power Peaks Develop](#) on page 170
- [How Peaks Cause Spectral Regrowth](#) on page 172
- [How Clipping Reduces Peak-to-Average Power](#) on page 173
- [Configuring Circular Clipping](#) on page 176
- [Configuring Rectangular Clipping](#) on page 177

**Figure 8-8 Clipping Softkeys**




## How Power Peaks Develop

To see how clipping reduces high power peaks, it is important to understand how the peaks develop as you construct a signal.

### Multiple Channel Summing

I/Q waveforms can be the summation of multiple channels, as shown in the following figure. If a bit in the same state (high or low) occurs simultaneously in several individual channel waveforms, an unusually high power peak (positive or negative) occurs in the summed waveform.

Because the high and low states of the bits in channel waveforms are random and generally result in a cancelling effect, high power peaks occur infrequently with multiple channel summing.






### Combining the I and Q Waveforms


When the I and Q waveforms combine in the I/Q modulator to create an RF waveform, the magnitude of the RF envelope is  $\sqrt{I^2+Q^2}$ , where the squaring of I and Q always results in a positive value.

As shown in the following figure, simultaneous positive and negative peaks in the I and Q waveforms do not cancel each other, but combine to create an even greater peak.




## How Peaks Cause Spectral Regrowth

In a waveform, high power peaks that occur infrequently cause the waveform to have a high peak-to-average power ratio, as illustrated in the following figure.



Because the gain of a transmitter's power amplifier is set to provide a specific average power, high peaks can cause the power amplifier to move toward saturation. This causes the intermodulation distortion that generates spectral regrowth. Spectral regrowth is a range of frequencies that develops on each side of the carrier (similar to sidebands) and extends into the adjacent frequency bands (see the following figure). Clipping provides a solution to this problem by reducing the peak-to-average power ratio.



## How Clipping Reduces Peak-to-Average Power

You can reduce peak-to-average power, and consequently spectral regrowth, by clipping the waveform. Clipping limits waveform power peaks by clipping the I and Q data to a selected percentage of its highest peak. The Signal Generator provides two methods of clipping:

- *Circular* clipping is applied to the composite I/Q data (I and Q data are equally clipped).

As shown in [Figure 8-9](#), the clipping level is constant for all phases of the vector and appears as a circle in the vector representation.

- *Rectangular* clipping is independently applied the I and Q data.

As shown in [Figure 8-10 on page 174](#), the clipping level is different for I and Q, and appears as a rectangle in the vector representation.

In both circular and rectangular clipping, the objective is to clip the waveform to a level that reduces spectral regrowth but does *not* compromise the integrity of the signal. The two complementary cumulative distribution plots in [Figure 8-11 on page 175](#) show the reduction in peak-to-average power that occurs after applying circular clipping to a waveform.

The lower the clipping value, the lower the peak power that is passed (the more the signal is clipped). The peaks can often be clipped without substantially interfering with the rest of the waveform. In many cases, data that might otherwise be lost in the clipping process is retained because of the error correction inherent in the coded systems. If you apply excessive clipping, however, lost data cannot be recovered. Experiment with clipping settings to find a percentage that reduces spectral regrowth while retaining needed data.

**Figure 8-9 Circular Clipping**




Figure 8-10 Rectangular Clipping





Figure 8-11 Reduction of Peak-to-Average Power

Complementary Cumulative Distribution



## Configuring Circular Clipping

Use this example to configure circular clipping and observe its affect on the peak-to-average power ratio of a waveform. Circular clipping clips the composite I/Q data (I and Q data are clipped equally). For more information about circular clipping, refer to [“How Clipping Reduces Peak-to-Average Power” on page 173](#).

---

**CAUTION** Clipping is non-reversible and cumulative. Save a copy of the waveform file before you apply clipping.

---


### Copy a Waveform File

1. Display the signal generator’s files: Press **File > Catalog Type > More > Volatile Segments**.
2. Highlight the waveform RAMP\_TEST\_WFM.
3. Press **Copy File**.
4. Name the copy (in this example, the name is MY\_TEST\_CIRC) and press **Enter**.

### Apply Circular Clipping to the Copied Waveform File


1. Open the DUAL ARB Waveform Utilities menu: Press **Mode > Dual ARB > More > Waveform Utilities**.
2. In the list of files, highlight the copied file (in this example, MY\_TEST\_CIRC).

3. Create the CCDF plot: Press **Plot CCDF**.
4. Observe the shape and position of the waveform’s curve (the dark line in the example at right).



5. Activate circular clipping: Press **Return > Clipping > Clipping Type** until **|I+jQ|** highlights.
6. Set circular clipping to 80%: Press **Clip |I+jQ| To > 80 > %**.

7. Apply 80% clipping to the I and Q data: Press **Apply to Waveform**.
8. Create the CCDF plot (see the example at right): Press **Plot CCDF**.



9. Observe the waveform’s curve after clipping.

Note the reduction in peak-to-average power relative to the previous plot.

## Configuring Rectangular Clipping

Use this example to configure rectangular clipping. Rectangular clipping clips the I and Q data independently. For more information about rectangular clipping, refer to “How Clipping Reduces Peak-to-Average Power” on page 173.


**CAUTION** Clipping is non-reversible and cumulative. Save a copy of the waveform file before you apply clipping.

### Copy a Waveform File


1. Display the signal generator’s files: Press **File > Catalog Type > More > Volatile Segments**.
2. Highlight the waveform RAMP\_TEST\_WFM.
3. Press **Copy File**.
4. Name the copy (in this example, the name is MY\_TEST\_REC) and press **Enter**.

### Apply Rectangular Clipping to the Copied Waveform File

1. Open the DUAL ARB Waveform Utilities menu: Press **Mode > Dual ARB > More > Waveform Utilities**.
2. In the list of files, highlight the copied file (in this example, MY\_TEST\_REC).
3. Create the CCDF plot: Press **Plot CCDF**.
4. Observe the shape and position of the waveform’s curve (the dark line in the example at right).
5. Activate rectangular clipping: Press **Return > Clipping > Clipping Type** until **|I|,|Q|** highlights.
6. Set 80% clipping for the I data: Press **Clip |I| To > 80 > %**.
7. Set 40% clipping for the Q data: Press **Clip |Q| To > 40 > %**.
8. Apply the rectangular clipping to the waveform: Press **Apply to Waveform**.



9. Create the CCDF plot (see the example at right): Press **Plot CCDF**.
10. Observe the waveform’s curve after clipping.  
Note the reduction in peak-to-average power relative to the previous plot.




## Scaling a Waveform

The signal generator uses an interpolation algorithm (sampling between the I/Q data points) when reconstructing a waveform. For common waveforms, this interpolation can cause overshoots, which may create a DAC over-range error condition. This chapter describes how DAC over-range errors occur and how you can use waveform scaling to eliminate these errors.

- [How DAC Over-Range Errors Occur](#) on page 179
- [How Scaling Eliminates DAC Over-Range Errors](#) on page 180
- Agilent MXG/EXG waveform scaling on [page 181](#) and [page 182](#):
  - Waveform runtime scaling to scale a currently-playing waveform
  - Waveform scaling to permanently scale either the currently playing waveform, or a non-playing waveform file in BBG media

Figure 8-12 Scaling Softkeys




For details on each key, use key help as described on [page 34](#).




## How DAC Over-Range Errors Occur

The signal generator uses an interpolator filter when it converts digital I and Q baseband waveforms to analog waveforms. Because the clock rate of the interpolator is four times that of the baseband clock, the interpolator calculates sample points between the incoming baseband samples and smooths the waveform as shown in the figure at the right.




The interpolation filters in the DACs overshoot the baseband waveform. If a baseband waveform has a fast-rising edge, the interpolator filter's overshoot becomes a component of the interpolated baseband waveform. This response causes a ripple or ringing effect at the peak of the rising edge. If this ripple overshoots the upper limit of the DAC range, the interpolator calculates erroneous sample points and is unable to replicate the true form of the ripple (see the figure at the right). As a result, the signal generator reports a DAC over-range error.



## How Scaling Eliminates DAC Over-Range Errors

Scaling reduces the amplitude of the baseband waveform while maintaining its basic shape and characteristics, such as peak-to-average power ratio. If the fast-rising baseband waveform is scaled enough to allow an adequate margin for the interpolator filter overshoot, the interpolator filter can calculate sample points that include the ripple effect and eliminate the over-range error (see the figure at the right).

Although scaling maintains the basic shape of the waveform, excessive scaling can compromise waveform integrity. For example, if the bit resolution becomes too low the waveform becomes corrupted with quantization noise. To achieve maximum accuracy and optimize dynamic range, scale the waveform no more than is required to remove the DAC over-range error. Optimum scaling varies with waveform content.



## Setting Waveform Runtime Scaling

Runtime scaling scales the waveform data during playback; it does not affect the stored data. You can apply runtime scaling to either a segment or sequence, and set the scaling value either while the ARB is on or off. This type of scaling is well suited for eliminating DAC over-range errors. Runtime scaling adjustments are not cumulative; the scaling value is applied to the original amplitude of the waveform file. There are two ways to save the runtime scaling setting: by using the save function (page 58) and by saving the setting to the file header (page 141). Saving to the file header saves the value with the waveform file, saving with the Save function stores the value as the current instrument setting.

Use this example to learn how to scale the currently selected waveform.

1. Select the waveform to which you want to apply scaling:
  - a. Press **Mode > Dual ARB > Select Waveform**.
  - b. Highlight the desired waveform (segment or sequence).
  - c. Press **Select Waveform**.
2. Play the selected waveform: Press **ARB Off On** until On highlights.
3. Set the Waveform Runtime Scaling value:
  - a. Press **ARB Setup > Waveform Runtime Scaling**.
  - b. Enter a scaling value.

The signal generator automatically applies the new scaling value to the waveform. There is no single value that is optimal for all waveforms. To achieve the maximum dynamic range, use the largest scaling value that does not result in a DAC over-range error.


- c. Press **Return**.

## Setting Waveform Scaling

Waveform scaling differs from waveform runtime scaling in that it permanently affects waveform data and only applies to waveform segments stored in BBG media. You scale the waveform either up or down as a percentage of the DAC full scale (100%). If you scale your waveforms using this method, you may also need to change the waveform runtime scaling value to accommodate this scaling.

When you scale, the signal generator permanently modifies the waveform file's sample values so that they conform to the desired scaling value. When you initiate scaling, the signal generator performs the following actions:

- locates the waveform file's absolute peak sample value
- determines its current percentage of full scale
- calculates the ratio of the desired scale value to the determined absolute peak sample scale value
- multiplies each sample in the waveform file by this ratio



Scaled sample value = scaling ratio × prescale sample val

Scaling ratio = desired scale val / current scale val  
= 60 / 85  
= 0.70588

Each sample in the waveform is multiplied by 0.70588 to reach the 60% post scaling waveform amplitude.

When you scale a waveform, you can create fractional data, lose data, or both. Fractional data occurs almost every time you reduce or increase the scaling value, and causes quantization errors.

Quantization errors are more noticeable when scaling down, since you are closer to the noise floor. You lose data when either the signal generator rounds fractional data down or the scaling value is derived using the results from a power of two. This means that scaling a waveform in half (power of two:  $2^1 = 2$ ) causes each waveform sample to lose one bit. The waveform data modifications are not correctable and may cause waveform distortion. It is always best to make a copy of the original file prior to applying scaling.

Use the following examples to apply waveform scaling to a waveform file. While this process uses the factory-supplied waveform RAMP\_TEST\_WFM, it is the same for any waveform file.

### Copy a Waveform File

1. Display the waveform files in BBG media: Press **File > Catalog Type > More > Volatile Segments**.
2. Highlight the waveform RAMP\_TEST\_WFM.
3. Press **Copy File**.
4. Name the copy (this example uses the name MY\_TEST\_SCAL) and press **Enter**.

### Apply Scaling to the Copied Waveform File

---

**CAUTION** This type of scaling is non-reversible. Any data lost in the scaling operation cannot be restored. Save a copy of the waveform file before scaling.

---


1. Open the DUAL ARB Waveform Utilities menu:  
Press **Mode > Dual ARB > More > Waveform Utilities**.
2. In the list of BBG Media segment files, highlight the copied file (in this example, MY\_TEST\_SCAL).
3. Set and apply a scaling value (in this example 70% scaling is applied):  
Press **Scale Waveform Data > Scaling > 70 > % > Apply to Waveform**.

## Setting the Baseband Frequency Offset

The baseband frequency offset specifies a value to shift the baseband frequency up to  $\pm 50$  MHz within the BBG 100 MHz signal bandwidth, depending on the signal generator's baseband generator option. While the following figure shows how to access the control using the Dual ARB player, the location of the **Baseband Frequency Offset** softkey within each ARB format, through the **ARB Setup** softkey, is the same as for the Dual ARB player.

When the Baseband Frequency Offset is non-zero, the hardware rotator accumulates phase-shift of the baseband signal. This residual phase remains even after the offset value is returned to zero. To remove this phase accumulation, either restart the personality or select the **Baseband Frequency Offset Phase Reset** softkey. This softkey will grey out whenever the phase, due to the frequency offset, is zero. In addition, while there is a non-zero residual phase present in the signal, the DAC Over-Range Protection feature will automatically ensure that the reduced internal scaling is applied. This reduced scaling will be removed when both the frequency offset is returned to zero and the phase is reset.

Figure 8-13 Baseband Frequency Offset Softkey for the Dual ARB Player



Common uses for the offset feature include:

- offsetting the carrier from any LO feedthrough (carrier signal spur at the carrier frequency)
- sum the baseband signal with external I and Q inputs to create a multicarrier signal
- use the signal generator's I/Q signal as an IF

---

**NOTE** Changing the baseband frequency offset may cause a DAC over range condition that generates error 628, Baseband Generator DAC over range. The signal generator incorporates an automatic scaling feature to minimize this occurrence. For more information, see “DAC Over-Range Conditions and Scaling” on page 186.

---


The baseband frequency offset value is one of the file header parameters (page 139), which means you can store this value with the waveform. When you select a waveform with a stored frequency offset value, the signal generator changes the current value to match the stored file header value. If there is no stored baseband offset frequency value for the current waveform, the signal generator uses the last set frequency offset value.

You can also use the Save function (page 58) to store this value as part of the signal generator setup. When you Recall a setup stored with the Save function, the baseband frequency offset value becomes the current instrument setting value, disregarding the stored file header value.

Use the following steps to offset the carrier from LO/carrier feedthrough. This example uses the factory supplied waveform, SINE\_TEST\_WFM available in the Dual ARB Player. To view the output for this example, connect the RF OUTPUT of the signal generator to the input of a spectrum analyzer.

1. Select and play the waveform.
  - a. Press **Mode > Dual ARB > Select Waveform**.
  - b. In the Segment On BBG Media column, select SINE\_TEST\_WFM.
  - c. Press **Select Waveform**.
2. Generate the waveform: Press **ARB Off On** to On.
3. Configure the carrier signal:
  - a. Set the carrier signal to 1 GHz.
  - b. Set the amplitude to 0 dBm.
  - c. Turn on the RF OUTPUT.
4. Press **Mode > Dual Arb > ARB Setup > More > Baseband Frequency Offset > 20 MHz**.

The modulated RF signal is now offset from the carrier frequency by 20 MHz as shown in the following figures.




## DAC Over-Range Conditions and Scaling

When using the baseband frequency offset (at a setting other than 0 Hz), it is possible to create a DAC over-range condition, which causes the Agilent MXG/EXG to generate an error. To minimize this condition with the frequency offset feature, the Agilent MXG/EXG incorporates an automatic DAC over-range protection feature that scales down the I/Q data by *1/square root of 2* when the offset is something other than zero. Because it can scale the data by more than what is actually need, it typically decreases the dynamic range of the waveform. This is especially noticeable when using a constant amplitude signal such as GSM.

For the Dual ARB Player, this automatic over-range feature can be turned off. When on, it is active for the Dual ARB signal only when the offset is something other than 0 Hz. The control for the Dual ARB DAC over-range protection feature is located in the key path as shown in [Figure 8-14](#).



Figure 8-14 Dual ARB DAC Over-Range Protection Softkey Location



In the Dual ARB Player, to avoid excessive scaling or to just perform scaling manually, turn the feature off and use the **Waveform Runtime Scaling** softkey to eliminate DAC over-range conditions.

## I/Q Modulation


The following factors contribute to the error vector magnitude:

- Differences in amplitude, phase, and delay between the I and Q channels
- DC offsets

The I/Q menu not only enables you to select the I/Q signal source and output, it also provides adjustments and calibrations to compensate for differences in the I and Q signals.

See also, [“Modulating the Carrier Signal” on page 48.](#)

Figure 8-15 I/Q Display and Softkeys



**I/Q**

Int Phase Polarity: Normal, Invert

Burst Envelope: Off, On

Int Equalization Filter: (Off)

Optimize Int I/Q Channel For: EVM, ACP

Int Channel Correction: Off, On

More 2 of 3

- ← Inverts an internally generated Q signal, so that the I component lags the Q component by 90 degrees.
- ← Used only with internally generated, bursted modulation formats. Enables/disables the RF burst modulator.
- ← Opens the internal I/Q Equalization Filter which can be used to correct and/or impair the RF and External I/Q outputs for the internal I/Q source.
- ← Selects between optimizing the internal I/Q channel for EVM (in channel performance) at the expense of ACP (out of channel performance) or optimizing for ACP at the expense of EVM.
- ← EVM is an 80% nyquist filter (100MHz wide) with a wide transition band. When an equalization filter is active, this filter is not active. ACP is also an 80% nyquist filter (100MHz wide), but the transition band is very narrow, thus reducing images for wide-band signals. This filter will be convolved with the active equalization filter and the Int Channel Correction filter (if it is on), the result of which will be truncated to the center 256 taps.

**I/Q**

Ext Input Level: 500 mV rms, Default, Man, Meas

Do External Input Level Measurement

Ext In I/Q Atten: 9.53 dB, Manual, Auto

Summing Ratio (INT/EXT): 0.00 dB

SCPI Commands:  
[:SOURCE]:DM:INTernal:CHANnel:OPTimization EVM|ACP  
[:SOURCE]:DM:INTernal:CHANnel:OPTimization?

← Toggles on or off the application of the internal baseband generator RF, and baseband magnitude and phase corrections across the 160MHz baseband bandwidth at the current RF frequency.

When this feature is on, arbitrary frequency switching while the baseband is on will take up to an additional 3.3ms (typical) to 6.8ms the first time that frequency is specified. After that, switching to that frequency will take up to an additional 1.3ms.

Up to 1024 unique frequencies can be cached before the oldest cache will be forgotten. If a frequency sweep is activated, then the calculation and caching will occur up front for the first 1024 unique frequencies, and all further unique frequencies will have the characteristics of arbitrary frequency switching.

If the I/Q Correction Optimized Path is set to Ext I/Q Output, then only the baseband corrections will be applied and the frequency switching speed will be unaffected.

This correction will be convolved with the ACP Internal I/Q Channel Optimization filter and the Equalization filter if they are active. The resulting filter will be truncated to 256 taps.

SCPI Commands:

[:SOURCE]:DM:INTernal:CHANnel:CORRection[:STATE] ON|OFF|1|0  
[:SOURCE]:DM:INTernal:CHANnel:CORRection[:STATE]?

For details on each key, use key help as described on page 34.

**I/Q Optimization**

RF Output

Ext I/Q Output

Each path requires different optimization values; when you select a path, you are selecting the unique optimization values required by that path. The signal generator applies the selected optimization values to all paths, which impairs the unselected paths.

## Using the Rear Panel I and Q Outputs

**NOTE** The rear panel I and Q connectors only output a signal while using the internal BBG.

In addition to modulating the carrier, the signal generator also routes the internally generated I and Q signals to the rear panel I and Q connectors. These output signals are post DAC, so they are in analog form. You can use these rear panel I and Q signals to:

- drive a system's transmitter stage
- test individual analog I and Q components such as an I/Q modulator
- route the I and Q signals into another signal generator

The factory default setting routes the internally generated I and Q signals to the I/Q modulator and the rear panel I and Q output connectors. However to optimize (apply calibration factors) the rear panel signals, you need to select the external I/Q output path.

### Select and Play a Waveform

1. Press **Mode > Dual ARB > Select Waveform**.
2. Highlight the desired waveform.
3. Press **Select Waveform > ARB Off On to On**.

### Optimize the Signal Path


1. Connect cables from the rear panel I and Q connectors to either a DUT or another signal generator.

When you turn the ARB on, the signal generator automatically outputs the I and Q signals to the rear panel connectors. You can use the rear panel I and Q signals as I and Q inputs to another signal generator. The MXG/EXG has front panel connectors, I Input and Q Input, for this purpose.



2. Press **I/Q > I/Q Correction Optimized Path > Ext I/Q Output**.

When you optimize a path, the path indicator turns green.

Factory default setting—RF Output path optimized



Rear panel I/Q path optimized



## Configuring the Front Panel Inputs

The signal generator accepts externally supplied analog I and Q signals through the front panel I Input and Q Input. You can use the external signals as the modulating source, or sum the external signals with the internal baseband generator signals.


1. Connect I and Q signals to the front panel connectors.
  - a. Connect an analog I signal to the signal generator's front panel I Input.
  - b. Connect an analog Q signal to the signal generator's front panel Q Input.
2. Set the signal generator to recognize the front panel input signals:

- **To Modulate onto the Carrier**

Press **I/Q > I/Q Source > External**.

Signal generator display: both paths are calibrated when the **I/Q Correction Optimized Path** is set to **Ext I/Q Output** (see [page 190](#))

**Note:** when the optimized path is set to RF, *only* the RF Out path is calibrated.




- **To Sum and Modulate onto the Carrier**

Press **I/Q > I/Q Source > Sum**.

To select and play a waveform for the BB GEN path, see [page 133](#).

Signal generator display: both RF paths are calibrated when the **I/Q Correction Optimized Path** is set to **RF Output** (see [page 190](#))



Notice that only the internal BBG (BB GEN) routes I and Q signals to the rear panel I and Q outputs.

3. If you are using only the external I and Q signals (no summing), turn on the I/Q modulator: Press **I/Q Off On** to On.
4. Configure the RF output:
  - a. Set the carrier frequency.
  - b. Set the carrier amplitude.
  - c. Turn the RF output on.

## I/Q Adjustments

Use the I/Q Adjustments to compensate for or add impairments to the I/Q signal.

Adjusts the I signal amplitude relative to the Q signal amplitude. Use this as an internal impairment, or to compensate for differences in signal path loss that occur due to path irregularities in the external I and Q output cabling.

The DC offset values are calibrated relative to the RMS waveform voltage being played out of the ARB. See page 142.

### I/Q > I/Q Adjustments

**I/Q Adjustments**

- I/Q Adjustments: **Off** On
- Internal Baseband Adjustments
- External Input Adjustments
- External Output Adjustments

This feature allows adjustment of the absolute phase of the internal I/Q channel by rotating both I and Q, thus adjusting the relative phase of the RF carrier. For option 012, this is the only way to adjust the RF phase for a unit with an external LO.

**Ext In I/Q Adj**

- External Input I Offset: 0.0000 V
- External Input Q Offset: 0.0000 V
- External Input I/Q Gain Balance: 0.000 dB
- Quadrature Angle Adjustment: 0.0

Offsets the phase of the Q signal relative to the phase of the I signal. The baseband quadrature adjustment key is calibrated in units of degrees. The external input quadrature adjustment is not calibrated.

The function provided by this key is not the same as the function provided by the I/Q Skew key.

**BB I/Q Adj**

- I Offset: 0.000 %
- Q Offset: 0.000 %
- I/Q Gain Balance: 0.000 dB
- Quadrature Angle Adjustment: 0.00 deg
- I/Q Phase: 0.00 deg

Note 1 of 2

Note: The I/Q signal will be scaled down by 0.7071 for all phase offsets except 0. Use -360 or +360, if it is desirable to maintain a constant power level with the ALC off while adjusting the I/Q phase.

**Ext Out I/Q Adj**

- I/Q Attenuator (N/A)
- Common Mode I/Q Offset Range: **Coarse** Fine
- Common Mode I/Q Offset: 0.0000 V
- Diff. Mode I Offset: 0.0000 V
- Diff. Mode Q Offset: 0.0000 V

The I/Q Attenuator softkey affects the I/Q signal to the RF Output and the External I/Q Outputs.

This softkey is active when the I/Q optimized path is set to **Ext I/Q Output** and a digital modulation personality is on. This attenuation is also adjustable using the **Mod Attenuator** key located in the Arb Setup menus in each personality. This adjustment is not affected by the I/Q Adjustments On/Off key.

When Auto mode is selected, the signal generator automatically optimizes I/Q attenuation for the current conditions. When the Manual mode is selected, I/Q Attenuation is the active function. The value you enter sets the attenuation level of the I/Q signal.

SCPI Commands (Refer to the commands for each personality):  
[:SOURce]:RADio:<personality>:IQ:MODul ation:ATTen

**Skew** is typically used either to create impairments, or to reduce error vectors on large bandwidth signals.

Provides a relative time delay correction between the I and Q signals. The different signal paths traveled by the I and Q signals result in time delay differences that show up as an EVM error in large bandwidth modulated signals.

Adding an equal and opposite time delay (skew) in the I/Q signals during baseband generation eliminates the time delay error, correcting for any delays in signals that are generated in the internal baseband generator.

**BB I/Q Adj**

- I/Q Skew: 0.000000000000 sec
- I/Q Delay: 0.000000000000 sec

Available only when a waveform is playing.

Changes the absolute phase of both the I and Q signals with respect to triggers and markers.

Positive values add delay and negative values advance the signals. This value affects both the baseband signal modulated onto the RF and the external output signals (I and Q). This setting cannot be used with constant envelope modulation and it does not affect external I and Q inputs.

**Offsets** are typically used to either reduce carrier leakage, or to create an impairment that simulates carrier leakage.

#### Common Mode I/Q Offset Range

This changes the adjustment range of the Common Mode I/Q Offset from Coarse (Default) to fine or vice versa. The Coarse range corresponds to the default value of  $\pm 2.5V$ . The Fine range corresponds to a value of  $\pm 100$  mV.

#### Common Mode I/Q Offset

This adjusts the DC offset of both I and Q signals simultaneously.

#### Diff Mode I Offset

This adjusts the DC offset level of the I and I-bar output signal. I and I-bar cannot be adjusted independently.

#### Diff Mode Q Offset

This adjusts the DC offset level of the I and I-bar output signal. I and I-bar cannot be adjusted independently.

**Table 8-2 I/Q Adjustments Uses**

| <b>I/Q Adjustment</b> | <b>Effect</b>            | <b>Impairment</b>                             |
|-----------------------|--------------------------|---|
| Offset                | Carrier feedthrough      | dc offset                                     |
| Quadrature Angle      | EVM error                | phase skew                                    |
|                       | I/Q images               | I/Q path delay                                |
| I/Q Skew              | EVM error                | high sample rate phase skew or I/Q path delay |
| I/Q Gain Balance      | I/Q amplitude difference | I/Q gain ratio                                |
| I/Q Phase             | I/Q phase rotation       | RF phase adjustment                           |

The I/Q adjustment, I/Q Delay, is not for adding impairments; its function is to compensate for any latency between the EVENT output signals (marker signals) and the RF output.

## I/Q Calibration

Use the I/Q calibration for I and Q signal corrections. What aspects of the I and Q signal is corrected depends on whether the signal is internally or externally generated.


| Correction       | Internal I and Q | External I and Q |
|------------------|------------------|------------------|
| Offset           | X                | X                |
| Gain Balance     | X                | X                |
| Quadrature Error | X                | X                |

When you perform an I/Q calibration, that calibration data takes precedence over the factory-supplied calibration data. The calibration routines improve performance that may degrade over time or due to temperature changes. An I/Q calibration should be run when the ambient temperature has varied by at least  $\pm 5$  degrees Celsius from the ambient temperature at which the previous calibration was run.

- The user I/Q calibration is persistent (i.e. Pressing instrument preset or cycling power does not remove the user I/Q calibration from memory).
- If the start and stop frequencies are set to the same value, then the calibration will be performed exactly at that frequency and the data will be persisted in the bounding calibration array elements.



I/Q > I/Q Calibration



Available only when Calibration type = User

Deletes any user-generated calibration data and restores the factory-supplied calibration data.

**DC** optimizes the I/Q performance for the current instrument settings, and typically completes in several seconds. Changing any instrument setting after performing a DC calibration voids the DC calibration and causes the signal generator to revert to the user calibration data (or factory-supplied calibration data, if no user calibration data exists)

**User** provides a quicker calibration when a full calibration is not required. You can limit the calibration by specifying the calibration start and stop frequencies.

When you limit the calibration to less than the instrument's full frequency range, the factory-supplied calibration data is used for the rest of the range. If the start and stop frequencies are set to the same value, then the calibration will be performed exactly at that frequency and the data will be persisted in the bounding calibration array elements. Information is retained through a preset or power cycle\*.

**Full** takes approximately a minute, executing measurements over the instrument's entire frequency range.

Information is retained through a preset or power cycle\*.

**\*Caution:**

To avoid the loss of data, GPIB settings, or current user instrument states that have not been permanently saved to non-volatile memory, the signal generator should always be powered down either via the Instrument's front panel power button or the appropriate SCPI command. Signal generators installed in rack systems and powered down with the system rack power switch rather than the instrument's front panel switch display an Error -310 due to the instrument not being powered down correctly.

**Note**

A DC calibration requires the following settings:

- I/Q: On
- Optimized Path: RF Output
- Source: Internal

For details on each key, use key help as described on [page 34](#).

## Using the Equalization Filter

An equalization FIR file can be created externally, uploaded via SCPI, and subsequently selected from the file system (refer to “[Working with Files](#)” on page 50). For information related to downloading FIR file coefficients, refer to the *Programming Guide*. For information regarding working with FIR file coefficients manually, refer to “[Modifying a FIR Filter Using the FIR Table Editor](#)” on page 204.

This filter can be used to correct and/or impair the RF and External I/Q outputs for the internal I/Q source. This filter will be convolved with the ACP Internal I/Q Channel Optimization filter if that filter is selected, the result of which will be truncated to the center 256 taps. The equalization filter operates at 200 MHz, so all equalization filters must be resampled to 200 MHz prior to selection, if they are sampled at some other rate.

The MXG/EXG supports equalization filters—either Complex or Real—that are programmable FIR filters with two inputs (I, Q) and two outputs (I, Q) per sample. This 256-tap filter has two modes of operation:

---

**NOTE** The maximum number of taps is 256 (with 2 coefficients per tap for a complex filter) for equalization filters. The minimum number of taps is 2.

Equalization filters can also be referred to as predistortion filters or correction filters.


---

| Type of Filter | Description  |
|----------------|--|
| Real           | The I and Q samples are independently filtered by a single set of real coefficients.   |
| Complex        | The samples are treated as complex ( $I + jQ$ ) and convolved with the filter coefficients which are specified as $(I + jQ)$ in the time domain. |

The equalization filter can be turned on and off.

Figure 8-16 Int Equalization Filter Softkeys

For details on each key, use key help as described on page 34.



**Note:**  
Use the FIR Table editor to view the filter's coefficients.  
Refer to page 204.

For more information on the SCPI commands, refer to the *SCPI Command Reference*.

**SCPI commands:**

Equalization filter state:  
[:SOURCE]:DM:INTERNAL:EQUALIZATION:FILTer:STATe { OFF } | ON  
[:SOURCE]:DM:INTERNAL:EQUALIZATION:FILTer:STATe?

Equalization filter selection:  
[:SOURCE]:DM:INTERNAL:EQUALIZATION:FILTer:SElect "filename"  
[:SOURCE]:DM:INTERNAL:EQUALIZATION:FILTer:SElect?

To add a real filter to the file system:

```
:MEMory:DATA:FIR "filename", [REAL,] osr, coeff1 [,coeff2 [...,
coeffN]]
:MEMory:DATA:FIR? "filename"
```

To add complex filter to the file system:

```
:MEMory:DATA:FIR "filename", COMpLex, osr, hIRe0, hQIm0 [, hIRe1,
hQIm1 [..., hIReN, hQImN]]
:MEMory:DATA:FIR? "filename"
```

To add I/Q symbol data to the file system:

```
:MEMory:DATA "WFM1:filename", <blockdata>
```


## Using Finite Impulse Response (FIR) Filters in the Dual ARB Real-Time Modulation Filter

Finite Impulse Response filters can be used to compress single carrier I/Q waveforms down to just the I/Q constellation points and then define the transitions similar to the modulation filter in Arb Custom (refer to “Using Finite Impulse Response (FIR) Filters with Custom Modulation” on page 281). The key difference for dual ARB real-time modulation is that a filter is applied as the waveform plays, rather than in the waveform data itself.

**Figure 8-17 Filter Menu**

Mode > Dual ARB > Arb Setup > More > Real-Time Modulation Filter >

Enables or disables the Modulation Filter. This filter is typically applied to an Arb Waveform containing just the I/Q symbol decision points. The Modulation Filter then effectively defines the transitions between the symbol decision points. This means that the filter must have an oversample ratio of 2 or more. When this feature is active, the Sample Clock Rate is actually the Symbol Rate. Also, the filter must be real (refer to page 208).



## Creating a User-Defined FIR Filter Using the FIR Table Editor

In this procedure, you use the FIR Values table editor to create and store an 8-symbol, windowed sync function filter with an oversample ratio of 4.

### Accessing the Table Editor


1. Press **Preset**.
2. Press **Mode > Dual ARB > Arb Setup > More > Real-Time Modulation Filter > Select > Nyquist**.
3. Press **Define User FIR**.
4. Press **More 1 of 2 > Delete All Rows > Confirm Delete of All Rows**.

This will initialize the table editor as shown in [Figure 8-18](#).

**Figure 8-18** Creating a User-Defined FIR Filter Using the FIR Filter Table Editor

Mode > Dual ARB > Arb Setup > More > Real-Time Modulation Filter > Define User FIR > More 1 of 2 > Delete All Rows > Confirm Delete of All Rows

For details on each key, use key help as described on [page 34](#).




Opens a menu that enables you to select and load a saved file into volatile memory. See [page 35](#).

[page 205](#)

Adds a column for specifying the imaginary coefficients of the filter. (All of the imaginary coefficients will be 0 initially.) If the Convert to Complex Filter softkey has been selected the Convert to Real Filter softkey becomes available.

Caution: Selecting the Convert to Real Filter softkey removes the Imaginary Values column and the imaginary values are lost.

Active only when: FIR filter coefficient table has minimum of two values visible.



#### Note:

Modulation filters must be real and have an oversample ratio (OSR) of 2 or greater. Equalization filters are typically complex and must have an oversample ratio (OSR) of 1.

### Entering the Coefficient Values

1. Press the **Return** softkey to get to the first page of the table editor.
2. Use the cursor to highlight the Value field for coefficient 0.

3. Use the numeric keypad to type the first value (–0.000076) from [Table 8-3](#). As you press the numeric keys, the numbers are displayed in the active entry area. (If you make a mistake, you can correct it using the backspace key.)
4. Continue entering the coefficient values from the table in step 1 until all 16 values have been entered.

**Table 8-3**

| Coefficient | Value     |
|-------------|-----------|
| 0           | –0.000076 |
| 1           | –0.001747 |
| 2           | –0.005144 |
| 3           | –0.004424 |
| 4           | 0.007745  |
| 5           | 0.029610  |
| 6           | 0.043940  |
| 7           | 0.025852  |

| Coefficient | Value     |
|-------------|-----------|
| 8           | –0.035667 |
| 9           | –0.116753 |
| 10          | –0.157348 |
| 11          | –0.088484 |
| 12          | 0.123414  |
| 13          | 0.442748  |
| 14          | 0.767329  |
| 15          | 0.972149  |

### Duplicating the First 16 Coefficients Using Mirror Table

In a windowed sinc function filter, the second half of the coefficients are identical to the first half in reverse order. The signal generator provides a mirror table function that automatically duplicates the existing coefficient values in the reverse order.

1. Press **Mirror Table**. The last 16 coefficients (16 through 31) are automatically generated and the first of these coefficients (number 16) highlights, as shown in [Figure 8-19 on page 201](#).

**Figure 8-19**

FIR table coefficient values, may be from the factory default values or entered by the user.

| FIR Values |                   | Oversample Ratio: 4, Length In Symbols: 8 |
|------------|-------------------|---|
| Coeff.     | Real Value        |   |
| 10         | -0.15734800       |   |
| 11         | -0.08848400       |   |
| 12         | 0.12341400        |   |
| 13         | 0.44274800        |   |
| 14         | 0.76732900        |   |
| 15         | 0.97214900        |   |
| 16         | <b>0.57214900</b> |   |
| 17         | 0.76732900        |   |
| 18         | 0.44274800        |   |
| 19         | 0.12341400        |   |

Use the Goto Row menu to move around and make changes to the FIR Values coefficient table.

For details on each key, use key help as described on [page 34](#).

## Setting the Oversample Ratio

---

**NOTE** Modulation filters are real and have an oversample ratio (OSR) of two or greater. Equalization filters are typically complex and must have an OSR of one (refer to “Using the Equalization Filter” on page 196 and to “Setting the Real-Time Modulation Filter” on page 208).

---

The oversample ratio (OSR) is the number of filter coefficients per symbol. Acceptable values range from 1 through 32; the maximum number of taps allowed by the table editor is 1024.

The actual limits on OSR, number of coefficients, and number of symbols depends on the feature with which the FIR is used. Refer to [Table 8-4](#).

**Table 8-4**

| Filter Type                                | Oversampling Ratio (OSR) | Number of Taps (Maximum) | Symbols/Coefficients (Maximum) |
|--|--------------------------|--------------------------|--------------------------------|
| Equalization <sup>a</sup>                  | 1                        | 256                      | --                             |
| ARB Custom Modulation <sup>b</sup>         | ≥ 2                      | --                       | 512/1024                       |
| Dual ARB Real-Time Modulation <sup>c</sup> | ≥ 2                      | --                       | 32/1024                        |

<sup>a</sup>When I/Q timing skew, I/Q delay, or the ACP internal I/Q channel optimization features are active, the effective number of taps for the equalization filter are reduced.

<sup>b</sup>The filter may be sampled to a higher or lower OSR.

<sup>c</sup>The filter will be decimated to a 16 or lower OSR depending on the symbol rate.

For modulation filters, if the oversample ratio is different from the internal, optimally selected one, then the filter is automatically resampled to an optimal oversample ratio.

For this example, the desired OSR is 4, which is the default, so no action is necessary.

## Displaying a Graphical Representation of the Filter


The signal generator has the capability of graphically displaying the filter in both time and frequency dimensions.

1. Press **More 1 of 2 > Display Filter > Display FFT** (fast Fourier transform).

Refer to [Figure 8-20 on page 203](#).



Figure 8-20




For details on each key, use key help as described on page 34.

2. Press **Return**.
3. Press **Display Impulse Response**.

Refer to Figure 8-21.

Figure 8-21



For details on each key, use key help as described on page 34.

4. Press **Return** to return to the menu keys.

### Storing the Filter to Memory

Use the following steps to store the file.

1. Press **Load/Store > Store To File**. The catalog of FIR files appears along with the amount of memory available.
2. As described in [Storing, Loading, and Playing a Waveform Segment](#) on page 132, name and store this file as **FIR\_1**.

The **FIR\_1** file is the first file name listed. (If you have previously stored other FIR files, additional file names are listed below **FIR\_1**.) The file type is **FIR** and the size of the file is 260 bytes. The amount of memory used is also displayed. The number of files that can be saved depends on the size of the files and the amount of memory used. Refer to [Figure 8-22](#).

Figure 8-22

The screenshot shows a control panel with the following elements:

- FREQUENCY:** 6.000 000 000 00 GHz
- AMPLITUDE:** -144.00 dBm
- List Load/Store:** A menu with options: Load From Selected File, Store To File, Delete File, and Goto Row.
- Catalog of FIR Files in Int Storage:** A table with columns: File Name, Type, Size, and Modified. It shows three entries: FIR\_1, FIR\_2 (highlighted), and NEWFIR2.
- Status:** 36kB used, 29.2GB free.
- Footer:** 03/14/2012 14:15

A callout box on the right side of the interface states: "These keys manage the table of DMOD files in internal storage." An arrow points from this callout to the 'Delete File' and 'Goto Row' buttons.

Catalog displays FIR files that have been previously saved by the user.

For details on each key, use key help as described on page 34.

Memory is also shared by instrument state files and list sweep files.

This filter can now be used to customize a modulation format or it can be used as a basis for a new filter design.

## Modifying a FIR Filter Using the FIR Table Editor


FIR filters stored in signal generator memory can easily be modified using the FIR table editor. You can load the FIR table editor with coefficient values from user-defined FIR files stored in non-volatile memory or from one of the default FIR filters. Then you can modify the values and store the new files.

## Loading the Default Gaussian FIR File

Figure 8-23 Loading the Default Gaussian FIR File

Mode > Dual ARB > Arb Setup > More > Real-Time Modulation Filter

For details on each key, use key help as described on page 34.




1. Press **Preset**.
2. Press **Mode > Dual ARB > Arb Setup > More > Real-Time Modulation Filter > Define User FIR > More > Load Default FIR > Gaussian**.
3. Press **Filter BbT > 0.300 > Enter**.
4. Press **Filter Symbols > 8 > Enter**.
5. Press **Generate**.

**NOTE** The actual oversample ratio during modulation is automatically selected by the instrument. A value between 4 and 16 is chosen dependent on the symbol rate, the number of bits per symbol of the modulation type, and the number of symbols.

6. Press **Display Filter > Display Impulse Response** (refer to Figure 8-24).

Figure 8-24




For details on each key, use key help as described on page 34.

7. Press **Return**.

### Modifying the Coefficients

1. Using the front panel arrow keys, highlight coefficient 15.
2. Press **0 > Enter**.
3. Press **Display Impulse Response**.

Figure 8-25



For details on each key, use key help as described on page 34.

- Refer to **Figure 8-25**. The graphic display can provide a useful troubleshooting tool (in this case, it indicates that a coefficient value is missing, resulting in an improper Gaussian response).
4. Press **Return**.
  5. Highlight coefficient 15.
  6. Press **1 > Enter**.

## Storing the Filter to Memory

The maximum file name length is 23 characters (alphanumeric and special characters).

1. Press **Return** > **Return** > **Load/Store** > **Store To File**.
2. Name the file NEWFIR2.
3. Press **Enter**.

The contents of the current FIR table editor are stored to a file in non-volatile memory and the catalog of FIR files is updated to show the new file.

## Setting the Real-Time Modulation Filter


The real-time modulation filter effectively compresses a single carrier I/Q waveform down to just the I/Q constellation points and then controls the transitions similar to the modulation filter in Arb Custom modulation. The key difference is that this filter is applied as the waveform plays, rather than in the waveform data itself. The real-time modulation filter is only available for Dual ARB waveforms.

When the real-time modulation filter is on, the sample clock rate acts as the symbol rate. The sample clock rate must be set to one half of the sample rate for the real-time Arb modulation filter feature to be turned on. The sample rate is determined by the Option 65x baseband generator.

**CAUTION** Because the Arb format only supports rectangular I/Q data for defining the symbol decision points, constant envelope modulation, which should be specified as magnitude and phase, are not supported. (Examples of constant envelope modulation are MSK and FSK.)

The carrier frequency must be the same for all frequencies used (i.e. only single carrier applications work with arb real-time modulation filters).

Figure 8-26 Real-Time Modulation Filter Softkeys for the Dual ARB Player



Common uses for the real-time modulation feature include:

- Where the single carrier rectangular ideal I/Q symbol decision points are known and are to have an over-sampled filter applied.
- Where greater effective MXG/EXG memory size is required.
- When you have a low rate waveform that could benefit from a higher OSR that does not make the waveform longer.

The real-time modulation filter setup is one of the file header parameters (page 139), which means you can store this setup with the waveform. When you select a waveform with a stored modulation filter setup, the signal generator changes the current setup to match the stored file header setup. If there is no stored modulation filter setup for the current waveform, the signal generator uses the last set modulation filter setup.

You can also use the Save function (page 58) to store this value as part of the signal generator setup. When you Recall a setup stored with the Save function, the modulation filter value becomes the current instrument setting value, disregarding the stored file header value.

Use the following steps to apply a real-time modulation filter to the current waveform loaded into volatile memory. This example uses the factory supplied waveform, SINE\_TEST\_WFM available in the Dual ARB Player. To view the output for this example, connect the RF OUTPUT of the signal generator to the input of a spectrum analyzer.

---

**NOTE** The following setup assumes you have completed the setup in “Setting the Baseband Frequency Offset” on page 184 for creating a modulated RF signal that is offset from the carrier frequency by 20 MHz.

---

1. Configure the modulation filter:

Press **Mode > Dual ARB > Arb setup > More > Real-Time Modulation Filter > Select > Root Nyquist**

2. Press **Filter Alpha > .4 > Enter.**

The modulated RF signal now has a real-time modulation filter of type root nyquist, with a filter alpha of 0.400.


## Multiple Baseband Generator Synchronization

Available in the Dual ARB menu, this feature lets you set up a master/slave system of up to sixteen Agilent MXG/EXGs so that the baseband generators (BBG) synchronize the playing of waveforms. The system count includes one Agilent MXG/EXG to function as the master (see “Equipment Setup” on page 213).

The MXG/EXG with Option 012, enables 2x2, 3x3, or 4x4 MIMO configurations to share a common external LO signal to create phase coherent system. Refer to “Understanding Option 012 (LO In/Out for Phase Coherency) with Multiple Baseband Generator Synchronization” on page 216 and the *Data Sheet*.

**Figure 8-27 Multiple Baseband Generator Synchronization (BBG Synchronization) Trigger Softkeys and Menu Location**

**Note:** The BBG sync feature automatically configures the trigger settings shown below. To avoid a settings conflict error in this process, manually configure the trigger settings prior to setting the BBG sync parameters shown on [page 211](#).



For details on each key, use key help as described on [page 34](#).



Figure 8-28 Multiple BBG Synchronization Front Panel Displays

Mode > Dual ARB > Arb Setup > More >  
Multi-BBG Sync Setup

Master Display and Available Softkeys

Master/slave indicator and setup diagram.

Master shows one of the following messages:

- Out of Sync
- In Sync

Shows after pressing **Sync Slaves**

**Note:** Press only after pressing **Listen for Sync** on all slave instruments and the slaves show "Waiting For Sync" as the status.

Slave Display and Available Softkeys

Master/slave indicator and setup diagram. The bottom slave indicator is green on the last slave in the system.

Slave shows one of the following messages:

- Out of Sync
- Waiting for Sync
- In Sync

Shows after pressing **Listen for Sync**

Shows after pressing **Sync Slaves** on the master

**Note:** Press before pressing **Sync Slaves** on the master instrument.

For details on each key, use key help as described on page 34.

## Understanding the Master/Slave System

### System Delay

The multiple BBG synchronization feature provides a system for synchronizing the waveform generation capability of up to 16 signal generators to within a characteristic value of  $\pm 8$  ns between the master and the last slave. This minor amount of delay ( $\pm 8$  ns) can be reduced further to picosecond resolution by using the **I/Q Delay** softkey located in the **I/Q** menu. To reduce the delay, check and adjust the BBG signal alignment for each signal generator in the system. For more information on adjusting the delay, see “[I/Q Adjustments](#)” on page 192.

The delay value includes compensation for cables that have less than 1 ns of propagation delay between the **EVENT 1** and **PAT TRIG** connectors (see [Equipment Setup](#)). The recommended cable is an Agilent BNC cable, part number 10502A. The use of cables with greater propagation delay may not allow the signal generators to properly synchronize.

### System Synchronization

Synchronization occurs after the master signal generator sends a one-time event pulse that propagates through and to each slave in the system. Prior to this event, each slave must recognize that it is waiting for this event pulse, which occurs during the system configuration (see “[Configuring the Setup](#)” on page 213). In order to properly send the synchronization pulse, the trigger source and the Dual ARB Player for each signal generator must be turned off.

The master/slave setup does *not* incorporate a feedback system between the slaves and the signal generator selected as the master. After synchronization, if changes occur to the Multi-BBG Sync Setup menu or a signal generator is added to the system, the master does not automatically resynchronize the setup. This may cause the signal generators in the system to incorrectly report their status as In Sync.

The system can also misinterpret other signals as the synchronization pulse, which results in an incorrect In Sync status. These types of signals include a continuous trigger or an active Marker routed to the EVENT 1 connector. Improperly connected rear panel cables can also create a false status.

You must resynchronize the entire system after making any change in one or all of the Multi-BBG Sync Setup menus, after adding a signal generator to the system, or in doubt as to the true status of a signal generator. Changes to parameters that are outside of the Multi-BBG Sync Setup menu such as waveform files, Dual ARB state, sample rate, scaling, carrier frequency or amplitude have no effect on the system synchronization. To resynchronize a system, see “[Making Changes to the Multiple Synchronization Setup and Resynchronizing the Master/Slave System](#)” on page 215.

### System Trigger Setup

The multiple BBG synchronization feature restricts the trigger selections (see [page 210](#)) for each signal generator. For signal generators selected as slaves, you can only modify the trigger type (with restrictions). The trigger source is fixed and set to receive a trigger through the rear panel **PAT TRIG** connector. On the master, you can change both the trigger type (with restrictions) and the trigger source. The trigger source provides three options for triggering the waveforms: external trigger, front panel **Trigger** key, or the GPIB trigger.

If the trigger settings are other than what the BBG synchronization feature supports, the feature changes the trigger settings to what is shown on [page 210](#). When this change occurs, the Agilent MXG/EXG generates a settings conflict error to alert you to the changes. To avoid the error

generation, appropriately configure the trigger settings prior to selecting a signal generator as the master or slave.


The system trigger propagates in the same manner as the synchronization pulse initiated by the master (see [System Synchronization](#)). So if it is not turned off during changes to the synchronization parameters, it can cause a false In Sync status.

The signal generator does not reset the trigger parameters when the multiple BBG synchronization feature is turned off. To play waveforms after disabling the feature, you must either set the trigger type to **Free Run** or provide a trigger to start the waveform play back.

## Equipment Setup

**Figure 8-29 Multiple Baseband Synchronization Setup**

**Note:** To minimize synchronization delay, the Agilent BNC cable 10502A is the recommended cable for the rear panel daisy chain connections (see [page 212](#)).



## Configuring the Setup

### Set the Common Parameters

Perform the following steps on all signal generators:

1. Set the frequency of the carrier signal.
2. Set the power level of the carrier signal.
3. Select the desired waveform (see [page 132](#)).

Do *not* turn the Dual ARB on.

4. Except for triggering, set the desired waveform parameters such as markers and sample clock.

The baseband synchronization feature limits the trigger selections for both the master and slaves. If the current trigger settings include unsupported BBG synchronization parameters, the Agilent MXG/EXG generates a settings conflict error and changes the trigger settings. To avoid the settings conflict error, manually set the trigger parameters as shown on [page 210](#) prior to setting the multiple BBG synchronization parameters.

5. Turn on the RF Output.

#### Set the BBG Synchronization Master Parameters

1. Press **Mode** > **Dual ARB** > **ARB Setup** > **More** > **Multi-BBG Sync Setup** > **Multi-Bbg Sync Type** > **Master**.
2. Set the number of slaves using the **Number of Slaves** softkey.
3. If desired, modify the trigger parameters (see [page 210](#)).

The master signal generator allows the modifications of both the trigger type and the trigger source.

- a. Return to the Dual ARB menu (see [page 210](#)).
- b. Set the desired trigger type and source.
- c. Return to the **Multi-BBG Sync Setup** menu.

#### Set the BBG Synchronization Slave Parameters

1. Press **Mode** > **Dual ARB** > **ARB Setup** > **More** > **Multi-BBG Sync Setup** > **Multi-BBG Sync Type** > **Slave**.
2. Set the number of Slaves using the **Number of Slaves** softkey.
3. Set the slave position that the signal generator occupies.

There can be up to fifteen slaves in a system.

4. Press the **Listen for Sync** softkey and verify that Waiting for Sync appears in the Status area of the display.
5. If desired, select a different trigger type parameter:
  - a. Return to the Dual ARB menu (see [page 210](#)).
  - b. Set the desired trigger type.
  - c. Return to the **Multi-BBG Sync Setup** menu.
6. Repeat for each slave signal generator in the system.

#### Synchronize the System

Perform this procedure only after setting the parameters for both the master and slave signal generators. If resynchronizing a system, use the procedure “[Making Changes to the Multiple Synchronization Setup and Resynchronizing the Master/Slave System](#)” on [page 215](#).

1. On the master, press the **Sync Slaves** softkey.

---

**NOTE** All of the signal generators in the master/slave system must be resynchronized when any changes are made to the master/slave settings or with the addition of a slave instrument, even if In Sync appears after pressing the **Listen for Sync** softkey on the slave instruments.

---

2. On the front panel displays, ensure that all of the signal generators show In Sync as the Status.

### Trigger and Play the Waveform

1. On all Agilent signal generators, press **Mode > Dual ARB > ARB Off On** to On.
2. Start the trigger signal going to the master signal generator.

## Making Changes to the Multiple Synchronization Setup and Resynchronizing the Master/Slave System

If any changes are made to the master/slave parameters or a signal generator (slave unit) is added to the system, the system must be resynchronized even if In Sync appears in the Status portion of the display.

1. Turn off the trigger source. If using the **Trigger** key, there is nothing to turn off.  
If the trigger source is on and provides a continuous pulse stream, it may cause the signal generators to incorrectly display In Sync as the status after pressing the **Listen for Sync** softkey.
2. On each of the signal generators, press **Mode > Dual ARB > ARB Off On** to Off.  
If a signal generator(s) has the Dual ARB on during changes, signal generators further in the chain may incorrectly display In Sync after pressing the **Listen for Sync** softkey.
3. On each of the signal generators, press **ARB Setup > More > Multi-BBG Sync Setup**.
4. Make the changes in the Multi-BBG Sync Setup menu.  
Out Of Sync appears as the status message.
5. On each of the slave signal generators, press **Listen for Sync**.
6. Ensure that all of the slaves' Status show Waiting for Sync. If In Sync shows as the status, perform the following steps:
  - a. Check that the **PATT TRIG** to **EVENT 1** cables are properly connected on the rear panel.  
A disconnected cable can cause a false In Sync status.
  - b. If the cables are connected, perform steps 1 and 2.
  - c. Press **Listen for Sync** and ensure that Waiting for Sync appears as the status.
7. On the master signal generator, press **Sync Slaves**.
8. Verify that In Sync appears as the status on all master/slave signal generators.
9. Perform the process “[Trigger and Play the Waveform](#)” on page 215.

## Understanding Option 012 (LO In/Out for Phase Coherency) with Multiple Baseband Generator Synchronization

---

**NOTE** This section assumes that the previous section on Multiple Baseband Generator Synchronization has been read and understood. If not, refer to “[Multiple Baseband Generator Synchronization](#)” on page 209 before continuing.

---

The MXG/EXG with Option 012, enables 2x2, 3x3, or 4x4 MIMO configurations to share a common external LO signal to create a phase coherent system (refer also, to “[Multiple Baseband Generator Synchronization](#)” on page 209).

RF phase coherency may *not* be needed for general STC/MIMO receiver testing, since a MIMO receiver perceives any phase differences between the sources as part of the channel conditions and correct for them. But, RF phase coherency might be desirable for certain applications such as R&D on beamforming systems.

### Configuring the Option 012 (LO In/Out for Phase Coherency) with MIMO

The Agilent BNC cable, part number 10502A, is the recommended cable for the standard multi-BBG synchronization setup, and is recommended for Option 012 too (see also [Figure 8-29 on page 213](#)). Additionally, for the 2x2, 3x3, and 4x4 MIMO connections from the LO IN and LO OUT to the splitter, additional cables are required (refer to [Table 8-5](#), [Figure 8-30 on page 218](#), and [Figure 8-31 on page 219](#)).

---

**NOTE** Agilent recommends the LO Output be covered when not in use.

When the LO In/Out jumper cable is removed and the instrument is in Dual ARB mode, the instrument is unlevelled and the instrument displays an Unlevel error message.

All test equipment requires a 12 hour warm-up period to ensure accurate performance.

---

The phase coherent configuration requires the following:

- The recommended LO input drive level should be in the 0 to 6 dBm range.

---

**NOTE** The 0 to 6 dBm LO input drive level ensures the instruments will operate over the full frequency and over the full 0 to 55 ambient temperature range<sup>1</sup>.

---

- The I/Q calibration and the self-test must be performed with the LO In/Out jumper cable in place. Where the I/Q calibration cannot be run, the baseband offset can be manually adjusted to minimize the I/Q offsets.
- The phase coherency feature only applies to the Dual ARB modulation mode.
- All cables from the splitter output to the instrument inputs should be of equal lengths.

---

<sup>1</sup>LO input power requirements vary with temperature; power <0 dBm may work at 20–30 degree ambient temperature conditions. Refer to the *Data Sheet*.

**Table 8-5 Option 012 (LO In/Out for Phase Coherency) Equipment**

| MIMO Configuration | Part <sup>a</sup> | Cable Length        | Notes  |
|--------------------|-------------------|---------------------|--|
| 2x2                | n/a               | As required         | SMA flexible cables are connected from the power splitter outputs to the LO inputs on the rear panel of both the master and the slave MXG/EXGs. Refer to <a href="#">Figure 8-30 on page 218</a> . |
|                    | 11636A            | n/a                 | Power Divider, DC to 18 GHz. Refer to <a href="http://www.agilent.com">www.agilent.com</a> .   |
| 3x3                | n/a               | As required         | SMA flexible cables are connected from the power splitter outputs to the LO inputs on the rear panel of the slave MXG/EXGs. Refer to <a href="#">Figure 8-31 on page 219</a> .                     |
|                    | PS3-20-451/12 S   | n/a                 | 3-Way Pulser Microwave Corp., 3-Way Wilkinson Dividers   |
| 4x4                | n/a               | As required         | The SMA flexible cables are connected to the power splitter output to the LO inputs on the rear panel of the slave MXG/EXGs. Refer to <a href="#">Figure 8-31 on page 219</a> .                    |
|                    | PS4-16-452/10 S   | n/a                 | 4-Way Pulser Microwave Corp., 4-Way Wilkinson Dividers   |
| All                | 10502A            | 22.86 cm (9 inches) | Refer to <a href="#">Figure 8-30 on page 218</a> and <a href="#">Figure 8-31 on page 219</a> . See also "Multiple Baseband Generator Synchronization" on page 209.                                 |


<sup>a</sup>On all of the MIMO configurations, the same length of SMA flexible cables are connected from the splitter output to the inputs on the master and slave instruments. Refer to [Figure 8-30 on page 218](#) and to [Figure 8-31 on page 219](#).

## 2x2 MIMO (LO In/Out for Phase Coherency) Configuration

For the 2x2 MIMO (LO In/Out for phase coherency) setup, the LO from the master MXG/EXG can be run through a power splitter and used as the LO input to both the master and the slave signal generators. No external source is required.

To generate phase coherent signals for a 2x2 MIMO configuration, the master MXG LO OUT is connected via a power splitter to the slave LO IN. The LO OUT provides a sufficient amplitude LO signal when connected directly, to drive the Slave MXG/EXG(s), thus providing phase coherency for the RF output signals. In this example, we show two MXG signal generators with Option 012 connected for a phase coherent 2x2 MIMO solution. Refer to [Figure 8-30](#).

**Figure 8-30 2x2 MIMO (LO In/Out for Phase Coherency) Equipment Setup**



### Note:

To optimize the phase coherence, the same length SMA flexible cable is recommended for the *output* of the 2-way splitter connections to the LO IN of the signal generator with Option 012 (see [page 216](#)).

To minimize synchronization delay, the Agilent BNC cable 10502A is the recommended cable for the rear panel daisy chain connections on the EVENT 1 and PAT TRIG BNC connectors (see [page 216](#)).

## 3x3 and 4x4 MIMO (LO In/Out for Phase Coherency) Configurations

For a 3x3 and 4x4 MIMO (LO In/Out for phase coherency) setups, an additional analog source is needed to provide the higher LO power required by the power splitter and the additional instruments.

Splitting the LO output four ways causes too much loss to drive the LO input of the N5172B/82Bs in the system. Also, there is no amplitude adjustment to the LO output of the N5172B/82B. To generate phase coherent signals for 3x3 and 4x4 configurations with the MXG/EXG, an external Master LO is needed to provide a sufficient amplitude LO input signal to the vector MXG/EXGs (refer to [Figure 8-31 on page 219](#)).

---

**NOTE** The Master LO is *not* controlled by any of the *Signal Studio* software, but must be set *manually*—via the RF frequency settings on the master signal generator—by the user to the desired frequency and amplitude.

---




**Figure 8-31 3x3 and 4x4 MIMO (LO In/Out for Phase Coherency) Equipment Setup**

**Note:**

A SMA flexible cable is recommended for the *input* to the 4-way splitter connections to the LO IN and LO OUT of the instruments with Option 012 (see [page 216](#)).

To optimize the phase coherence, the same length SMA flexible cable is recommended for the *output* of the 4-way splitter connections to the LO IN of the instruments with Option 012 (see [page 216](#)).


To minimize synchronization delay, the Agilent BNC cable 10502A is the recommended cable for the rear panel daisy chain



## Real-Time Applications

The Agilent X-Series signal generators provide access to several real-time applications for signal creation.

**Figure 8-32 Real-Time Applications Softkeys**



For details on each key, use key help as described on page 34.

## Waveform Licensing

Waveform licensing enables you to license waveforms that you generate and download from any Signal Studio application for unlimited playback in a signal generator. Each licensing option (221-229) allows you to permanently license up to five waveforms or (250-259) allows you to permanently license up to 50 waveforms of your choice (i.e. Waveform Option 22x or Option 25x are *perpetual fixed* waveform licenses).

Waveforms licensed with Options 221-229 or Options 250-259 cannot be exchanged for different waveforms. Once a waveform is licensed, that license is permanent and cannot be revoked or replaced. Option 22x and 25x waveform licenses are signal generator specific (i.e. signal generator serial number specific). If a licensed Option 22x or Option 25x waveform file is transferred to another signal generator, the file must be licensed by a separate Option 22x or Option 25x that is in the other signal generator *before* it can be played.

To redeem Option 22x or Option 25x, refer to the *N5182B-2xx Entitlement Certificate* that comes with the N5182B-2xx order. For more information on extracting and downloading waveform files, refer to the *Programming Guide*.

## Understanding Waveform Licensing

Use any N76xxB Signal Studio software to build and download waveforms to the signal generator. Each Option 22x provides 5 available slots and Option 25x license provides 50 available slots, where you can add and play waveforms for a trial period of 48 hours per slot. During this time, you can replace the waveform any number of times until you are satisfied with it. After the trial period expires, the waveform in the slot is no longer playable until the slot is locked for permanent playback; however, you can replace the waveform in the slot with another waveform of your choice before locking the slot.

To license additional waveforms that exceed the number permitted by an Option 22x or Option 25x, you must purchase another Option 22x or Option 25x that you do *not* already own. For example, if you already own Option 250, purchase Option 251 to add an additional 50 slots. Adding all options, 250-259, provides a maximum of 500 slots. Adding all options, 221-229, provides a maximum of 45 slots. (Repurchasing the same option for the *same* signal generator, gives you no additional Waveform licenses.)

## Installing an Option N5182-22x or Option N5182B-25x

Load a Waveform License, Option N5182-22x or Option N5182B-25x, into the signal generator using License Manager or a USB media. For more information on loading the Waveform License, refer to the *N5182B-2xx Entitlement Certificate* included with your order.

## Licensing a Signal Generator Waveform

Create and download a waveform into the signal generator using any of the N76xxB Signal Studio software. Refer to your Signal Studio software help if you need assistance using the application.

Refer to [page 226](#) for steps in adding the waveform to a license slot for a 48-hour trial period. During the trial period, the waveform can be played and replaced any number of times. When the trial time expires, the slot can no longer be used for playback until the slot is locked for permanent playback capability.

## Waveform Licensing Softkeys Overview

**Figure 8-33 Waveform Licensing Softkeys**  
Mode > Dual ARB > More

**Note: Waveforms licensed with Option 2xx cannot be exchanged for other waveforms. Once a waveform is locked into a license slot, that license is permanent and cannot be revoked or replaced.**

This softkey is only available if there is an Option 2xx license installed on the instrument. Pressing this softkey displays the licensing status and associated filename for each slot and accesses the waveform licensing menu selections.

**Note:** When Waveform Licensing is first accessed, all slots appear as **Available**. For licensing status descriptions after waveforms have been added to a slot, refer to [Table 8-6 on page 225](#).

| Waveform Slot | Status                     | Filename                 | Licenses Used: 2/50 |
|---------------|----------------------------|--------------------------|---------------------|
| 1             | Remaining Trial Time 47:42 |                          |                     |
| 2             | Remaining Trial Time 47:54 | 802_11AC_160MHZ_256Q.WFM |                     |
| 3             | Available                  |                          |                     |
| 4             | Available                  |                          |                     |
| 5             | Available                  |                          |                     |
| 6             | Available                  |                          |                     |
| 7             | Available                  |                          |                     |
| 8             | Available                  |                          |                     |
| 9             | Available                  |                          |                     |
| 10            | Available                  |                          |                     |

**UFI Licensing** menu options:

- Add Waveform To First Available Slot:** This softkey allows you to add a waveform that you select to the first available slot. Refer to [page 223](#).
- Replace Waveform In Slot:** This softkey allows you to replace a waveform in the selected slot. Refer to [page 224](#).
- Clear Waveform From Slot:** This softkey clears the waveform from the selected slot.
- Lock Waveform In Slot:** This softkey allows you to lock a waveform into a slot. After the trial period has expired, the waveform must be locked in order to be able to play the waveform. Refer to [page 224](#).
- Goto Slot:** This softkey allows you to select a specific slot where you want to add, replace, or clear a waveform. You can also select a slot by using the front panel arrow keys or by scrolling to the slot. Refer to [page 223](#).

Refer to the SCPI Command Reference for related license commands.

For details on each key, use key help as described on [page 34](#).


**Figure 8-34 Waveform Licensing Softkeys**

Mode > Dual ARB > More >  
Waveform Licensing > Add  
Waveform to First Available Slot

or

Mode > Dual ARB > More >  
Waveform Licensing > Replace  
Waveform in Slot

**Note: Waveforms licensed with Option 2xx cannot be “exchanged”. Once a slot is locked, that license for the waveform in the locked slot is permanent and cannot be revoked or replaced.**




The softkey is greyed out, if a waveform is already licensed or does not require licensing.

To select a waveform, use the arrow keys to highlight the waveform and then press **Add Waveform**.

Refer to the SCPI Command Reference for related License Commands.

The waveform to be added or replaced can be selected from BBG memory, internal storage, or a USB device.



This softkey displays a catalog of the waveform segments stored in the **Int Storage** or **USB Media**.

This softkey displays a catalog of the waveforms stored in the **BBG** memory.

For details on each key, use key help as described on [page 34](#).

**Figure 8-35 Waveform Licensing Softkeys**

**Mode > Dual ARB > More > Waveform Licensing  
> Lock Waveform in Slot**

|                          |  |
|--------------------------|--|
| <b>Lock In Slot</b>      | Press this softkey to confirm that you want to lock the waveform into the slot for permanent licensing. If the waveform has not been saved to internal storage, a warning message appears. Refer to <a href="#">Step 4 on page 227</a> .   |
| Confirm Locking Waveform |  |
|                          | This softkey is displayed if the waveform is not found in the internal storage memory of the signal generator. Press this softkey to store the waveform into the Internal Storage and to activate the <b>Confirm Locking Waveform</b> softkey. Refer to <a href="#">Step 4 on page 227</a> . |

**Mode > Dual ARB > More > Waveform Licensing > Goto Slot** — Refer to the SCPI Command Reference for related license commands.

|                           |  |
|---------------------------|--|
| <b>Goto Slot</b>          |  |
| Enter                     | Press this softkey after entering a specific slot number using the front panel numeric pad.  |
| Goto First Slot           | Press this softkey to go to the first slot.  |
| Goto First Available Slot | Press this softkey to go to the first slot whose status is available.  |
| Goto Last Slot            | Press this softkey to go to the last slot. The number of slots depends on the number of licensing options installed on the instrument. |

**Mode > Dual ARB > More > Waveform Licensing > More > More**

|                           |                            |                          |                           |
|---------------------------|----------------------------|--------------------------|---------------------------|
| FREQUENCY                 |                            | RF OFF                   | WFF Licensing             |
| 6.000 000 000 00 GHz      |                            | -144.00 dBm              | Play Waveform             |
| Waveform Licensing Status |                            |                          | Locate Waveform in Memory |
| Slot                      | Filename                   | Licenses Used: 2/50      |                           |
| 1                         | Remaining Trial Time 46:20 |                          |                           |
| 2                         | Locked 03/15/2012          | 802_11AC_160MHZ_2560.WFF |                           |
| 3                         | Available                  |                          |                           |
| 4                         | Available                  |                          |                           |
| 5                         | Available                  |                          |                           |
| 6                         | Available                  |                          |                           |
| 7                         | Available                  |                          |                           |
| 8                         | Available                  |                          |                           |
| 9                         | Available                  |                          |                           |
| 10                        | Available                  |                          |                           |
| 03/15/2012 16:28          |                            |                          | More 2 of 2               |

For details on each key, use key help as described on [page 34](#).

**Table 8-6 Waveform Licensing Slot Status Messages**

| Status Column              | Meaning  | Notes  |
|----------------------------|--|--|
| Available                  | The slot has never had a waveform added to it.   | 50 slots are initially available for each Option 25x.<br>5 slots are initially available for each Option 22x.  |
| Locked MM/DD/YY            | The slot is locked and can no longer be modified.  | The waveform in this slot is licensed to this signal generator for unlimited playback.   |
| Remaining Trial Time HH:MM | The slot is in a trial period that is available for 48 hours that begins when a waveform is added. | During the trial period, the waveform in this slot can be played, cleared, or replaced with another waveform.  |
| Lock Required              | The trial period for the slot has expired but the slot has not been locked.                        | The slot can be cleared or replaced with a different waveform but the waveform cannot be played until the slot is locked. A trial period is no longer available. |

**Example: Licensing a Signal Studio Waveform**

The following steps add a waveform file to a license slot and lock the slot for permanent playback.



1. Press **Mode > Dual ARB > More > Waveform Utilities > Waveform Licensing**

The signal generator displays a catalog of files labeled: Catalog of BBG Segment Files in BBG Memory.

2. Use the arrow keys to highlight and select the file to be licensed.
3. Press **Add Waveform** to add the selected waveform to the first available slot.

**Figure 8-36 Add Waveform**  
Mode > Dual ARB > More > Waveform Licensing > Add Waveform to First Available Slot

Status area for the waveform N7602B-WFM1 is empty and the **Add Waveform** softkey is active, indicating the waveform is licensable.



The selected waveform is added to the first available slot. The trial time for the slot begins as soon as the waveform is added.

During the 48 hour trial period, the waveform can be played and replaced any number of times.

When the trial time expires, the licensing status of the slot changes to **Lock Required** after which the waveform can no longer be played until the slot is locked.



4. License the waveform:

- a. Press **Lock Waveform in Slot**.

A warning is displayed: **\*\*\* Waveform Lock Warning!!! \*\*\***. *If necessary, verify you have selected the correct waveform you want for licensing by pressing **Return**.*

**Figure 8-37 Waveform Lock Warning**




- b. Press **Confirm Locking Waveform**.

The licensing status of the slot will be changed to Locked MM/DD/YY.

- c. If the waveform has not been previously backed up in internal storage, a warning is displayed: **\*\*\* Waveform Backup Required!!! \*\*\***.
- d. Make a backup copy of this waveform on a USB media or a computer before pressing **Backup Waveform to Int Storage**. *(If the waveform is lost or deleted on the signal generator, it cannot be recovered).*


**Figure 8-38 Backup Waveform To Int Storage softkey**



**CAUTION** It is important that you make a *backup* copy of any waveforms that you are licensing. *Do not store the backup copy on the signal generator. If all copies of the waveforms are deleted or lost, there is no way to recover the waveform or reassign the license.* Refer to [“Working with Files” on page 50](#).

### Waveform Licensing Warning Messages

Figure 8-39



This standard warning is displayed every time a waveform is selected to be locked. This notification indicates that one of the available "license slots" is about to be used from Option 2xx.

**ALWAYS make backup copies of waveforms in a separate non-volatile memory in case a file is deleted or lost from the instrument's internal storage.**

This warning is displayed when an attempt is made to lock a waveform that has *not* been saved to internal storage or USB media (i.e. waveforms cannot be locked unless they have been stored to non-volatile memory). Press the **Backup Waveform To Int Storage** softkey.

This warning is displayed when there is insufficient memory or other problems with the internal storage, or USB media (non-volatile memory) and the waveform could not be saved to non-volatile memory.

This warning is displayed when the waveform file cannot be found in BBG or internal storage. You must ensure that the waveform still resides in the instrument before you can lock it.

---

## 9 Adding Real–Time Noise to a Signal (Option 403)

Before using this information, you should be familiar with the basic operation of the signal generator. If you are not comfortable with functions such as setting the power level and frequency, refer to [Chapter 3, “Basic Operation,” on page 33](#) and familiarize yourself with the information in that chapter.

This feature is available only in Agilent X-Series vector signal generators with Option 431. Option 431 requires Option 653 or 655 (N5172B) or Option 656 or 657 (N5182B).

This chapter contains examples of using the additive white gaussian noise (AWGN) waveform generator, which is available only in vector signal generators with Option 403.

- [Adding Real–Time Noise to a Dual ARB Waveform](#) on page 229
- [Using Real Time I/Q Baseband AWGN](#) on page 235

### Adding Real–Time Noise to a Dual ARB Waveform

---


**NOTE** The procedures in this section that pertain specifically to adding Real–Time Noise (AWGN) to a waveform, are applicable to the Custom ARB, Multitone, and Two–Tone modulation standards too.

---

A vector signal generator with option 403 enables you to apply additive white gaussian noise (AWGN) to a carrier in real time while the modulating waveform plays in the dual ARB waveform player. This feature appears in each of the arb formats and as a stand–alone menu (Refer to [Figure 9-7 on page 235](#)).

Figure 9-1 Real Time I/Q Baseband AWGN Softkeys

For details on each key, use key help as described on page 34.



**Figure 9-2 Real Time I/Q Baseband AWGN - Power Control Mode Softkeys**  
 Mode > Dual ARB > Arb Setup >  
 Real-Time AWGN Setup

For details on each key, use key help as described on [page 34](#).





Figure 9-6 on page 234 provides additional details on these settings.

— see [page 232](#)

Selecting **Total** as the power control mode makes the total power and C/N independent variables while making the carrier power and total noise power dependent variables. The dependent variables carrier power and total noise power are set by the total power, C/N, and the rest of the Noise settings. The carrier power and total noise power change as any noise parameter is adjusted to keep the total power and the C/N at their last specified values.




Selecting **Carrier** as the power control mode makes the carrier power and C/N independent variables while making the total power and total noise power dependent variables. The dependent variables total power and total noise power are set by the carrier power, C/N, and the rest of the Noise settings. The total power and total noise power change as any noise parameter is adjusted to keep the carrier power and the C/N at their last specified values.

Selecting **Total Noise** as the power control mode makes the total noise power and C/N independent variables while making the total power and carrier power dependent variables. The dependent variables total power and carrier power are set by the total noise power, C/N, and the rest of the Noise settings. The total power and carrier power change as any noise parameter is adjusted to keep the total noise power and the C/N at their last specified values.

**Figure 9-3 Real Time I/Q Baseband AWGN - Noise Mux Menu Softkeys**

Mode > Dual ARB > Arb Setup >  
 Real-Time AWGN Setup > More




### $E_b/N_0$ Adjustment Softkeys for Real Time I/Q Baseband AWGN

This feature allows the AWGN C/N to be set using the  $E_b/N_0$  (energy per bit over noise power density at the receiver or signal to noise ratio per bit) form. This requires the carrier bit rate to be known. Refer to Figure 9-4, “ $E_b/N_0$  Carrier Bit Equation.”

**Figure 9-4  $E_b/N_0$  Carrier Bit Equation**

$$\frac{C}{N_{dB}} = \left(\frac{E_b}{N_0}\right) dB + 10\log_{10}\left(\frac{bitRate}{carrierBandwidth}\right)$$

**Figure 9-5 Real Time I/Q Baseband AWGN -  $E_b/N_0$  Adjustment Softkeys**  
 Mode > Dual ARB > Arb Setup > Real-Time AWGN Setup



Display remains grayed out until real-time AWGN is enabled.

$E_b/N_0$  is displayed when **Carrier to Noise Ratio Format** softkey is set to  $E_b/N_0$ .

Eb/No(rate=1.000 bps): 0.00 dB

The **Carrier Bit Rate** softkey sets the carrier bit rate. (The default carrier bit rate is 1 bps.)



The **Carrier Bit Rate** softkey is only available when the **Carrier to Noise Ratio Format** Softkey is set to  $E_b/N_0$ .

To view the carrier bit rate equation, refer to [page 34](#).

Figure 9-6 on page 234 provides additional details on these settings.

Selects either the Carrier to Noise Ratio (C/N) or energy per bit over noise power density at the receiver ( $E_b/N_0$ ) as the variable controlling the ratio of the carrier power to noise power in the carrier bandwidth. When  $E_b/N_0$  is selected, the second page of the AWGN Setup menu shows the **Carrier Bit Rate** softkey to enable the  $E_b/N_0$  value to be calculated.

The active softkey changes with the Carrier to Noise Ratio Format selected (C/N or  $E_b/N_0$ ). See below.



Whether a softkey is available depends on the **Carrier to Noise Ratio Format** softkey setting (e.g. C/N or  $E_b/N_0$ ).

C/N selected


Carrier to Noise Ratio 0.00 dB

Eb/No 0.00 dB

$E_b/N_0$  selected

For details on each key, use key help as described on [page 34](#).

Figure 9-6 Carrier to Noise Ratio Components



### Example

Use the following steps to modulate a 1 GHz, -10 dBm carrier with the factory-supplied waveform SINE\_TEST\_WFM, and then apply noise with a 45 MHz bandwidth signal that has a 30 dB carrier-to-noise ratio across a 40 MHz carrier bandwidth.


1. Preset the signal generator and set the following:
  - Frequency: 1 GHz
  - Amplitude: -10 dBm
  - RF output: on
2. Select the factory-supplied waveform SINE\_TEST\_WFM:
  - a. Press **Mode** > **Dual ARB** > **Select Waveform**.
  - b. Highlight SINE\_TEST\_WFM and press **Select Waveform**.
3. Turn on the dual ARB player: press **ARB Off On** to highlight On.
4. Set the ARB sample clock to 50 MHz: Press **ARB Setup** > **ARB Sample Clock** > **50** > **MHz**.
5. Press **Real-Time AWGN Setup** and set the following:
  - Carrier to Noise Ratio: 30 dB
  - Carrier Bandwidth: 40 MHz
  - Noise Bandwidth: 45 MHz
  - Real-time AWGN: on

The signal generator's displayed power level (-10 dBm) *includes* the noise power.



## Using Real Time I/Q Baseband AWGN

Figure 9-7 Real Time I/Q Baseband AWGN Softkeys



For details on each key, use key help as described on page 34.

Use the following steps to apply 10 MHz bandwidth noise to a 500 MHz, -10 dBm carrier.

1. Configure the noise:
  - a. Preset the signal generator.
  - b. Press **Mode** > **More** > **Real-Time AWGN**
  - c. Press **Bandwidth** > **10** > **MHz**.

2. Generate the noise:

Press **Real-Time AWGN Off On** until On highlights.

During generation, the AWGN and I/Q annunciators activate (as shown at right). AWGN is now available to modulate the RF carrier.

| FREQUENCY          | AMPLITUDE    |
|--------------------|--------------|
| 500.000 000 00 MHz | -10.00 dBm   |
| I/Q                | AWGN         |
| Ampld: -10.00 dBm  | Incr: 1.00dB |

3. Configure the RF output:

- Frequency: 500 MHz
- Amplitude: -10 dBm
- RF output: on

The carrier with AWGN is now available at the signal generator's RF OUTPUT connector.



---

# 10 Real-Time Phase Noise Impairments (Option 432)

Before using this information, you should be familiar with the basic operation of the signal generator. If you are not comfortable with functions such as setting the power level and frequency, refer to [Chapter 3, “Basic Operation,” on page 33](#) and familiarize yourself with the information in that chapter.

This feature is available only in Agilent X-Series vector signal generators with Option 431. Option 431 requires Option 653 or 655 (N5172B) or Option 656 or 657 (N5182B).


This chapter contains the softkey maps to locate the Phase Noise Impairment option functions and information on the use of this feature.

- [Real-Time Phase Noise Impairment](#) on page 238
- [The Agilent X-Series Phase Noise Shape and Additive Phase Noise Impairments](#) on page 239
- [Understanding the Phase Noise Adjustments](#) on page 241
- [DAC Over-Range Conditions and Scaling](#) on page 242

## Real-Time Phase Noise Impairment

This feature lets you degrade the phase noise performance of the signal generator by controlling two frequency points and an amplitude value. The signal generator adds this phase noise to the phase noise normally produced by the signal generator. This feature appears in each of the arb formats and as a stand-alone menu. While the following figure shows how to access the controls using both the stand-alone menu and the Dual ARB player, the location and softkeys within each arb format is the same as for the Dual ARB player.


Figure 10-1 Stand-Alone and Dual ARB Player Real-Time Phase Noise Softkeys



For details on each key, use key help as described on page 34.

## The Agilent X-Series Phase Noise Shape and Additive Phase Noise Impairments

### Phase Noise Plots Without Phase Noise Impairment




The Agilent X-Series vector signal generator demonstrates a definitive shape to its phase noise plot. The mid-frequency offsets are characterized by a leveling (flattening) of the phase noise amplitude from approximately a 3 kHz offset to approximately a 70 kHz offset.

Close in and far out offsets demonstrate sloping characteristics (areas before and after the mid-frequency offsets).


The signal generator degrades the phase noise by moving the mid-frequency characteristics and/or changing its amplitude using the following settings:

- Start frequency ( $f_1$ ) of the mid-frequency characteristics
- Stop frequency ( $f_2$ ) of the mid-frequency characteristics
- Amplitude ( $L_{mid}$ ) of the mid-frequency characteristics




This is a plot of the unmodified phase noise shape that shows the location that each value alters.

**Phase Noise Plots With Phase Noise Impairments**



When turned on, this phase noise is added to the base phase noise of the signal generator.

Even though it is only the mid-frequency characteristics placement that are modified, these changes affect the entire phase noise shape. The close in and far out offset characteristics change by exhibiting approximately a 20 dBc/Hz slope for each octave of frequency offset.




The resultant phase noise plot shown on the left has the following settings:

- $f_1 = 100 \text{ Hz}$
- $f_2 = 1 \text{ kHz}$
- Amplitude ( $L_{mid}$ ) =  $-70 \text{ dBc}$

Ensure that the  $f_1$  value is less than or equal to  $f_2$ . If not,  $f_2$  changes its value to match  $f_1$ . Conversely if  $f_2$  is set to a value that is less than  $f_1$ ,  $f_1$  changes its value to match  $f_2$ .

The frequency values entered for the impairments may not be the exact values when viewed on the RF output. The entered values are guidelines that the signal generator uses to calculate the real values. See [“Understanding the Phase Noise Adjustments” on page 241](#) for more information.

To view the results of the settings ( $f_1$ ,  $f_2$ , and  $L_{mid}$ ), use the front panel graph (below and on [page 238](#)) or view the phase noise plot on a measurement instrument (shown above—Agilent E4440A PSA with Option 226).



Signal generator front panel plot:

- $f_1 = 100 \text{ Hz}$
- $f_2 = 1 \text{ kHz}$
- $L_{mid} = -70 \text{ dBc}$

## Understanding the Phase Noise Adjustments


The signal generator bases the resultant phase noise shape on three settings, Lmid (amplitude), f1 (start frequency), and f2 (stop frequency).

The range for Lmid is coupled to f2, so as f2 increases in value, Lmid's upper boundary decreases. If the current Lmid setting is too high for the new f2 setting, the signal generator changes the Lmid value and generates an error to alert you to the change. In addition, the actual Lmid value can vary by 0.28 dBc/Hz from the entered value.

The frequency settings (f1 and f2) are really guidelines that the signal generator uses to calculate the real frequency offset values seen on the RF OUTPUT. This means that the entered start and stop frequency values are an approximation and may not be the values seen on a measurement instrument, however they will be close.

The effects of the f1 and f2 parameters are based on a varying logarithmic scale. This scale is determined by the f2 value. The higher the f2 value the larger the scale, which makes this behavior more noticeable at higher frequency settings. This becomes apparent when a change in the f1 or f2 value causes little to no change in the f1 or f2 position. This is easy to view using the signal generator's front panel phase noise graph and demonstrated in Figure 10-2. This behavior makes the frequency adjustments coarser as the f2 frequency value increases.

Figure 10-2 f1 and f2 Frequency Setting Behavior



For details on each key, use key help as described on page 34.


The only way to make an accurate determination of the effect of the f1 and f2 values is by viewing the front panel graph or making a measurement. You can view the front panel graph remotely by using the LXI interface. For more information on the LXI interface, see the *Programming Guide*.

## DAC Over-Range Conditions and Scaling

When using phase noise impairment, it is possible to create a DAC over-range condition, which causes the signal generator to generate an error. To minimize this condition with the phase noise impairment feature, the Agilent X-Series signal generator incorporates an automatic DAC over-range protection feature that scales down the I/Q data. Because it can scale the data by more than what is actually need, it typically decreases the dynamic range of the waveform. This is especially noticeable when using a constant amplitude signal such as GSM.

For the Dual ARB Player, the automatic over-range protection can be turned off (on is the factory default). The control for the Dual ARB DAC over-range protection feature is located in the key path as shown in [Figure 10-3](#).

**Figure 10-3 Dual ARB DAC Over-Range Protection Softkey Location**



For details on each key, use key help as described on [page 34](#).

In the Dual ARB Player, to avoid excessive scaling or to just perform scaling manually, turn the over-range protection off and use the **Waveform Runtime Scaling** softkey to eliminate DAC over-range conditions.

When the automatic feature is disabled, the other options to eliminate a DAC over-range condition are to reduce the  $f_2$  value, or the  $L_{mid}$  value, or both until the condition corrects itself.



---

# 11 Custom Digital Modulation (Option 431)

Before using this information, you should be familiar with the basic operation of the signal generator. If you are not comfortable with functions such as setting the power level and frequency, refer to [Chapter 3, “Basic Operation,” on page 33](#) and familiarize yourself with the information in that chapter.

This feature is available only in Agilent X-Series vector signal generators with Option 431. Option 431 requires Option 653 or 655 (N5172B) or Option 656 or 657 (N5182B).

- [Custom Modulation](#) on page 244
- [Creating and Using Bit Files](#) on page 252
- [Using Customized Burst Shape Curves](#) on page 258
- [Using the Arbitrary Waveform Generator](#) on page 265
- [Using Finite Impulse Response \(FIR\) Filters with Custom Modulation](#) on page 281
- [Modifying a FIR Filter Using the FIR Table Editor](#) on page 287
- [Differential Encoding](#) on page 290

## Custom Modulation

For creating custom modulation, the signal generator offers two modes of operation: the ARB custom modulation mode and the real-time custom modulation mode. The ARB custom modulation mode has built-in modulation formats such as NADC or GSM and pre-defined modulation types such as BPSK and 16QAM that can be used to create a signal. It also provides the flexibility to modify the digital format's attributes. The real-time custom modulation mode can be used to create custom data formats using built-in PN sequences or custom-user files along with various modulation types and different built-in filters such as Gaussian or Nyquist.

Both modes of operation are used to build complex, digitally modulated signals that simulate communication standards with the flexibility to modify existing digital formats, define or create digitally modulated signals, and add signal impairments.

### ARB Custom Modulation Waveform Generator

The signal generator's ARB Custom Modulation mode is designed for out-of-channel test applications. This mode can be used to generate data formats that simulate random communication traffic and can be used as a stimulus for component testing. Other capabilities of the ARB Custom Modulation mode include:

- configuring single or multicarrier signals. Up to 100 carriers can be configured.
- creating waveform files using the signal generator's front panel interface.

The waveform files, when created as random data, can be used as a stimulus for component testing where device performance such as adjacent channel power (ACP) can be measured. The `AUTOGEN_WAVEFORM` file, that is automatically created when you turn the ARB Custom Modulation on, can be renamed and stored in the signal generator's non-volatile memory. This file can later be loaded into volatile memory and played using the dual ARB waveform player.


For more information, refer to [“Waveform File Basics” on page 130](#) and [“Modes of Operation” on page 4](#).

### Real-Time Custom Modulation Waveform Generator

The real-time mode simulates single-channel communication using user-defined modulation types along with custom FIR filters, and symbol rates. Data can be downloaded from an external source into PRAM memory or supplied as real-time data using an external input. The real-time I/Q baseband mode can also generate pre-defined data formats such as PN9 or FIX4. A continuous data stream generated in this mode can be used for receiver bit error analysis. This mode is limited to a single carrier. The real-time custom modulation mode:

- has more data and modulation types available than the ARB waveform generator mode
- supports custom I/Q constellation formats
- has the capability to generate continuous PN sequences for bit error rate testing (BERT)
- needs no waveform build time when signal parameters are changed.

**Figure 11-1 ARB Custom Modulation Softkeys**



For details on each key, use key help as described on page 34.

**Figure 11-2 Quick Setup Softkeys**





Figure 11-3 Mod Type Softkeys



For details on each key, use key help as described on page 34.

**Figure 11-4 Custom Modulation Formats and Applications**

| Modulation format | Application where used  |
|-------------------|---|
| MSK, GMSK         | GSM, CDPD   |
| BPSK<br>QPSK      | Deep space telemetry, cable modems<br>Satellite, CDMA, NADC, TETRA, PHS, PDC, LMDS,<br>DVB-S, cable (return path), cable modems, TFTS |
| OQPSK<br>FSK      | CDMA, satellite<br>DECT, paging, RAM mobile data, AMPS, CT2,<br>ERMES, land mobile radio, public safety                               |
| 8, 16 VSB         | North American digital TV (ATV), broadcast, cable   |
| 8PSK              | Satellite, aircraft   |
| 16 QAM            | Microwave digital radio, modems, DVB-C, DVB-T   |
| 32 QAM            | Terrestrial microwave, DVB-T  |
| 64 QAM            | DVB-C, modems, broadband set top boxes, MMDS  |
| 256 QAM           | Modems, DVB-C (Europe), Digital Video (US)  |


**Figure 11-5 Store Custom Dig Mod State Softkeys**

Mode > ARB Custom Modulation > Single Carrier Setup > Store Custom Dig Mod State

The screenshot shows the 'Store Custom Dig Mod State' screen. At the top, the frequency is 6.000 000 000 00 GHz and the amplitude is -144.00 dBm. Below this is a 'Catalog of DMOD Files in Int Storage' with the following details: 36kB used, 29.2GB free. The catalog contains one file: '1 FIR\_EXAM' of Type 'DMOD', Size '832 B', and Modified '02/20/12 14:12'. The 'Store State' panel on the right includes softkeys: 'Store To File', 'Delete File', 'Goto Row', and 'Confirm Delete'. A callout box for 'Confirm Delete' shows 'Confirm Delete' and 'Goto Row' options. A callout box for 'Goto Row' shows 'Enter', 'Goto Top Row', 'Goto Middle Row', and 'Goto Bottom Row' options. A note at the bottom states: 'Catalog displays digital modulation (DMOD) files that have been previously saved.'


For details on each key, use key help as described on [page 34](#).

Figure 11-6 Real-Time Custom Modulation Softkeys



For details on each key, use key help as described on page 34.


Figure 11-7 Modulation Setup Softkeys



For details on each key, use key help as described on page 34.



Figure 11-8 Modulation Type Softkeys



For details on each key, use key help as described on page 34.

## Creating and Using Bit Files

This procedure teaches you how to use the Bit File Editor to create, edit, and store user-defined files for data transmission within real time I/Q baseband generated modulation. For this example, a user file is defined within a custom digital communications format.

User files (user-defined data files) can be created on a remote computer and moved to the signal generator for subsequent modification, or they can be created and modified using the signal generator's Bit File Editor.


These user files can then be transmitted data as a continuous unframed data stream according to the protocol of the active format, transmitted as the data for a custom ARB modulation or real-time format. User files are not available for signals generated by the dual ARB waveform generator.

---

**NOTE** For information on creating user-defined data files on a remote computer, see the *Agilent Signal Generators Programming Guide*.

---

**Figure 11-9 Data Selection Softkeys**




## Creating a User File

### Accessing the Table Editor

1. Press **Presets**.
2. Press **Mode > Real-Time Custom Modulation > Modulation Setup > Data > User File > Create File**.

This opens the Bit File Editor. The Bit File Editor contains three columns: Offset, Binary Data, and Hex Data, as well as cursor position (Position) and file name (Name) indicators, as shown in the following figure.

Figure 11-10 Bit File Display



---

**NOTE** When you create new file, the default name appears as UNTITLED, or UNTITLED1, and so forth. This prevents overwriting previous files.


---

### Entering Bit Values

Bit data is entered into the table editor in 1-bit format. The current hexadecimal value of the binary data is shown in the Hex Data column, and the cursor position (in hexadecimal) is shown in the Position indicator.

1. Refer to the following figure.
2. Enter the 32 bit values shown.

Figure 11-11 Entering Bit Values



## Renaming and Saving a User File

In this example, you learn how to store a user file. If you have not created a user file, complete the steps in the previous section, “Creating a User File” on page 253.

1. Press **More (1 of 2) > Rename > Editing Keys > Clear Text.**
2. Enter a file name (for example, USER1) using the alpha keys and the numeric keypad.
3. Press **Enter.**

The user file has now been renamed and stored to the Bit memory catalog with the name USER1.

## Recalling a User File

In this example, you learn how to recall a user-defined data file from the memory catalog. If you have not created and stored a user-defined data file, complete the steps in the previous sections, “Creating a User File” on page 253 and “Renaming and Saving a User File” on page 255.

1. Press **Preset**.
2. Press **Mode > Real-Time Custom Modulation > Modulation Setup > Data > User File**.
3. Highlight the file USER1.
4. Press **Edit File**.

The Bit File Editor opens the file USER1.

## Modifying an Existing User File


In this example, you learn how to modify an existing user-defined data file. If you have not created, stored, and recalled a user-defined data file, complete the steps in the previous sections, “Creating a User File” on page 253, “Renaming and Saving a User File” on page 255 and “Recalling a User File” on page 256.

### Navigating the Bit Values

1. Press **Return > Goto > 4 > C > Enter**.

This moves the cursor to bit position 4C in the table, as shown in the following figure.

Figure 11-12 Navigating the Bit Values




Cursor moves to new position

### Inverting Bit Values

1. Press **1011**.

This inverts the bit values that are positioned 4C through 4F. Notice that hex data in this row has now changed to 76DB6DB6, as shown in the following figure.

Figure 11-13 Inverting Bit Values



### Applying Bit Errors to a User File

In this example, you learn how to apply bit errors to a user-defined data file. If you have not created and stored a user-defined data file, complete the steps in the previous sections, “Creating a User File” on page 253 and “Renaming and Saving a User File” on page 255.

1. Press **Apply Bit Errors**.
2. Press **Bit Errors > 5 > Enter**.
3. Press **Apply Bit Errors**.

Notice both **Bit Errors** softkeys change value as they are linked.

## Using Customized Burst Shape Curves

You can adjust the shape of the rise time curve and the fall time curve using the Rise Shape and Fall Shape editors. Each editor allows you to enter up to 256 values, equidistant in time, to define the shape of the curve. The values are then resampled to create the cubic spline that passes through all of the sample points.


The Rise Shape and Fall Shape table editors are available for custom real-time I/Q baseband generator waveforms.

### Understanding Burst Shape

The default burst shape of each format is implemented according to the standards of the format selected. You can, however, modify the following aspects of the burst shape:

|                          |   |
|--------------------------|---|
| Rise time                | the period of time, specified in symbols or bits, where the burst increases from a minimum of $-70$ dB (0) to full power (1).   |
| Fall time                | the period of time, specified in symbols or bits, where the burst decreases from full power (1) to a minimum of $-70$ dB (0).   |
| Rise delay               | the period of time, specified in symbols or bits, that the start of the burst rise is delayed. Rise delay can be either negative or positive. Entering a delay other than zero shifts the full power point earlier or later than the beginning of the first useful symbol.  |
| Fall delay               | the period of time, specified in symbols or bits, that the start of the burst fall is delayed. Fall delay can be either negative or positive. Entering a delay other than zero shifts the full power point earlier or later than the end of the last useful symbol.   |
| User-defined burst shape | up to 256 user-entered values which define the shape of the curve in the specified rise or fall time. The values can vary between 0 (no power) and 1 (full power) and are scaled linearly. Once specified, the values are resampled as necessary to create the cubic spline that passes through all of the sample points. |






Burst shape maximum rise and fall time values are affected by the following factors:

- the symbol rate
- the modulation type

When the rise and fall delays equal 0, the burst shape is attempting to synchronize the maximum burst shape power to the beginning of the first valid symbol and the ending of the last valid symbol of the timeslot. The following figure illustrates a bursted signal in an EDGE frame with a rise delay of 0 and a fall delay of +1 bit.




pk743b

The signal generator firmware computes optimum burst shape based on the settings you've chosen for modulation. You can further optimize burst shape by lining up the data portion with the modulation. For example, if you're designing a new modulation scheme, do the following:

- Adjust the modulation and filtering to set the spectrum you want.
- Adjust the burst rise and fall delay and rise and fall time for the timeslots.

If you find that the error vector magnitude (EVM) or adjacent channel power (ACP) increases when you turn bursting on, you can adjust the burst shape to assist with troubleshooting.

**Figure 11-14 Burst Shape Softkeys**



For details on each key, use key help as described on [page 34](#).

## Creating a User-Defined Burst Shape Curve

Using this procedure, you learn how to enter rise shape sample values and mirror them as fall shape values to create a symmetrical burst curve.

This section teaches you how to perform the following tasks:

- “[Accessing the Table Editors](#)” on [page 261](#)
- “[Entering Sample Values](#)” on [page 262](#)

### Accessing the Table Editors

1. Press **Preset**.
2. Press **Mode > Real-Time Custom Modulation > Burst Shape**.
3. Press **More > Define User Burst Shape > More (1 of 2) > Delete All Rows > Confirm Delete Of All Rows**.

### Entering Sample Values

Use the sample values in the following table.

| Rise Shape Editor |          |        |          |
|-------------------|----------|--------|----------|
| Sample            | Value    | Sample | Value    |
| 0                 | 0.000000 | 4      | 0.830000 |
| 1                 | 0.400000 | 5      | 0.900000 |
| 2                 | 0.600000 | 6      | 1.000000 |
| 3                 | 0.750000 |        |          |

1. Highlight the value (1.000000) for sample 1.
2. Press **.4** > **Enter**.
3. Press **.6** > **Enter**.
4. Enter the remaining values for samples 3 through 6 from the table above.
5. Press **Return** > **Edit Fall Shape** > **Load Mirror Image of Rise Shape** > **Confirm Load Mirror Image Of Rise Shape**.

This changes the fall shape values to a mirror image of the rise shape values, as shown in [Figure 11-15 on page 262](#).

**Figure 11-15 Mirror Image of Rise Shape**

The screenshot shows the 'Rise Shape Editor' and 'Fall Shape Editor' side-by-side. The 'Rise Shape Editor' has samples 0-7 with values 0.000000, 0.400000, 0.600000, 0.750000, 0.830000, 0.900000, 1.000000, and a dashed line for sample 7. The 'Fall Shape Editor' has samples 0-7 with values 1.000000, 0.900000, 0.830000, 0.750000, 0.600000, 0.400000, 0.000000, and a dashed line for sample 7. The interface also shows frequency (6.000 000 000 00 GHz), dBm (-144.00), and navigation buttons like 'Load/Store', 'Load Mirror Image of Rise Shape', 'Delete All Rows', and 'Display Burst Shape'.


| Rise Shape Editor (UNSTORED) |          | Fall Shape Editor (UNSTORED) |          |
|------------------------------|----------|------------------------------|----------|
| Sample                       | Value    | Sample                       | Value    |
| 0                            | 0.000000 | 0                            | 1.000000 |
| 1                            | 0.400000 | 1                            | 0.900000 |
| 2                            | 0.600000 | 2                            | 0.830000 |
| 3                            | 0.750000 | 3                            | 0.750000 |
| 4                            | 0.830000 | 4                            | 0.600000 |
| 5                            | 0.900000 | 5                            | 0.400000 |
| 6                            | 1.000000 | 6                            | 0.000000 |
| 7                            | -----    | 7                            | -----    |

## Display the Burst Shape

Press **Display Burst Shape**.

This displays a graphical representation of the waveform's rise and fall characteristics, as shown in [Figure 11-16](#).

**Figure 11-16 Burst Shape**



To return the burst to the default conditions, press the following keys:

**Return > Return > Return > Confirm Exit From Table Without Saving > Restore Default Burst Shape.**

## Storing a User-Defined Burst Shape Curve

1. Press **Define User Burst Shape > More (1 of 2) > Load/Store > Store To File**.

If there is already a file name from the Catalog of SHAPE Files occupying the active entry area, press the following keys:

**Editing Keys > Clear Text**

2. Enter a file name (for example, NEWBURST) using the alpha keys and the numeric keypad.  
The maximum file name length is 23 characters (alphanumeric and special characters).
3. Press **Enter**.

The contents of the current Rise Shape and Fall Shape table editors are stored to the Catalog of SHAPE Files. This burst shape can now be used to customize a modulation or as a basis for a new burst shape design.

## Recalling a User-Defined Burst Shape Curve

Once a user-defined burst shape file is stored in memory, it can be recalled for use with real-time I/Q baseband generated digital modulation.

This example requires a user-defined burst shape file stored in memory. If you have not created and stored a user-defined burst shape file, complete the steps in the previous sections, [“Creating a User-Defined Burst Shape Curve” on page 261](#) and [“Storing a User-Defined Burst Shape Curve” on page 263](#).

1. Press **Preset**.


2. Press **Mode > Real-Time Custom Modulation > Burst Shape > Burst Shape Type > User File.**
3. Highlight the desired burst shape file (for example, NEWBURST).
4. Press **Select File.**

The selected burst shape file is now applied to the current real time I/Q baseband digital modulation state.

## Using the Arbitrary Waveform Generator

This section teaches you how to build dual arbitrary (ARB) waveform files containing custom digital modulation for testing component designs.

**Figure 11-17 Adding Custom Modulation to a Waveform**



For details on each key, use key help as described on [page 34](#).

## Using Predefined Custom Digital Modulation

This section teaches you how to perform the following tasks:

- [Selecting a Predefined EDGE Setup](#) on page 265
- [Generating the Waveform](#) on page 265
- [Configuring the RF Output](#) on page 266

### Selecting a Predefined EDGE Setup

1. Press **Preset**.
2. In the ARB Custom Modulation menu ([page 265](#)), press **Single Carrier Setup** > **Quick Setup** > **EDGE**.

### Generating the Waveform

Press **Digital Modulation Off On**.

This generates a waveform with the pre-defined EDGE state selected in the step. The display changes to Dig Mod Setup: EDGE. During waveform generation, the DIGMOD and I/Q annunciators appear and the pre-defined digital modulation state is stored in volatile memory (BBG). The waveform is now modulating the RF carrier.

### **Configuring the RF Output**

1. Set the RF output frequency to 891 MHz.
2. Set the output amplitude to -5 dBm.
3. Press **RF On/Off**.

The predefined EDGE signal is now available at the signal generator's RF OUTPUT connector.






**Figure 11-19 Modifying a Digital Modulation Type**

Mode > ARB Custom Modulation > Single Carrier Setup > Modulation Type > Select

For details on each key, use key help as described on [page 34](#).



This section teaches you how to perform the following tasks:

- [Selecting a Digital Modulation Setup](#) on page 268
- [Configuring the RF Output](#) on page 266
- [Selecting the Filter](#) on page 269
- [Configuring the RF Output](#) on page 266

### Selecting a Digital Modulation Setup

1. Press **Preset**.
2. In the ARB Custom Modulation menu ([page 267](#)), press **Single Carrier Setup > Quick Setup > NADC**.

### Modifying the Modulation Type and Symbol Rate

1. In the ARB Custom Modulation menu ([page 267](#)), press **Single Carrier Setup > Modulation Type > Select > PSK > QPSK and OQPSK > QPSK**.
2. Press **Return > Symbol Rate > 56 > ksp/s**.

### Selecting the Filter

1. In the Setup Mod menu ([page 267](#)), press **Filter > Select > Nyquist**.
2. Press **Return > Return**.

### Generating the Waveform

Press **Digital Modulation Off On**.

This generates a waveform with the custom, single-carrier NADC, digital modulation state created in the previous sections. The display changes to Dig Mod Setup: NADC (Modified). During waveform generation, the DIGMOD and I/Q annunciators appear and the custom single-carrier digital modulation state is stored in volatile memory. The waveform is now modulating the RF carrier.

For instructions on storing this custom, single-carrier NADC, digital modulation state to the non-volatile memory catalog, see [Storing a Custom Digital Modulation State](#) on page 269.

### Configuring the RF Output

1. Set the RF output frequency to 835 MHz.
2. Set the output amplitude to 0 dBm.
3. Press **RF On/Off**.

The user-defined NADC signal is now available at the RF OUTPUT connector.

### Storing a Custom Digital Modulation State

Using this procedure, you learn how to store a custom digital modulation state and a custom multicarrier digital modulation state to non-volatile memory.

If you have not created a custom, single-carrier, digital modulation state, complete the steps in the previous section, [Creating a Custom Digital Modulation State](#) on page 267.




## Recalling a Custom Digital Modulation State

Using this procedure, you will learn how to recall a custom digital modulation state from signal non-volatile memory.

If you have not created and stored a user-defined, single-carrier, digital modulation state, complete the steps in the previous sections, [Creating a Custom Digital Modulation State](#) on page 267 and [Storing a Custom Digital Modulation State](#) on page 269, then preset the signal generator to clear the stored user-defined, digital modulation waveform from volatile ARB memory.

**Figure 11-21** Recalling a Custom Digital Modulation State

Mode > ARB Custom Modulation > Single Carrier Setup > Quick Setup



1. In the Quick Setup menu, press **Custom Digital Mod State**.
2. Highlight the desired file (for example, NADCQPSK).
3. Press **Select File > Return**.
4. Press **Digital Modulation Off On** until On is highlighted.

The instrument regenerates the custom, digital modulation waveform in volatile memory. After waveform generation, the custom, digital modulation waveform is available to be modulated on the RF output.

For instruction on configuring the RF output, see [Configuring the RF Output](#) on page 266.

## Defining a Modulation

You can build a unique modulation by utilizing two tools, the FSK table editor or the I/Q table editor. These tables map data onto specific absolute modulation states. To map transitions between states, a differential table editor is provided.

### Building an Asymmetric FSK Modulation with the FSK Table Editor

You can use the FSK table editor to create customized asymmetric FSK modulation of up to 16 levels, then apply the custom FSK modulation to one of the modulation standards. An example of this capability is to create an interfering signal for adjacent channel selectivity testing of FLEX™ pagers. To do this, build a 4-level FSK modulation at 4.8 kHz and 1.6 kHz in the FSK table editor, shown in [Figure 11-22](#). Then use this signal to modulate a PN15 data transmission. In the FLEX™ protocol, each of the levels in 4-level FSK represents a 2-bit sequence.



### Create a Continuous 4-Level FSK Signal

Use this procedure to create a 4-level FSK signal for adjacent channel testing of FLEX™ pagers.

1. Press **Preset** on the signal generator.
2. Press **Mode > Real-Time Custom Modulation > Modulation Setup > Modulation Type > Define User FSK**.
3. Enter the frequency deviations shown in [Figure 11-22](#) into the FSK table editor.
4. Store the file as 4FSK. Press **Load/Store > Store To File > 4FSK > Enter**.
5. Load the file. Press **Load from Selected File > Confirm Load From File**.
6. Turn on Custom Modulation. Press **Return > Return > Return > Real-Time Custom On**.
7. Set the Frequency to the desired carrier frequency for the adjacent channel.
8. Set the desired Amplitude.
9. Press **RF On**. The amplitude of the interferer can then be adjusted to measure the performance of the device under test.

Figure 11-22 FSK Table Editor

Mode > Real-Time Custom Modulation > Modulation Setup > Modulation Type > Define User FSK




For details on each key, use key help as described on [page 34](#).

### Mapping I/Q Values with the I/Q Table Editor

In most digital radio systems, the frequency of the carrier is fixed so only phase and magnitude need to be considered. The phase and magnitude of symbols can be represented as a discrete point in the I/Q plane. I represents "in phase" and Q represents "quadrature".

Figure 11-23 I/Q Constellation Diagram



By modulating the carrier to one of several predetermined positions in the I/Q plane, you can then transmit encoded information. Each position or state represents a certain bit pattern that can be decoded at the receiver. The mapping of the states at each symbol decision point on the I/Q plane is referred to as a constellation diagram. You can create a unique signal by mapping your constellation diagram into the I/Q table editor, shown in Figure 11-24. The table editor also has a display feature, which provides a quick visual check of the expected I/Q constellation.

Figure 11-24 I/Q Table Editor

Mode > Real-Time Custom Modulation > Modulation Setup > Modulation Type > Define User I/Q

|                      |         |             |  |                  |
|----------------------|---------|-------------|--|------------------|
| FREQUENCY            |         | AMPLITUDE   |  | User Mod Type    |
| 6.000 000 000 00 GHz |         | -144.00 dBm |  | Insert Row       |
| I/Q Values           |         |             |  |                  |
| Data                 | I Value | Q Value     |  |                  |
| 000000000            | -----   | -----       |  |                  |
|                      |         |             |  | Delete Row       |
|                      |         |             |  | Goto Row▶        |
|                      |         |             |  | Display I/Q Map▶ |
|                      |         |             |  |                  |
| 03/20/2012 19:01     |         |             |  | Page 1 of 2      |

For details on each key, use key help as described on page 34.



Utilizing this I/Q mapping flexibility, you can create unique modulation schemes. For example, a circular constellation arrangement called a STAR QAM is easily implemented and saved for later recall with the real-time I/Q baseband generator. Figure 11-25 shows that the STAR QAM has 16 states or symbols. Four data bits define each symbol. Thus, the diagram and the table are equivalents.

### Create a STAR QAM Modulation Scheme

1. Press **Preset** on the signal generator.
2. Press **Mode > Real-Time Custom Modulation > Modulation Setup > Modulation Type > Define User IQ.**
3. Enter the values shown in Figure 11-25 for I and Q using the numeric keypad and arrow keys. Press **Display IQ Map** to check your entry and adjust any entry errors.
4. Press **Return > Store To File > Clear Text.**
5. Turn on Custom Modulation. Press **Return > Return > Return > Real-Time Custom On.**
6. Name the file **STAR** and press **Enter.**
7. Load the file. Highlight **STAR** and press **Load from Selected File > Confirm Load From File.**
8. Turn on Custom Modulation. Press **Return > Return > Return > Return > Real-Time Custom On.**
9. Set the Frequency and Amplitude to the desired values.
10. Press **RF On.**

Figure 11-25 STAR QAM Diagram and Table





Figure 11-26 shows the X-Series setup and the I/Q display.

Figure 11-26 Custom Modulation and I/Q Display



### Hints for Constructing Modulations

- The map is limited to 16 total signal levels for I and Q combined. The readout on the right-hand side of the table tracks the number of I and Q levels utilized. Levels are I or Q values. Figure 11-27 shows an 8PSK signal built in two different ways. The 8PSK signal in Figure 11-27 utilizes five of the available sixteen I/Q values on the left, and utilizes four of the available sixteen I/Q values on the right.
- Following this example, the real-time I/Q baseband generator supports a symmetric 256QAM constellation but not an asymmetric 256QAM constellation, since the asymmetry requires more than sixteen I/Q values.
- The levels do not have to be equally spaced or symmetric in the I/Q plane. For example, the 16QAM modulations shown in Figure 11-28 are both possible.

Figure 11-27 8PSK Signal Built Two Ways





Figure 11-28 16QAM I/Q Map with Even and Uneven Levels




## Creating a Custom Multicarrier Digital Modulation State

In this procedure, you learn how to customize a predefined, multicarrier, digital modulation setup by creating a custom, 3-carrier EDGE, digital modulation state.

This section teaches you how to perform the following tasks:

- [Creating a Multicarrier Digital Modulation Setup](#) on page 279
- [Modifying Carrier Frequency Offset](#) on page 279
- [Modifying Carrier Power](#) on page 279
- [Generating the Waveform](#) on page 279
- [Configuring the RF Output](#) on page 279

Figure 11-29 Creating a Multicarrier Digital Modulation Setup



For details on each key, use key help as described on [page 34](#).

### Creating a Multicarrier Digital Modulation Setup

1. Press **Preset**.
2. Press **Mode > ARB Custom Modulation > Multicarrier Off On** to **On**.
3. Press **Multicarrier Setup > Select Carrier and Initialize Table > Carrier Setup > EDGE > Done**.

### Modifying Carrier Frequency Offset

1. Highlight the Freq Offset value (500.000 kHz) for the carrier in row 2.
2. Press **-625 > kHz**.

### Modifying Carrier Power

1. Highlight the Power value (0.00 dB) for the carrier in row 2.
2. Press **-10 > dB**.

You now have a custom 2-carrier EDGE waveform with a carrier at a frequency offset of -625 kHz and a power level of -10.00 dBm, as shown in the following figure.

For details on each key, use key help as described on page 34.

If Digital Modulation is already on, you must press Apply Multicarrier to apply the changes and generate a new custom multicarrier digital modulation waveform based on the updated values.

| FREQUENCY                         |         | AMPLITUDE    |           | Carrier Setup                       |  |
|-----------------------------------|---------|--------------|-----------|-------------------------------------|--|
| 6.000 000 000 00 GHz              |         | -144.00 dBm  |           | Select Carrier and Initialize Table |  |
| Multicarrier Setup: EDGE Carriers |         |              |           |                                     |  |
| Carrier Phases: Fixed             |         |              |           |                                     |  |
|                                   | Carrier | Freq Offset  | Power     | Insert Row                          |  |
| 1                                 | EDGE    | -500.000 kHz | 0.00 dB   | Delete Row                          |  |
| 2                                 | EDGE    | -625.000 kHz | -10.00 dB | Goto Row                            |  |
| 3                                 | -----   | -----        | -----     | Apply Multicarrier                  |  |
| 02/20/2012 15:08                  |         |              |           |                                     |  |
| More 1 of 2                       |         |              |           |                                     |  |

### Generating the Waveform

Press **Return > Digital Modulation Off On**.

This generates a waveform with the custom, multicarrier, EDGE state created in the previous sections. The display changes to Dig Mod Setup: Multicarrier (Modified). During waveform generation, the DIGMOD and I/Q annunciators appear and the new custom, multicarrier, EDGE state is stored in volatile memory. The waveform is now modulating the RF carrier.

For instructions on storing this custom, multicarrier, EDGE state to non-volatile memory, see “Storing a Custom Multicarrier Digital Modulation State” on page 280.

### Configuring the RF Output

1. Set the RF output frequency to 890.01 MHz.
2. Set the output amplitude to -10 dBm.
3. Press **RF On/Off**.

The custom multicarrier EDGE signal is now available at the RF OUTPUT connector.

## Storing a Custom Multicarrier Digital Modulation State

Using this procedure, you learn how to store a custom, multicarrier, digital modulation state to non-volatile memory.

If you have not created a custom, multicarrier, digital modulation state, complete the steps in the previous section, “Creating a Custom Multicarrier Digital Modulation State” on page 278.

Figure 11-30 Storing a Custom Multicarrier Softkeys

**Carrier Phases:** Fixed

| Carrier | Carrier | Freq Offset  | Power     |
|---------|---------|--------------|-----------|
| 1       | EDGE    | -500.000 kHz | 0.00 dB   |
| 2       | EDGE    | -625.000 kHz | -10.00 dB |
| 3       | -----   | -----        | -----     |

**Carrier Phases:** Fixed Random  
**Fixed:** All the carriers are set to a phase of 0.  
**Random:** All of the carriers are set to a random phase value.  
 Load/Store → page 35  
 For details on each key, use key help as described on page 34.

1. Return to the top-level Digital Modulation menu, where **Digital Modulation Off On** is the first softkey.
2. Press **Multicarrier Setup > More > Load/ Store > Store To File**.  
If there is already a file name from the Catalog of MDMOD Files occupying the active entry area, press the following key: **Clear Text**
3. Enter a file name (for example, EDGEM1) using the alpha keys and the numeric keypad with a maximum length of 23 characters.
4. Press **Enter**.

The user-defined, multicarrier, digital modulation state is now stored in non-volatile memory.

---

**NOTE** The RF output amplitude, frequency, and operating state settings are not stored as part of a user-defined, digital modulation state file.

---

## Applying Changes to an Active Multicarrier Digital Modulation State

If the digital modulation format is currently in use (**Digital Modulation Off On** set to On) while changes are made in the Multicarrier Setup table editor, you must apply the changes before the updated waveform will be generated.


From the Multicarrier Setup table editor, press **Apply Multicarrier** to apply the changes and generate a new custom multicarrier digital modulation waveform based on the updated values.

## Using Finite Impulse Response (FIR) Filters with Custom Modulation

Finite Impulse Response filters can be used to refine the transitions between symbol decision points of the generated waveforms.

**Figure 11-31 Filter Menu**

Mode > ARB Custom Modulation > Single Carrier Setup > Filter



For details on each key, use key help as described on page 34.

## Understanding FIR Filters

FIR filters are used to limit the bandwidth of the input to the I and Q modulators. Several different types of FIR filters exist. The NADC, PDC, PHS, and TETRA standards specify a root Nyquist filter in both the transmitter and the receiver. The combined response is equivalent to a Nyquist filter. The Nyquist filter has an impulse response that rings at the data clock rate so nulls appear at all symbol decision points except the desired one at the center of the impulse response. Since each symbol causes zero response at all undesired decision points, there can be no inter-symbol interference (ISI). The alpha term ( $\alpha$ ) defined for Nyquist-type filters identifies the frequency cutoff point where the filter response is zero. The closer the alpha term is to zero, the steeper the filter roll-off becomes. Alpha gives a direct measure of the occupied bandwidth of the system and is calculated as


$$\text{Occupied Bandwidth} = \text{Symbol Rate} \times (1 + \alpha)$$

The NADC and TETRA standards specify an alpha of 0.35. PDC and PHS standards specify an alpha of 0.50. For each of these standards, the Agilent X-Series signal generator provides a root Nyquist filter with the designated alphas as the default premodulation filter. Figure 11-32 shows the Nyquist impulse response for several values of alpha.

Notice that the half-amplitude point is always at the half-symbol rate. Since all of the information is contained within the half symbol rate bandwidth, alpha is a measure of the additional occupied bandwidth.

Another type of FIR filter, which is specified in the GSM and DECT standards, is the Gaussian filter. Gaussian filters typically have more inter-symbol interference than Nyquist filters, but their adjacent channel power performance is better for constant-amplitude modes like MSK, where Nyquist filtering of I and Q is not possible. The bandwidth bit time (BbT) product (similar to  $\alpha$ ) is defined by the GSM standard as 0.30 and by the DECT standard as 0.50. For each of these standards, the Agilent X-Series signal generator provides a Gaussian filter with the designated BbT product as the default premodulation filter.

Figure 11-32 Nyquist Filter Impulse Response



### Selecting a Filter and the Alpha ( $\alpha$ ) or Bandwidth Bit Time (Bbt) Product

Due to individual system design requirements, you may decide to change the filter or the filter  $\alpha$  or BbT. You can adjust the alpha from 0 to 1 and the BbT from 0.1 to 1.

To change the filter alpha:

1. Preset the instrument.
2. Press **Mode** > **Real-Time Custom Modulation** > **Modulation Setup** > **Filter** > **Select Nyquist** > **Filter Alpha**.
3. Enter a new value between 0 and 1. Press **Enter**.
4. To restore the default filter values, press **Restore Default Filter**.



**NOTE** To change the filter Bbt, press **Mode > Real-Time Custom Modulation > Modulation Setup > Filter > Select Gaussian > Filter Bbt**.

Enter a new value between 0.1 and 1.

## Creating a User-Defined FIR Filter Using the FIR Table Editor

In this procedure, you use the FIR Values table editor to create and store an 8-symbol, windowed sync function filter with an oversample ratio of 4.

### Accessing the Table Editor

1. Press **Preset**.
2. Press **Mode > ARB Custom Modulation > Single Carrier Setup > Filter > Select > Nyquist**.
3. Press **Filter > Define User FIR**.
4. Press **More 2 of 2 > Delete All Rows > Confirm Delete of All Rows**.

This will initialize the table editor as shown in [Figure 11-33](#).

**Figure 11-33** Creating a User-Defined FIR Filter Using the FIR Filter Table Editor

Mode > ARB Custom Modulation > Single Carrier Setup > Filter > Define User FIR > More > Delete All Rows > Confirm Delete of All Rows

For details on each key, use key help as described on [page 34](#).

Opens a menu that enables you to select and load a saved file into volatile memory. See [page 35](#).

page 199

Active only when:  
FIR filter coefficient table has minimum of two values visible.

Note:

Modulation filters are typically real and have an oversample ratio (OSR) of two or greater.

Equalization filters are typically complex and have an oversample ratio (OSR) of one (Dual ARB only).

### Entering the Coefficient Values

1. Press the **Return** softkey to get to the first page of the table editor.
2. Use the cursor to highlight the Value field for coefficient 0.
3. Use the numeric keypad to type the first value (–0.000076) from [Table 11-1](#). As you press the numeric keys, the numbers are displayed in the active entry area. (If you make a mistake, you can correct it using the backspace key.)
4. Continue entering the coefficient values from the table in step 1 until all 16 values have been entered.

**Table 11-1**

| Coefficient | Value     |
|-------------|-----------|
| 0           | –0.000076 |
| 1           | –0.001747 |
| 2           | –0.005144 |
| 3           | –0.004424 |
| 4           | 0.007745  |
| 5           | 0.029610  |
| 6           | 0.043940  |
| 7           | 0.025852  |

| Coefficient | Value     |
|-------------|-----------|
| 8           | –0.035667 |
| 9           | –0.116753 |
| 10          | –0.157348 |
| 11          | –0.088484 |
| 12          | 0.123414  |
| 13          | 0.442748  |
| 14          | 0.767329  |
| 15          | 0.972149  |


### Duplicating the First 16 Coefficients Using Mirror Table

In a windowed sinc function filter, the second half of the coefficients are identical to the first half in reverse order. The signal generator provides a mirror table function that automatically duplicates the existing coefficient values in the reverse order.

1. Press **Mirror Table**. The last 16 coefficients (16 through 31) are automatically generated and the first of these coefficients (number 16) highlights, as shown in [Figure 11-34 on page 285](#).

**Figure 11-34**

FIR table coefficient values, may be from the factory default values or entered by the user.



Use the Goto Row menu to move around and make changes to the FIR Values coefficient table.

For details on each key, use key help as described on [page 34](#).

### Setting the Oversample Ratio

**NOTE** Modulation filters must be real and have an oversample ratio (OSR) of two or greater.

The oversample ratio (OSR) is the number of filter coefficients per symbol. Acceptable values range from 1 through 32; the maximum combination of symbols and oversampling ratio allowed by the table editor is 1024. The instrument hardware, however, is actually limited to 32 symbols, an oversample ratio between 4 and 16, and 512 coefficients. So if you enter more than 32 symbols or 512 coefficients, the instrument is unable to use the filter. If the oversample ratio is different from the internal, optimally selected one, then the filter is automatically resampled to an optimal oversample ratio.

For this example, the desired OSR is 4, which is the default, so no action is necessary.


### Displaying a Graphical Representation of the Filter

The signal generator has the capability of graphically displaying the filter in both time and frequency dimensions.

1. Press **More > Display Filter > Display FFT** (fast Fourier transform).

Refer to [Figure 11-35 on page 286](#).

Figure 11-35




For details on each key, use key help as described on page 34.

2. Press **Return**.
3. Press **Display Impulse Response**.

Refer to Figure 11-36.

Figure 11-36



For details on each key, use key help as described on page 34.

4. Press **Return** to return to the menu keys.


### Storing the Filter to Memory

Use the following steps to store the file.

1. Press **Load/Store > Store To File**. The catalog of FIR files appears along with the amount of memory available.
2. As described in [Storing, Loading, and Playing a Waveform Segment](#) on page 132, name and store this file as **FIR\_1**.

The **FIR\_1** file is the first file name listed. (If you have previously stored other FIR files, additional file names are listed below **FIR\_1**.) The file type is **FIR** and the size of the file is 260 bytes. The amount of memory used is also displayed. The number of files that can be saved depends on the size of the files and the amount of memory used. Refer to [Figure 11-37](#).

Figure 11-37



Catalog displays FIR files that have been previously saved by the user.

For details on each key, use key help as described on [page 34](#).

Memory is also shared by instrument state files and list sweep files.

This filter can now be used to customize a modulation format or it can be used as a basis for a new filter design.

## Modifying a FIR Filter Using the FIR Table Editor


FIR filters stored in signal generator memory can easily be modified using the FIR table editor. You can load the FIR table editor with coefficient values from user-defined FIR files stored in non-volatile memory or from one of the default FIR filters. Then you can modify the values and store the new files.

## Loading the Default Gaussian FIR File

Figure 11-38 Loading the Default Gaussian FIR File

Mode > ARB Custom Modulation > Single Carrier Setup

For details on each key, use key help as described on page 34.



1. Press **Preset**.
2. Press **Mode > ARB Custom Modulation > Single Carrier Setup > Quick Setup > NADC**.
3. Press **Filter > Define User FIR > More 1 of 2 > Load Default FIR > Gaussian**.
4. Press **Filter BbT > 0.300 > Enter**.

5. Press **Filter Symbols > 8 > Enter**.
6. Press **Generate**.


---

**NOTE** The actual oversample ratio during modulation is automatically selected by the instrument. A value between 4 and 16 is chosen dependent on the symbol rate, the number of bits per symbol of the modulation type, and the number of symbols.

---

7. Press **Display Filter > Display Impulse Response** (refer to [Figure 11-39](#)).

**Figure 11-39 Impulse Response Display**




For details on each key, use key help as described on [page 34](#).

8. Press **Return**.

## Modifying the Coefficients

1. Using the front panel arrow keys, highlight coefficient 15.
2. Press **0 > Enter**.
3. Press **Display Impulse Response**.

**Figure 11-40 Impulse Response Display with Modified Coefficients**



For details on each key, use key help as described on [page 34](#).

Refer to [Figure 11-40 on page 289](#). The graphic display can provide a useful troubleshooting tool (in this case, it indicates that a coefficient value is missing, resulting in an improper Gaussian response).

4. Press **Return**.
5. Highlight coefficient 15.
6. Press **1 > Enter**.

### Storing the Filter to Memory

The maximum file name length is 23 characters (alphanumeric and special characters).

1. Press **Return > Load/Store > Store To File**.
2. Name the file NEWFIR2.
3. Press **Enter**.

The contents of the current FIR table editor are stored to a file in non-volatile memory and the catalog of FIR files is updated to show the new file.

### Differential Encoding


Differential encoding is a digital-encoding technique whereby a binary value is denoted by a signal *change* rather than a particular signal state. Using differential encoding, binary data in any user-defined I/Q or FSK modulation can be encoded during the modulation process via symbol table offsets defined in the Differential State Map.

For example, consider the signal generator's default 4QAM I/Q modulation. With a user-defined modulation based on the default 4QAM template, the I/Q Values table editor contains data that represent four symbols (00, 01, 10, and 11) mapped into the I/Q plane using two distinct values, 1.000000 and -1.000000. The following illustration shows the 4QAM modulation in the I/Q Values table editor.

| FREQUENCY             | AMPLITUDE    | User Mod Type                    |
|-----------------------|--------------|----------------------------------|
| 6.000 000 000 00 GHz  | -144.00 dBm  | Load/Store▶                      |
| I/Q Values (UNSTORED) |              | Load Default I/Q Map▶            |
| Data                  | I Value      | Q Value                          |
| 000000000             | 1.000000000  | 1.000000000                      |
| 000000001             | -1.000000000 | 1.000000000                      |
| 000000010             | -1.000000000 | -1.000000000                     |
| 000000011             | 1.000000000  | -1.000000000                     |
| 000000100             |              |                                  |
|                       |              | Delete All Rows▶                 |
|                       |              | Differential Encoding<br>Off On  |
|                       |              | Configure Differential Encoding▶ |
| 02/20/2012 17:16      |              | More 2 of 2                      |



The following illustration shows a 4QAM modulation I/Q State Map.



Differential encoding employs relative offsets between the states in the symbol table to encode user-defined modulation schemes. The Differential State Map table editor is used to introduce symbol table offset values which in turn cause transitions through the I/Q State Map based on their associated data value. Whenever a data value is modulated, the offset value stored in the Differential State Map is used to encode the data by transitioning through the I/Q State Map in a direction and distance defined by the symbol table offset value.

Entering a value of +1 will cause a 1-state forward transition through the I/Q State Map, as shown in the following illustration.

---

**NOTE** The following I/Q State Map illustrations show all of the possible state transitions using a particular symbol table offset value. The actual state-to-state transition would depend upon the state in which the modulation had started.

---

As an example, consider the following data/symbol table offset values.

**Table 11-2**

| Data     | Offset Value |
|----------|--------------|
| 00000000 | +1           |
| 00000001 | -1           |

**Table 11-2**

| <b>Data</b> | <b>Offset Value</b> |
|-------------|---------------------|
| 00000010    | +2                  |
| 00000011    | 0                   |

---


**NOTE** The number of bits per symbol can be expressed using the following formula. Because the equation is a ceiling function, if the value of  $x$  contains a fraction,  $x$  is rounded up to the next whole number.

$$x = \lceil \log_2(y) \rceil$$



Where  $x$  = bits per symbol, and  $y$  = the number of differential states.

---

These symbol table offsets will result in one of the transitions, as shown.



When applied to the user-defined default 4QAM I/Q map, starting from the 1st symbol (data 00), the differential encoding transitions for the data stream (in 2-bit symbols) 0011100001 appear in the following illustration.



| Data Value | Symbol Table Offset |
|------------|---------------------|
| 00         | +1                  |
| 01         | -1                  |
| 10         | +2                  |
| 11         | +0                  |

As you can see from the previous illustration, the 1st and 4th symbols, having the same data value (00), produce the same state transition (forward 1 state). In differential encoding, symbol values do not define location; they define the direction and distance of a *transition* through the I/Q State Map.

## Using Differential Encoding

The signal generator’s Differential State Map table editor enables you to modify the differential state map associated with user-defined I/Q and user-defined FSK modulations. In this procedure, you create a user-defined I/Q modulation and then configure, activate, and apply differential encoding to the user-defined modulation. For more information, see “[Differential Encoding](#)” on page 290.

### Configuring User-Defined I/Q Modulation

1. Press **Preset**.
2. Perform the following keypress sequence required for your format type.

#### For Custom ARB Format

Press **Mode > ARB Custom Modulation > Single Carrier Setup > Modulation Type > Select > More 1 of 2 > Define User I/Q > More > Load Default I/Q Map > QAM > 4QAM**.

Or this alternate sequence:

Press **Mode > ARB Custom Modulation > Single Carrier Setup > Quick Setup (desired format) > Modulation Type > Select > More > Define User I/Q > More 1 of 2 > Load Default I/Q Map > QAM > 4QAM**.

This loads a default 4QAM I/Q modulation and displays it in the I/Q table editor.

The default 4QAM I/Q modulation contains data that represent 4 symbols (00, 01, 10, and 11) mapped into the I/Q plane using 2 distinct values (1.000000 and -1.000000). These 4 symbols will be traversed during the modulation process by the symbol table offset values associated with each symbol of data. Refer to [Figure 11-41](#).

Figure 11-41

| FREQUENCY            |              | AMPLITUDE    |                                  | User Mod Type                |
|----------------------|--------------|--------------|----------------------------------|------------------------------|
| 6.000 000 000 00 GHz |              | -144.00 dBm  |                                  | Load/Store▶                  |
|                      |              |              |                                  | Load Default I/Q Map▶        |
| I/Q Values Data      | I Value      | Q Value      | Delete All Rows▶                 |                              |
| 000000000            | 1.000000000  | 1.000000000  | Differential Encoding Off On     |                              |
| 000000001            | -1.000000000 | 1.000000000  | Configure Differential Encoding▶ |                              |
| 000000010            | -1.000000000 | -1.000000000 |                                  |                              |
| 000000011            | 1.000000000  | -1.000000000 |                                  |                              |
| 000000100            |              |              |                                  |                              |
|                      |              |              |                                  | 02/20/2012 17:23 Page 2 of 2 |

### Accessing the Differential State Map Table Editor

Press **Configure Differential Encoding**.

This opens the Differential State Map table editor, as shown. At this point, you see the data for the 1st symbol (00000000) and the cursor prepared to accept an offset value. You are now prepared to create a custom differential encoding for the user-defined default 4QAM I/Q modulation. Refer to [Figure 11-42 on page 295](#).

Figure 11-42

| FREQUENCY                   |                     | AMPLITUDE   |  | Diff Encode      |
|-----------------------------|---------------------|-------------|--|------------------|
| 6.000 000 000 00 GHz        |                     | -144.00 dBm |  | Edit Item        |
|                             |                     |             |  | Insert Row       |
| Differential State Map Data | Symbol Table Offset |             |  | Delete Row       |
| 00000000                    | -----               |             |  | Goto Row▶        |
|                             |                     |             |  | Delete All Rows▶ |
|                             |                     |             |  | 02/20/2012 17:25 |

### Editing the Differential State Map

1. Press **1** > **Enter**.

This encodes the first symbol by adding a symbol table offset of 1. The symbol rotates *forward* through the state map by 1 value when a data value of 0 is modulated.

2. Press **+/-** > **1** > **Enter**.

This encodes the second symbol by adding a symbol table offset of -1. The symbol rotates *backward* through the state map by 1 value when a data value of 1 is modulated.

---

**NOTE** At this point, the modulation has one bit per symbol. For the first two data values (00000000 and 00000001) only the last bits (the 0 and the 1, respectively) are significant.

---

3. Press **2** > **Enter**.

This encodes the third symbol by adding a symbol table offset of 2. The symbol rotates *forward* through the state map by 2 values when a data value of 10 is modulated.

4. Press **0** > **Enter**.

This encodes the fourth symbol by adding a symbol table offset of 0. The symbol does *not* rotate through the state map when a data value of 11 is modulated.

---

**NOTE** At this point, the modulation has two bits per symbol. For the data values 00000000, 00000001, 00000010, 00000011, the symbol values are 00, 01, 10, and 11 respectively.

---

### Applying Custom Differential Encoding

Press **Return** > **Differential Encoding Off On**.

This applies the custom differential encoding to a user-defined modulation.

---

**NOTE** Notice that (UNSTORED) appears next to Differential State Map on the signal generator's display. Differential state maps are associated with the user-defined modulation for which they were created.

In order to save a custom differential state map, you must store the user-defined modulation for which it was designed. Otherwise the symbol table offset data is purged when you press the **Confirm Exit From Table Without Saving** softkey when exiting from the I/Q or FSK table editor.

---

---

# 12 Multitone and Two–Tone Waveforms (Option 430)

Before using this information, you should be familiar with the basic operation of the signal generator. If you are not comfortable with functions such as setting the power level and frequency, refer to [Basic Operation](#) on page 33 and familiarize yourself with the information in that chapter.

This feature is available only in Agilent X-Series vector signal generators with Option 430. Option 430 requires Option 653 or 656.

## Creating a Custom Two–Tone Waveform

Using the Two–Tone menu, you can define, and modify user–defined Two–Tone waveforms. Two–Tone waveforms are generated by the dual arbitrary waveform generator.

The section [Using Two–Tone Modulation](#) on page 297 teaches you how to perform the following tasks:

- [Creating a Two–Tone Waveform](#) on page 298
- [Viewing a Two–Tone Waveform](#) on page 299
- [Minimizing Carrier Feedthrough](#) on page 300
- [Changing the Alignment of a Two–Tone Waveform](#) on page 301

## Creating a Custom Multitone Waveform

Using the Multitone Setup table editor, you can define, modify and store user–defined multitone waveforms. Multitone waveforms are generated by the dual arbitrary waveform generator.

The [Using Multitone Modulation](#) on page 303 teaches you how to perform the following tasks:

- [Initializing the Multitone Setup Table Editor](#) on page 303
- [Configuring Tone Powers and Tone Phases](#) on page 304
- [Removing a Tone](#) on page 304
- [Generating the Waveform](#) on page 304
- [Configuring the RF Output](#) on page 304

## Using Two–Tone Modulation

In the following sections, this chapter describes the two–tone mode, which is available only in Agilent X-Series vector signal generators with Option 430:


- [Creating a Two–Tone Waveform](#) on page 298
- [Viewing a Two–Tone Waveform](#) on page 299
- [Minimizing Carrier Feedthrough](#) on page 300

- [Changing the Alignment of a Two-Tone Waveform](#) on page 301

See also: [Saving a Waveform's Settings & Parameters](#) on page 139

**NOTE** For more information about two-tone waveform characteristics, and the two-tone standard, download *Application Note 1410* from our website by going to <http://www.agilent.com> and searching for “AN 1410” in Test & Measurement.

## Two-Tone Modulation Softkeys



For details on each key, use key help as described on [page 34](#).

## Creating a Two-Tone Waveform

This procedure describes how to create a basic, centered, two-tone waveform.


1. Preset the signal generator.
2. Set the signal generator RF output frequency to 6 GHz.
3. Set the signal generator RF output amplitude to -10 dBm.



4. Press **Mode > More > Two-Tone > Freq Separation > 10 > MHz**.
5. Press **Two Tone Off On** to On.
6. Turn on the RF output.

The two-tone signal is now available at the signal generator RF OUTPUT connector. [Figure 12-1 on page 299](#) shows what the signal generator display should look like after all steps have been completed. Notice that the T-TONE, I/Q, annunciators are displayed; the RF ON, MOD ON are on; and the parameter settings for the signal are shown in the status area of the signal generator display.

**Figure 12-1**



For details on each key, use key help as described on page 34.


## Viewing a Two-Tone Waveform

This procedure describes how to configure the spectrum analyzer to view a two-tone waveform and its IMD products. Actual key presses will vary, depending on the model of spectrum analyzer you are using.

1. Preset the spectrum analyzer.
2. Set the carrier frequency to 6 GHz.
3. Set the frequency span to 60 MHz.
4. Set the amplitude for a 10 dB scale with a -10 dBm reference.
5. Adjust the resolution bandwidth to sufficiently reduce the noise floor to expose the IMD products. A 9.1 kHz setting was used in our example.
6. Turn on the peak detector.
7. Set the attenuation to 4 dB, so you're not overdriving the input mixer on the spectrum analyzer.

You should now see a two-tone waveform with a 6 GHz center carrier frequency that is similar to the one shown in [Figure 12-2 on page 300](#). You will also see IMD products at 10 MHz intervals above and below the generated tones, and a carrier feedthrough spike at the center frequency with carrier feedthrough distortion products at 10 MHz intervals above and below the center carrier frequency.

Figure 12-2



For details on each key, use key help as described on [page 34](#).

**Carrier Feedthrough  
Distortion**

## Minimizing Carrier Feedthrough

This procedure describes how to minimize carrier feedthrough and measure the difference in power between the tones and their intermodulation products. Before beginning this procedure, it is important that a recent I/Q calibration has been performed on the instrument. The procedure for performing an I/Q calibration (refer to “[I/Q Calibration](#)” on [page 194](#)).

This procedure builds upon the previous procedure.


1. On the spectrum analyzer, set the resolution bandwidth for a sweep rate of about 100 to 200 ms. This will allow you to dynamically view the carrier feedthrough spike as you make adjustments.
2. On the signal generator, press **I/Q > I/Q Adjustments > I/Q Adjustments Off On** to On.
3. Press **Internal Baseband Adjustments > I Offset** and turn the rotary knob while observing the carrier feedthrough with the spectrum analyzer. Changing the I offset in the proper direction will reduce the feedthrough level. Adjust the level as low as possible.
4. Press **Q Offset** and turn the rotary knob to further reduce the carrier feedthrough level.
5. Repeat steps 3 and 4 until you have reached the lowest possible carrier feedthrough level.
6. On the spectrum analyzer, return the resolution bandwidth to its previous setting.
7. Turn on waveform averaging.

8. Create a marker and place it on the peak of one of the two tones.
9. Create a delta marker and place it on the peak of the adjacent intermodulation product, which should be spaced 10 MHz from the marked tone.
10. Measure the power difference between the tone and its distortion product.

You should now see a display that is similar to the one shown in [Figure 12-3 on page 301](#). Your optimized two-tone signal can now be used to measure the IMD products generated by a device-under-test.

Note that carrier feedthrough changes with time and temperature. Therefore, you will need to periodically readjust your I and Q offsets to keep your signal optimized.

**Figure 12-3**



For details on each key, use key help as described on [page 34](#).

## Changing the Alignment of a Two-Tone Waveform


This procedure describes how to align a two-tone waveform left or right, relative to the center carrier frequency. Because the frequency of one of the tones is the same as the carrier frequency, this alignment typically hides any carrier feedthrough. However, image frequency interference caused by left or right alignment may cause minor distortion of the two-tone signal. This procedure builds upon the previous procedure.

1. On the signal generator, press **Mode > Two Tone > Alignment Left Cent Right** to Left.
2. Press **Apply Settings** to regenerate the waveform.

**NOTE** Whenever a change is made to a setting while the two-tone generator is operating (**Two Tone Off On** set to On), you must apply the change by pressing the **Apply Settings** softkey before the updated waveform will be generated. When you apply a change, the baseband generator creates a two-tone waveform using the new settings and replaces the existing waveform in ARB memory.

3. On the spectrum analyzer, temporarily turn off waveform averaging to refresh your view more quickly. You should now see a left-aligned two-tone waveform that is similar to the one shown in [Figure 12-4](#).


Figure 12-4



For details on each key, use key help as described on [page 34](#).

## Using Multitone Modulation

### Multitone Modulation Softkeys




For details on each key, use key help as described on page 34.

### Initializing the Multitone Setup Table Editor

1. Press **Preset**.
2. Press **Mode > Multitone**
3. Press **Initialize Table > Number of Tones > 5 > Enter**.
4. Press **Freq Spacing > 20 > kHz**.

Figure 12-5

| FREQUENCY                           |             | RF OFF      |       | Init Tones                    |  |
|-------------------------------------|-------------|-------------|-------|-------------------------------|--|
| 6.000 000 000 00 GHz                |             | -144.00 dBm |       | Number Of Tones 5             |  |
| Number of Tones: 5                  |             |             |       | Freq Spacing 20.000 kHz       |  |
| Multitone Setup: default (UNSTORED) |             |             |       | Initialize Phase Fixed Random |  |
| Tone                                | Freq Offset | Power       | Phase | State                         |  |
| 1                                   | -40.000 kHz | 0.00 dB     | 0     | On                            |  |
| 2                                   | -20.000 kHz | 0.00 dB     | 0     | On                            |  |
| 3                                   | 0.000 kHz   | 0.00 dB     | 0     | On                            |  |
| 4                                   | 20.000 kHz  | 0.00 dB     | 0     | On                            |  |
| 5                                   | 40.000 kHz  | 0.00 dB     | 0     | On                            |  |
|                                     |             |             |       | Done                          |  |
| 03/08/2012 12:14                    |             |             |       | More 1 of 2                   |  |



The Random Seed softkey that affects the Multitone's phase values is not used in the following examples and is shown for reference, only.

For details on each key, use key help as described on page 34.

5. Press **Done**.

You now have a multitone setup with five tones spaced 20 kHz apart. The center tone is placed at the carrier frequency, while the other four tones are spaced in 20 kHz increments from the center tone.

### Configuring Tone Powers and Tone Phases

1. Highlight the value (0 dB) in the Power column for the tone in row 2.
2. Press **Edit Table > Edit Item > -4.5 > dB**.
3. Highlight the value (0) in the Phase column for the tone in row 2.
4. Press **Edit Item > 123 > deg**.

### Removing a Tone

1. Highlight the value (On) in the State column for the tone in row 4.
2. Press **Toggle State**.

### Generating the Waveform

Press **Return > Multitone Off On** until On is highlighted.

This generates the multitone waveform with the parameters defined in the previous sections. During waveform generation, the M-TONE and I/Q annunciators activate and the multitone waveform is stored in volatile ARB memory. The waveform is now modulating the RF carrier.

### Configuring the RF Output

1. Set the RF output frequency to 100 MHz.

2. Set the output amplitude to 0 dBm.
3. Press **RF On/Off**.

The multitone waveform is now available at the signal generator's RF OUTPUT connector.

## Applying Changes to an Active Multitone Signal

If the multitone generator is currently in use (**Multitone Off On** set to On) while changes are made in the Multitone Setup table editor, you must *apply* the changes before the updated waveform will be generated.

From the Multitone Setup table editor, press the following key to apply the changes and generate a multitone waveform based on the updated values: **Apply Multitone**

## Storing a Multitone Waveform

In this example, you learn how to store a multitone waveform. If you have not created a multitone waveform, complete the steps in the previous section, [Creating a Custom Multitone Waveform](#) on page 297.

1. Press **Load/Store > Store To File**.

If there is already a file name from the Catalog of MTONE Files occupying the active entry area, press the following keys (see [page 35](#)):

**Edit Keys > Clear Text**

2. Enter a file name (for example, 5TONE) using the alpha keys and the numeric keypad with a maximum length of 23 characters (see [page 35](#)).
3. Press **Enter**.

The multitone waveform is now stored in the Catalog of MTONE Files.

---

**NOTE** The RF output amplitude, frequency, and operating state settings are not stored as part of a multitone waveform file. Similarly, the multitone settings are not stored as part of the instrument state. Therefore, in most cases you should save both the instrument states and the multitone settings to be able to restore all of your settings later.

---

### Recalling a Multitone Waveform

Using this procedure, you learn how to recall a multitone waveform from the signal generator's memory catalog.

If you have not created and stored a multitone waveform, complete the steps in the previous sections, [Creating a Custom Multitone Waveform](#) on page 297 and [Storing a Multitone Waveform](#) on page 305, then preset the signal generator to clear the stored multitone waveform from volatile ARB memory.

1. Press **Mode > Multitone**.
2. Press **Load/Store**.
3. Highlight the desired file (for example, 5TONE).
4. Press **Load From Selected File > Confirm Load From File**.
5. Press **Multitone Off On** until On is highlighted.

The firmware generates the multitone waveform in ARB memory. After waveform generation, the multitone waveform is available to be modulated on the RF output.

For instruction on configuring the RF output, see [Configuring the RF Output](#) on page 304.



---

# 13 Working in a Secure Environment

If you are using the instrument in a secure environment, you may need details of how to clear or sanitize its memory, in compliance with published security standards of the United States Department of Defense, or other similar authorities.

For the Series B MXG and EXG instruments, this information is contained in the PDF document "*Security Features and Document of Volatility*". This document is *not* included in the Documentation CD, but it may be downloaded from Agilent's web site, as described below.

The document includes the following topics:

- Security Terms and Definitions
- Instrument Memory Types
- Memory Clearing and Sanitization (Erase All, Erase and Sanitize All functions)
- Clearing Persistent State information
- Using the Secure Display feature (also documented in "[Using Secure Display](#)" on page 308 below)
- Declassifying a Faulty Instrument

## How to Obtain the Security Features Document

| Step | Action  |
|------|---|
| 1    | Click on or browse to the following URL:<br><a href="http://www.agilent.com/find/security">http://www.agilent.com/find/security</a> |
| 2    | To locate and download the document, select Model Number "N5182B", "N5181B", "N5172B" or "N5171B", then click "Submit".             |
| 3    | Follow the on-screen instructions to download the PDF file.   |

## Using Secure Display

This function prevents unauthorized personnel from reading the instrument display or tampering with the current configuration via the front panel. When Secure Display is active, the display is blank, except for an advisory message, as shown in [Figure 13-1](#) below. All front panel keys are disabled.

To set Secure Display, press: **Utility > Display > More > Activate Secure Display > Confirm Secure Display.**

Once Secure Display has been activated, the power must be cycled to re-enable the display and front panel keys.

**Figure 13-1 Signal Generator Screen with Secure Display Activated**



---

# 14 Troubleshooting

- [Display](#) on page 310
- [Signal Generator Lock-Up](#) on page 310
- [RF Output](#) on page 310
  - [No RF Output](#)
  - [Power Supply Shuts Down](#)
  - [No Modulation at the RF Output](#)
  - [RF Output Power too Low](#)
  - [Distortion](#)
  - [Signal Loss While Working with a Spectrum Analyzer](#)
  - [Signal Loss While Working with a Mixer](#)
- [Sweep](#) on page 314
  - [Cannot Turn Off Sweep](#)
  - [Sweep Appears Stalled](#)
  - [Incorrect List Sweep Dwell Time](#)
  - [List Sweep Information is Missing from a Recalled Register](#)
  - [Amplitude Does Not Change in List or Step Sweep](#)
- [Internal Media Data Storage](#) on page 315
  - [Instrument State Saved but the Register is Empty or Contains the Wrong State](#)
- [USB Media Data Storage](#) on page 315
  - [Instrument Recognizes USB Media Connection, but Does Not Display Files](#)
- [Preset](#) on page 315
  - [The Signal Generator Does Not Respond](#)
  - [Pressing Preset Performs a User Preset](#)
- [Error Messages](#) on page 316
- [Front Panel Tests](#) on page 317
- [Self Test Overview](#) on page 318
- [Licenses](#) on page 321
- [Contacting Agilent Technologies](#) on page 321
  - [Returning a Signal Generator to Agilent](#)

## Display

### The Display is Too Dark to Read

Brightness may be set to minimum. Use the figure in “[Display Settings](#)” on page 20 to locate the brightness softkey and adjust the value so that you can see the display.

### The Display Turns Black when Using USB Media

Removing the USB media when the instrument begins to use it can cause the screen to go black. Cycle instrument power.

### Signal Generator Lock-Up

- Ensure that the signal generator is not in remote mode (the R annunciator shows on the display). To exit remote mode and unlock the front panel, press **Local Cancel/(Esc)**.
- Ensure that the signal generator is not in local lockout, which prevents front panel operation. For information on local lockout, refer to the *Programming Guide*.
- If a progress bar appears on the signal generator display, an operation is in progress.
- Preset the signal generator.
- Cycle power on the signal generator.

## RF Output

### No RF Output

- Check the RF ON/OFF LED (shown on [page 5](#)). If it is off, press RF On/Off to turn the output on.
- Ensure that the amplitude is set within the signal generator’s range.
- If the instrument is playing a waveform, ensure that marker polarity and routing settings are correct (see “[Saving Marker Polarity and Routing Settings](#)” on page 146).

### Power Supply Shuts Down

If the power supply does not work, it requires repair or replacement. If you are unable to service the instrument, send the signal generator to an Agilent service center for repair (see “[Contacting Agilent Technologies](#)” on page 321).

### No Modulation at the RF Output

Check both the Mod On/Off LED and the *<modulation>* Off On softkey, and ensure that both are on. See also “[Modulating the Carrier Signal](#)” on page 48.

For digital modulation on a vector signal generator, ensure that the internal I/Q modulator is on (the I/Q annunciator displays).

If using an external modulation source, ensure that the external source is on and that it is operating within the signal generator’s specified limits.

## RF Output Power too Low

- If the AMPLITUDE area of the display shows the OFFS indicator, eliminate the offset:  
Press **Amptd > More 1 of 2 > Amptd Offset > 0 > dB**. See also [“Setting an Output Offset” on page 105](#).
- If the AMPLITUDE area of the display shows the REF indicator, turn off the reference mode:
  1. Press **Amptd > More > Amptd Ref Off On** until Off highlights.
  2. Reset the output power to the desired level.
 See also [“Setting an Output Reference” on page 106](#).
- If you are using the signal generator with an external mixer, see [page 312](#).
- If you are using the signal generator with a spectrum analyzer, see [page 311](#).
- If pulse modulation is on, turn off the ALC, and check that pulse width is within specifications.

## Distortion

If you edit and resave a segment in a waveform sequence, the sequence does not automatically update the RMS value stored in its header. This can cause distortion on the output signal. Display the sequence header information and recalculate the RMS value (see [page 139](#)).

## Signal Loss While Working with a Spectrum Analyzer

---

**CAUTION** To avoid damaging or degrading the performance of the signal generator, do not exceed 33 dBm (2W) *maximum* of reverse power levels at the RF input. See also *Tips for Preventing Signal Generator Damage* on [www.agilent.com](http://www.agilent.com).

---

The effects of reverse power can cause problems with the RF output when you use the signal generator with a spectrum analyzer that does not have preselection. Use an unlevelled operating mode (described on [page 102](#)).

A spectrum analyzer can have as much as +5 dBm LO feedthrough at its RF input port at some frequencies. If the frequency difference between the LO feedthrough and the RF carrier is less than the ALC bandwidth, the LO's reverse power can amplitude modulate the signal generator's RF output. The rate of the undesired AM equals the difference in frequency between the spectrum analyzer's LO feedthrough and the signal generator's RF carrier.

Reverse power problems can be solved by using one of the unlevelled operating modes.

See:

- [“ALC Off Mode” on page 102](#)  
and
- [“Power Search Mode” on page 103](#)

## Signal Loss While Working with a Mixer


**CAUTION** To avoid damaging or degrading the performance of the signal generator, do not exceed 33 dBm (2W) *maximum* of reverse power levels at the RF input. See also *Tips for Preventing Signal Generator Damage* on [www.agilent.com](http://www.agilent.com).

To fix signal loss at the signal generator's RF output during low-amplitude coupled operation with a mixer, add attenuation and increase the RF output amplitude.

The figure at right shows a configuration in which the signal generator provides a low amplitude signal to a mixer.


The internally leveled signal generator RF output (and ALC level) is  $-8$  dBm. The mixer is driven with an LO of  $+10$  dBm and has an LO-to-RF isolation of  $15$  dB. The resulting  $-5$  dBm LO feedthrough enters the signal generator's RF output and arrives at the internal detector.

Depending on frequency, it is possible for most of this LO feedthrough energy to enter the detector. Because the detector responds to its total input power regardless of frequency, this excess energy causes the ALC to reduce the RF output. In this example, the reverse power across the detector is actually greater than the ALC level, which can result in loss of signal at the RF output.



The solution at right shows a similar configuration with the addition of a 10 dB attenuator connected between the RF output of the signal generator and the input of the mixer. The signal generator's ALC level increases to +2 dBm and transmits through a 10 dB attenuator to achieve the required -8 dBm amplitude at the mixer input.

Compared to the original configuration, the ALC level is 10 dB higher while the attenuator reduces the LO feedthrough (and the signal generator's RF output) by 10 dB. Using the attenuated configuration, the detector is exposed to a +2 dBm desired signal versus the -15 dBm undesired LO feedthrough. This 17 dB difference between desired and undesired energy results in a maximum 0.1 dB shift in the signal generator's RF output level.



## Sweep

### Cannot Turn Off Sweep

Press **Sweep > Sweep > Off**.

### Sweep Appears Stalled

The current status of the sweep is indicated as a shaded rectangle in the progress bar (see [“Configuring a Swept Output” on page 40](#)). If the sweep appears to stall, check the following:

1. Turn on the sweep with one of the following key sequences:
  - Sweep > Sweep > Freq**
  - Sweep > Sweep > Amptd**
  - Sweep > Sweep > Waveform** (vector instruments only)
2. If the sweep is in single mode, press the **Single Sweep** softkey.
3. If the sweep trigger (indicated by the **Sweep Trigger** softkey) is *not* set to Free Run, set it to Free Run to determine if a missing sweep trigger is blocking the sweep.
4. If the point trigger (indicated by the **Point Trigger** softkey) is *not* set to Free Run, set it to Free Run to determine if a missing point trigger is blocking the sweep.
5. Set the dwell time to one second to determine if the dwell time was set to a value that was too slow or too fast to see.
6. Ensure that you set at least two points in the step sweep or list sweep.

### Incorrect List Sweep Dwell Time

1. Press **Sweep > More > Configure List Sweep**.
2. Check that the list sweep dwell values are accurate.
3. If the dwell values are incorrect, edit them.  
If the dwell values are correct, continue to the next step.
4. Press **More**, and ensure that the **Dwell Type List Step** softkey is set to List.  
If Step is selected, the signal generator sweeps the list points using the dwell time set for step sweep rather than list sweep.

See also [“Configuring a Swept Output” on page 40](#).

### List Sweep Information is Missing from a Recalled Register

List sweep information is not stored as part of the instrument state in an instrument state register. Only the current list sweep is available to the signal generator. You can store list sweep data in the instrument catalog (see [“Loading \(Recalling\) a Stored File” on page 55](#)).

### Amplitude Does Not Change in List or Step Sweep

Verify that sweep type is set to amplitude (Amptd); the amplitude does not change when the sweep type is set to frequency (Freq) or waveform.



## Internal Media Data Storage

### Instrument State Saved but the Register is Empty or Contains the Wrong State

If the register number you intended to use is empty or contains the wrong instrument state, recall register 99. If you selected a register number greater than 99, the signal generator automatically saves the instrument state in register 99.

See also “[Working with Instrument State Files](#)” on page 57.

## USB Media Data Storage

### Instrument Recognizes USB Media Connection, but Does Not Display Files

If the USB media works on other instruments or computers, it may simply be incompatible with the signal generator; try a different USB media. Refer to <http://www.agilent.com/find/mxg> for details on compatible USB media.

## Preset

### The Signal Generator Does Not Respond

If the signal generator does not respond to a preset, the instrument may be in remote mode, which locks the keypad.

To exit remote mode and unlock the preset keys, press **Local Cancel/(Esc)**.

### Pressing Preset Performs a User Preset

This behavior results from the use of a backward-compatible SCPI command. To return the signal generator to normal use, send the command `:SYST:PRESet:TYPE NORM`.

For information on SCPI commands, refer to the *SCPI Command Reference*.

## Error Messages

### Error Message Types

Events do not generate more than one type of error. For example, an event that generates a query error does not generate a device-specific, execution, or command error.

**Query Errors (-499 to -400)** indicate that the instrument's output queue control has detected a problem with the message exchange protocol described in IEEE 488.2, Chapter 6. Errors in this class set the query error bit (bit 2) in the event status register (IEEE 488.2, section 11.5.1). These errors correspond to message exchange protocol errors described in IEEE 488.2, 6.5. In this case:

- Either an attempt is being made to read data from the output queue when no output is either present or pending, or
- data in the output queue has been lost.

**Device Specific Errors (-399 to -300, 201 to 703, and 800 to 810)** indicate that a device operation did not properly complete, possibly due to an abnormal hardware or firmware condition. These codes are also used for self-test response errors. Errors in this class set the device-specific error bit (bit 3) in the event status register (IEEE 488.2, section 11.5.1).

The <error\_message> string for a *positive* error is not defined by SCPI. A positive error indicates that the instrument detected an error within the GPIB system, within the instrument's firmware or hardware, during the transfer of block data, or during calibration.

**Execution Errors (-299 to -200)** indicate that an error has been detected by the instrument's execution control block. Errors in this class set the execution error bit (bit 4) in the event status register (IEEE 488.2, section 11.5.1). In this case:


- Either a <PROGRAM DATA> element following a header was evaluated by the device as outside of its legal input range or is otherwise inconsistent with the device's capabilities, or
- a valid program message could not be properly executed due to some device condition.

Execution errors are reported *after* rounding and expression evaluation operations are completed. Rounding a numeric data element, for example, is not reported as an execution error.

**Command Errors (-199 to -100)** indicate that the instrument's parser detected an IEEE 488.2 syntax error. Errors in this class set the command error bit (bit 5) in the event status register (IEEE 488.2, section 11.5.1). In this case:

- Either an IEEE 488.2 syntax error has been detected by the parser (a control-to-device message was received that is in violation of the IEEE 488.2 standard. Possible violations include a data element that violates device listening formats or whose type is unacceptable to the device.), or
- an unrecognized header was received. These include incorrect device-specific headers and incorrect or unimplemented IEEE 488.2 common commands.


## Front Panel Tests



For details on each key, use key help as described on [page 34](#).

## Self Test Overview

The self test is a series of internal tests that checks different signal generator functions. The self test, is also available by via the remote web interface. For more information on the Web-Enabled MXG, refer to the *Programming Guide*.



Utility > Instrument Info

**Instrument Info**

- Diagnostic Info▶
- Options Info▶
- Self Test▶
- Installed Board Info▶
- Front Panel Tests▶

FREQUENCY 6.000 000 000 00 GHz RF OFF -144.00 dBm

**Self Test**

Run Complete Self Test

**Self Test Summary**

The current status of self test is: Incomplete  
Not all tests have been run.

View Test Info

04/14/2012 17:44

Automatically runs diagnostic self test.

Self Test Summary displays current status.

Opens a table in which user selects specific tests and view details in Test Editor display.

FREQUENCY 6.000 000 000 00 GHz RF OFF -144.00 dBm

**Self Test**

View Details▶

Run Highlighted

Select/Deselect

Select/Deselect All

Run Selected

04/14/2012 17:47 **Page 1 of 2**

**Test Editor**

| Sel ID#                          | Test Name                               | Status  |
|----------------------------------|---|---------|
| --- RF: Digital Self Tests ---   |   |         |
| 101                              | Digital FPGA                            | NOT RUN |
| 102                              | Digital JTAG                            | NOT RUN |
| 103                              | Digital Voltages                        | NOT RUN |
| 104                              | Board Temperature                       | NOT RUN |
| 105                              | Sweep Out                               | NOT RUN |
| --- RF: Reference Self Tests --- |   |         |
| 201                              | Reference Voltages                      | NOT RUN |
| 202                              | Reference 100MHz Tank DAC               | NOT RUN |
| 203                              | Reference Tuning Voltage (Internal Ref) | NOT RUN |

Displays detailed information of highlighted test. Refer to [page 34](#)

Executes highlighted operation.

Selects or deselects highlighted operation.

Selects or deselects all operations.

Executes all selected operations.

**Self Test**

Loop Selected

Go To Test▶

Runs a loop of selected tests until a failure occurs.

Opens the Go To Menu. Adds navigation keys to the self test menu.

For details on each key, use key help as described on [page 34](#).



## Licenses

### A Time-Based License Quits Working

- The instrument's time or date may have been reset forward causing the time-based license to expire.
- The instrument's time or date may have been reset backward more than approximately 25 hours, causing the instrument to ignore time-based licenses.

See [page 22](#) for details and cautions on setting time and date.

### Cannot Load a Time-Based License

The instrument's time or date may have been reset backward more than approximately 25 hours, causing the instrument to ignore time-based licenses.

See [page 22](#) for details and cautions on setting time and date.

## Contacting Agilent Technologies

- assistance with test and measurements needs, and information on finding a local Agilent office: <http://www.agilent.com/find/assist>
- accessories or documentation: [http://www.agilent.com/find/X-Series\\_SG](http://www.agilent.com/find/X-Series_SG).
- new firmware releases: <http://www.agilent.com/find/upgradeassistant>.

If you do not have access to the Internet, please contact your field engineer.

---

**NOTE** In any correspondence or telephone conversation, refer to the signal generator by its model number and full serial number. With this information, the Agilent representative can determine whether your unit is still within its warranty period.

---

## Returning a Signal Generator to Agilent

Use the following steps to return a signal generator to Agilent Technologies for servicing:

1. Gather as much information as possible regarding the signal generator's problem.
2. Call the phone number listed on the Internet (<http://www.agilent.com/find/assist>) that is specific to your geographic location. If you do not have access to the Internet, contact your Agilent field engineer.

After sharing information regarding the signal generator and its condition, you will receive information regarding where to ship your signal generator for repair.

3. Ship the signal generator in the original factory packaging materials, if available, or use similar packaging to properly protect the signal generator.





## Glossary

### A

**Active Entry** The currently selected, and therefore editable, entry or parameter

**ARB** Arbitrary waveform generator

**AWG** Arbitrary waveform generator. Additive white Gaussian noise

### B

**BBG Media** Baseband generator media. Volatile memory, where waveform files are played or edited.

**BNC Connector** Bayonet Neill-Concelman connector. A type of RF connector used to terminate coaxial cable.

### C

**CCW** Counterclockwise

**C/N** Carrier-to-noise ratio

**CW** Continuous wave. Clockwise

### D

**DHCP** Dynamic host communication protocol

**Dwell Time** In a step sweep (see [page 42](#)), the time that the signal is settled and you can make a measurement before the sweep moves to the next point.

### E

**EVM** Error vector magnitude; the magnitude of the vector difference at a given instant between the ideal reference signal and the measured signal.

### F

**Filter factor Alpha** The filter's alpha coefficient. It is only valid for root nyquist and nyquist filters.

**Filter Factor BbT** The filter's bandwidth-bit-time (BbT). It is only valid for a Gaussian filter (similar to alpha). BbT is defined by the GSM standard as 0.3 and by the DECT standard as 0.5.

### G

**Gaussian filter** The Gaussian filter does not have a zero Inter-Symbol Interference (ISI). Wireless system architects must decide just how much of the ISI can be tolerated in a system and combine that with noise and interference. The Gaussian filter is gaussian shaped in both the time and frequency domains, and it does not ring like the root nyquist filters do. The effects of this filter in the time domain are relatively short and each symbol interacts significantly (or causes ISI) with only the preceding and succeeding symbols. This reduces the tendency for particular sequences of symbols to interact, which makes amplifiers easier to build and more efficient.

**GPIO** General purpose interface bus. An 8-bit parallel bus common on test equipment.

### H

**Hardkey** A labeled button on the instrument.

### I

**IF** Intermediate frequency

**Int Media** Internal media. Non-volatile signal generator memory, where waveform files are

stored.

**IP** Internet protocol. The network layer for the TCP/IP protocol suite widely used on Ethernet networks.

## L

**LAN** Local area network

**LO** Local oscillator

**LXI** LAN eXtension for Instrumentation. An instrumentation platform based on industry standard Ethernet technology designed to provide modularity, flexibility, and performance to small- and medium-sized systems. See also <http://www.lxistandard.org>

## M

**Modulation Format** Custom modulation, Two Tone, or Multitone.

**Modulation Mode** Dual ARB, Custom modulation, Two Tone, or Multitone.

**Modulation Standard** Refers to a Cellular standard format (i.e. NADC, PDC, PHS, etc.).

**Modulation Type** Refers to the various I/Q constellation types (i.e. PSK, MSK, FSK, C4FM, etc.).

## N

**Non-volatile** That which survives a power cycle (such as files stored in USB media).

**Nyquist filter** Also referred to as a cosine filter. These filters have the property that their impulse response rings at the symbol rate. Adjacent symbols do not interfere with each other at the symbol times because the response

equals zero at all symbol times except the center (desired) one.

## P

**Persistent** That which is unaffected by preset, user preset, or power cycle.

**Point-to-point Time** In a step sweep (page 42), the sum of the dwell time, processing time, switching time, and settling time.

## R

**Rectangular filter** Also referred to as a ideal low pass filter. These filters have very steep cut-off characteristics. The pass band is set to equal the symbol rate of the signal. Due to a finite number of coefficients, the filter has a predefined length and is not truly “ideal”. The resulting ripple in the cut-off band is effectively minimized with a Hamming window. This filter is recommended for achieving optimal ACP. A symbol length of 32 or greater is recommended for this filter.

**Root Nyquist filter** Also referred to as a Root cosine filter. These filters have the property that their impulse response rings at the symbol rate. Adjacent symbols do not interfere with each other at the symbol times because the response equals zero at all symbol times except the center (desired) one. Root nyquist filters heavily filter the signal without blurring the symbols together at the symbol times. This is important for transmitting information without errors caused by ISI. Note that ISI does exist at all times except the symbol (decision) times. A cascade of two of these filters has the transfer function of a Nyquist filter. One is in the transmitter, the other in the receiver, so that the system taken as a whole has the zero-ISI properties of an ISI filter.

**RMS** Root mean square. A time-varying signal's effective value (the equivalent DC voltage required to generate the equivalent heat across a given resistor). For a sinewave,  $RMS = 0.707 \times$

peak value.

## **S**

**Softkey** A button located along the instrument's display that performs whatever function is shown next to it on that display.

## **T**

**TCP** Transmission control protocol. The most common transport layer protocol used on Ethernet and the Internet.

**Terminator** A unit indicator (such as Hz or dBm) that completes an entry. For example, for the entry 100 Hz, *Hz* is the terminator.

**Type-N Connector** Threaded RF connector used to join coaxial cables.

## **U**

**USB** Universal serial bus. See also <http://www.usb.org>

**User FIR** Selects a user-defined set of coefficient values. Each line in the FIR values table contains one coefficient value. The number of coefficient values listed must be a multiple of the selected oversampling ratio. Each coefficient applies to both I and Q components.

## **V**

**Volatile** That which does not survive a power cycle (such as files stored in BBG media).



**Symbols**

, 198

ΦM

- annunciator, 9
- dc offset, removing, 67
- hardkey, 63
- softkeys, 63, 67

# points softkey, 43

# Skipped Points softkey, 150

**Numerics**

- 10 MHz OUT connector, 14
- 100Base-T LAN cable, 25
- 128 QAM softkey, 247, 251, 253, 254, 255, 256, 257, 261
- 1410, application note, 298
- 16-Lvl FSK softkey, 247, 251, 253, 254, 255, 256, 257, 261
- 16QAM softkey, 247, 251, 253, 254, 255, 256, 257, 261
- 256 QAM softkey, 247, 251, 253, 254, 255, 256, 257, 261
- 2-Lvl FSK softkey, 247, 251, 253, 254, 255, 256, 257, 261
- 32QAM softkey, 247, 251, 253, 254, 255, 256, 257, 261
- 430, option
  - multitone mode, 303
  - two-tone, 297
- 4-Lvl FSK softkey, 247, 251, 253, 254, 255, 256, 257, 261
- 4QAM softkey, 247, 251, 253, 254, 255, 256, 257, 261
- 628, error, 184
- 64QAM softkey, 247, 251, 253, 254, 255, 256, 257, 261
- 651/652/654, option
  - description, 4
  - multitone mode, 303
  - two-tone mode, 297
- 670/671/672, option
  - description, 4
- 8557D GPIB only softkey, 27, 28
- 8648A/B/C/D GPIB only softkey, 27, 28
- 8656B,8657A/B GPIB only softkey, 27, 28
- 8-Lvl FSK softkey, 247, 251, 253, 254, 255, 256, 257, 261

**A**

- AC power receptacle, 12
- ACP, 244
- Activate Secure Display softkey, 20
- active
  - entry, 323, 9
- Active High softkey, 163
- Active Low softkey, 163
- Add Comment To softkey, 57
- additive white Gaussian noise. *See* AWGN
- address, GPIB, 24
- Adjust Phase softkey, 37, 39
- Adjustable doublet softkey, 114
- adjustments
  - I/Q, 127, 192
  - quadrature, 192
  - real-time phase noise, 241
- advance, segment, 165
- Advanced Settings softkey, 25
- Aeroflex softkey, 27, 28
- Agilent MXG
  - modes of operation, 4
- Agilent sales and service offices, 321
- ALC
  - hold, 146, 147
  - OFF annunciator, 9
  - off mode, 101
  - softkeys, 37, 39, 150
- alc
  - setting, 39
- All softkey, 61
- Alpha, 323
- AM
  - annunciator, 9
  - external source, 67
  - hardkey, 63
  - softkeys, 63
  - wideband, 67
- amplitude
  - display area, 10
  - hardkey, 37, 39
  - LF output, 70, 71
  - modulation, 63
  - offset, 104
  - reference, 105
  - setting, 37, 39
  - troubleshooting sweep, 314
- AMPTD hardkey, 37, 39
- analog modulation, 4, 63
  - configuring, 64, 69
- angle, quadrature, 127
- annunciators, 9
- APCO 25 w/C4FM softkey, 246, 250
- APCO 25 w/CQPSK softkey, 246, 250
- apodization settings, FIR filter, 205, 288
- application notes
  - 1410, 298
- Apply To Waveform softkey, 150
- ARB
  - definition, 323
  - player, dual, 130
  - softkeys, 130, 161, 230, 231, 232, 233, 238
  - waveform clipping, 169
- arb, 244
- Arb Custom
  - FIR filters, 281, 287
- Arb Segment softkey, 56
- Arb Sequence softkey, 56
- arb setup
  - softkey, 208
- ARMED annunciator, 9
- arrow keys, 35

---

# Index

ASK Depth softkey, 247, 251, 253, 254, 255, 256, 257, 261  
ASK softkey, 247, 251, 253, 254, 255, 256, 257, 261  
ATTEN HOLD annunciator, 9  
Atten/ALC Control softkey, 37, 39  
Auto softkeys  
    (DHCP/Auto-IP), 25  
    Auto, 101  
    Recall, 111  
AUTOGEN\_WAVEFORM file, 244  
auto-IP, 25  
Auto-IP softkey, 25  
Automatically Use USB Media If Present softkey, 51  
AUX I/O connector, 17  
Auxiliary Software Options softkey, 30  
AWGN  
    adding, 229, 9  
    definition, 323, 229  
    softkeys, 235  
AWGN softkeys, 230, 231, 232, 233

## B

backspace hardkey, 35  
bandwidth ratio, 235  
Bandwidth softkey, 235  
baseband, 17  
    aligning signals at, 146  
    clipping, 169  
    frequency offset  
        softkey location, 184  
    , 184  
    I/Q output connectors, 15  
    memory, 130  
    noise, 229, 9  
    quadrature adjustment, 192  
    real time I/Q AWGN, 230, 231, 232, 233, 235  
    softkey, 184, 191  
    waveforms convert to analog, 179  
baseband frequency offset  
    DAC over range & scaling, 186  
    softkey, 184  
baseband generator, 244  
    custom arb mode, 4  
    dual arb mode, 5  
    multiple BBG resynchronization, 209, 4, 5, 303  
    two-tone mode, 297  
BB GEN, 191  
BBG  
    media, 130, 132, 323  
    Memory softkey, 56  
    routing, 191  
    Segments softkey, 51, 139  
BBG sync, 209  
    configure setup, 213  
    equipment setup, 213

    resynchronization, 215  
    system, 212  
    trigger setup, 212  
BbT, 323  
Binary softkey, 51  
bit file editor, using, 252  
bits per symbol, equation, 292  
Bk Sp hardkey, 35  
Bluetooth softkey, 246, 247, 250, 251, 253, 254, 255, 256, 257, 261  
BNC, 323  
Bright Color softkey, 20  
brightness adjustment, 20  
Brightness softkey, 20  
Buffered Trig softkey, 163  
Build New Waveform Sequence softkey, 135, 159  
Burst Envelope softkey, 189  
Bus softkey, 41

## C

C/N, 323  
C4FM softkey, 247, 251, 253, 254, 255, 256, 257, 261  
cables  
    crossover, 25  
    multi-BBG sync, 212  
cables, 100Base-T LAN, 25  
Calculate softkey, 139  
calibration  
    I/Q, 194  
    softkey, 194  
Calibration Type softkey, 194  
Cancel hardkey, 7  
carrier  
    bandwidth, 229  
    configuring, 38  
    feedthrough, 127  
    modulating, 48  
    softkeys, 230, 231, 232, 233  
    to noise ratio, 229  
Carrier Bandwidth softkey, 230, 231, 232, 233  
carrier feedthrough, minimizing, 300  
Carrier Softkey, 230, 231, 232, 233  
Carrier to Noise softkey, 230, 231  
Carrier+Noise softkey, 230, 232, 233  
Catalog Type softkey, 51, 52, 56, 139  
catalog, state files, 60  
ccw, 323  
CDPD softkey, 246, 247, 250, 251, 253, 254, 255, 256, 257, 261  
ceiling function, bits per symbol, 292  
Channel Band softkey, 37, 39  
channel bandwidth, 235  
Channel Number softkey, 37, 39  
circular clipping, 173, 176  
classified. *See* security  
Clear softkeys

- Error Queue(s), 62
  - Header, 139
  - Text, 35
  - clipping
    - circular, 173, 176
    - rectangular, 174, 177
    - softkeys, 169
  - clock, sample rate, 17
  - coefficient values, entering, 199, 284
  - color palette, display, 20
  - comments, adding & editing (instrument state), 58
  - component test, 244
  - Config Type softkey, 25
  - Configure softkeys
    - Cal Array, 83
    - List Sweep, 41, 44
    - Step Array, 83, 41, 43
  - Confirm Load From File softkey, 55
  - Connection Monitoring softkey, 25
  - Connection Type softkeys
    - Sockets, 86
    - USB, 86
    - VXI-11, 86
  - connectors
    - external triggering source, 166, 168
    - front panel, 5
    - rear panel
      - n5161a, 12
      - , 42
  - Continuous softkey, 163
  - continuous step sweep example, 47
  - continuous wave
    - description, 4
  - continuous wave output, 38
  - contrast adjustment, 20
  - Contrast softkey, 20
  - Copy & softkeys
    - Play Sequence, 55
    - Select User Flatness, 55
  - Copy softkeys
    - All Files, 56
    - File, 51, 56
  - correction array (user flatness), 88
    - viewing, 89
    - See also* user flatness correction
  - corrections, internal channel, 91
  - cosine filter. *See* nyquist filter
  - Create Directory softkey, 51, 56
  - crossover cable, 25
  - custom
    - multicarrier TDMA waveforms
      - creating, 278
    - TDMA digital modulation, 265
  - custom arb, 220, 244
  - Custom ARB softkeys, 220, 245, 249
    - custom arb waveform generator, 4
    - custom mode, 244
    - custom modulation
      - adding to a waveform, 265
      - waveform, adding to, 265
    - cw, 323
    - CW (no modulation) softkey, 44
    - CW mode
      - description, 4
- ## D
- DAC over range error, 179, 184
  - DAC over range protection
    - baseband frequency offset, 186
    - phase noise, 242
  - Dark Color softkey, 20
  - data
    - entry softkeys, 35, 307
    - files, 50–57
      - removing, 307
    - serial, synchronizing, 17
      - comments, adding and editing, 58
      - troubleshooting, 315, 61
      - using, 50
  - data files
    - creating, 253
    - modifying, 256
  - date, setting, 22
  - dc offset, 127
    - removing, 67
  - DCFMΦ/DCfM Cal softkey, 65
  - Declassifying faulty instrument, 307
  - DECT softkey, 246, 250
  - Default Gateway softkey, 25
  - default settings
    - restoring, 21, 25, 194
    - system, restoring, 34
  - Default softkey, 246, 250
  - delay
    - I/Q, 192
    - multiple BBG sync, 212
  - Delete softkeys
    - All Regs in Seq, 57, 132, 51, 57, 111, 135, 159
    - File, 51, 53, 56, 61
    - Item, 44
    - Row, 44
    - Selected Waveform, 135, 159, 57
    - Waveform Sequence, 159
  - description & plots, phase noise, 239
  - DETHTR annunciator, 10
  - Device softkey, 37, 39
  - DHCP, 25, 323
  - DHCP softkey, 25
  - Diff Mode softkeys, 192
  - differential encoding, 290

---

# Index

differential encoding, bits per symbol, [292](#)  
differential state map, bits per symbol, [292](#)  
DIGBUS annunciator, [10](#)  
digital bus, [16](#)  
digital modulation  
  formats, [4](#)  
  IQ map, QAM, [291](#)  
  multitone, [303–306](#)  
  TDMA, [265](#)  
  two tone, [297–302](#)  
digital modulation type  
  modifying, [268](#)  
digital operation, [129, 221](#)  
digital signal to analog waveform, [179](#)  
display  
  blanking, [307](#)  
  error message area, [11](#)  
  overview, [5, 9](#)  
  secure, [307, 20, 11, 19, 35, 150](#)  
  tests, [317, 11, 310](#)  
Display softkeys  
  Case, [35](#)  
  display, [19](#)  
  Waveform And Markers, [150](#)  
Displayed Case softkeys, [35](#)  
distortion, troubleshooting, [311](#)  
DNS Server Override softkey, [25](#)  
DNS Server softkey, [25](#)  
documentation, [xv](#)  
Domain Name softkey, [25](#)  
doublet  
  adjustable, [116](#)  
  softkeys, [114](#)  
  trigger, [116](#)  
Dual ARB  
  FIR table editor, [199, 204](#)  
  real-time modulation, [208](#)  
  user-defined FIR, [199](#)  
dual ARB  
  multi-BBG sync, [209](#)  
  player, [130](#)  
  real-time noise, [229](#)  
  softkeys, [131, 230, 231, 232, 233, 238](#)  
dual arb, [244](#)  
dual ARB player, [5](#)  
Dual ARB Real-Time  
  filters, [198](#)  
dual arbitrary waveform generator, [5](#)  
dual display, power meter, [74](#)  
dwell time, [44, 323](#)  
Dwell Type softkey, [44](#)  
dwell, troubleshooting, [314](#)  
Dynamic DNS Naming softkey, [25](#)  
Dynamic Hostname Services softkey, [25](#)

## E

E4428C, E4438C softkey, [27, 28](#)  
E442xB, E443xB softkey, [27, 28](#)  
E8241A, E8244A, E8251A, E8254A softkey, [27, 28](#)  
E8247C, E8257C, E8267C softkey, [27, 28](#)  
E8257D, E8267D softkey, [27, 28](#)  
EDGE  
  custom digital modulation, predefined, [265](#)  
EDGE softkey, [246, 250](#)  
Edit softkeys  
  Description, [139](#)  
  Noise RMS Override, [139](#)  
  Repetitions, [159, 139](#)  
  Selected Waveform Sequence, [135, 159](#)  
Editing Keys softkey, [35](#)  
Editing Mode softkey, [35](#)  
editor, bit file, [252](#)  
Enable/Disable Markers softkey, [135, 159](#)  
Enter Directory softkey, [55](#)  
entry, active, [323](#)  
equalization  
  filter, [196](#)  
equipment setup, [213](#)  
equipment, user flatness correction, [84, 85](#)  
Erase All, [307](#)  
Erase and Sanitize All, [307](#)  
ERR annunciator, [10](#)  
Error hardkey, [62](#)  
error messages, [62](#)  
  DAC over range, [179, 184](#)  
  display area, [11](#)  
  message format, [62](#)  
  types, [316](#)  
Esc hardkey, [7](#)  
EVENT  
  connector, AUX I/O, [17, 16, 145](#)  
  output jitter, [161, 145](#)  
EVM, [323](#)  
EVM error, [127](#)  
example  
  Waveform license, Opt 25x  
    adding a waveform, [226](#)  
    locking a slot, [226](#)  
examples  
  FIR filters  
    creating, [199, 281, 283](#)  
    modifying, [204, 287](#)  
  LF output, configuring, [69](#)  
Execute Cal softkey, [194](#)  
EXT CLOCK connector, [16](#)  
EXT REF annunciator, [9, 10](#)  
Ext softkeys  
  Delay, [164](#)  
  Ext, [41](#)



- I/Q Output, 189, 190
  - Pulse, 114
  - Source, 164
  - extension, file, 55
  - external
    - I and Q signals, 191
    - media, 61, 315, 67
    - reference oscillator, using, 38
    - trigger source, 166, 168
  - external leveling, 93–100
    - softkeys, 93
  - external leveling, configuring, 97
  - External softkeys
    - External, 189
    - Input, 192, 126
    - Output, 192
- F**
- factory defaults, restoring, 21, 25, 194
  - features, 2
  - feedthrough, 127
  - feedthrough, carrier, minimizing, 300
  - File hardkey, 51, 60
  - file headers
    - creating, 139
    - editing, 141, 142
    - viewing a different file, 143
  - files
    - catalog. *See* data storage
    - extensions, 55
    - working with, 50
  - filter
    - equalization, 196
    - real-time modulation
      - softkey location, 208
    - user, equalization, 196
  - filter, interpolator, 179
  - filters
    - finite impulse response, 198, 281
      - FIR, 198, 281
      - gaussian, loading default, 205, 288
      - nyquist, selecting, 269
    - filters Dual ARB, 198
  - finite impulse response filters
    - using, 198, 281
  - FIR filter
    - apodization settings, 205, 288
    - Hamming, 205, 288, 205, 288
    - Kaiser, 205, 288
    - window settings, 205, 288
  - FIR filters
    - Arb Custom, 281
    - creating, 199, 281, 283
    - modifying, 204, 287
    - storing, 203, 286
    - using, 198, 281
  - FIR table editor
    - accessing, 199, 283
    - Arb Custom, 287
    - coefficients, duplicating, 201, 285, 199, 284, 206, 289
    - Dual ARB, 199, 204
    - files, loading, 205, 288
      - creating, 199, 281, 283
      - modifying, 204, 287
      - storing, 203, 207, 286, 290
    - oversample ratio, setting, 202, 285
  - firmware
    - upgrading, 23, 321
  - First Mkr Point softkey, 150
  - First Sample Point softkey, 150
  - Fixed softkey, 101
  - flat bandwidth, 235
  - flatness correction. *See* user flatness correction
  - Flatness softkey, 83
  - FM
    - annunciator, 10
    - dc offset, removing, 67
    - external source, 67
    - hardkey, 63
    - softkeys, 63
  - Free Run softkey, 41, 108, 163
  - Free-Run softkey, 114
  - Freq Dev softkey, 247, 251, 253, 254, 255, 256, 257, 261
  - FREQ hardkey, 37, 39
  - Freq softkeys, 83
  - frequency
    - display area, 9
    - hardkey, 7, 8, 37, 39
    - LF output, 70
      - start and stop, swept-sine, 71
    - modulation, 63, 106
    - offset, 104, 184
    - reference, 105
    - setting, 37, 39, 37, 39
  - frequency units, 37
  - front panel
    - disabling keys, 307, 9
    - I/Q inputs, using, 127
    - knob resolution, 22
    - overview, 5
    - tests, 317
  - FSK softkey, 247, 251, 253, 254, 255, 256, 257, 261
  - FTP Server softkey, 26
  - fundamental operation *See* basic operation
- G**
- Gated softkey, 114, 163
  - gated triggering, 164, 166
  - Gaussian
    - definition, 323

---

# Index

gaussian filter, loading default, [205, 288](#)

Gaussian. *See* AWGN

glossary, [323](#)

Go To Default Path softkey, [51, 53, 61](#)

Goto Row softkey, [44, 51](#)

GPIB

connector, [14](#)

definition, [323](#)

setup, [24](#)

Address, [24](#)

Setup, [24](#)

green LED, [8](#)

GSM softkey, [246, 250](#)

guides, content of, [xv](#)

## H

hardkeys

definition, [323](#)

help on, [34](#)

overview, [5](#)

*See also* specific key

header utilities softkeys, [139](#)

Help hardkey, [7, 34](#)

Hostname softkey, [25](#)

hostname, setting, [25](#)

HP 3300A, emulating, [111](#)

## I

I connector, [8](#)

I Offset softkey, [192](#)

I OUT connector, [15](#)

I/O Config softkey, [19](#)

I/Q

adjustments, [127, 192](#)

front panel inputs, using, [127, 191](#)

Int Equalization Filter softkeys location, [197](#)

modulation, [126, 188](#)

optimizing, [190](#)

rear panel outputs, [15, 190](#)

signal path, optimizing, [190, 146, 197, 126, 189–195](#)

waveform, clipping, [169](#)

ideal low-pass filter. *See* rectangular filter

IF, [323](#)

images, [127](#)

impairments

I/Q adjustments, [127](#)

impairments, real-time

phase noise, [237](#)

Import Waveform softkey, [159](#)

improve non-harmonics, [37](#)

Incr Set hardkey, [8](#)

information, removing from memory, [307](#)

Insert softkeys

Insert, [135, 44](#)

Row, [44](#)

Waveform, [135](#)

Install Assembly softkey, [31](#)

Install licenses softkey, [55](#)

installation guide content, [xv](#)

instrument

firmware, upgrading, [23](#)

softkeys

Adjustments, [19](#)

Info, [19](#)

Options, [30](#)

associating with waveform, [58](#)

files, [57, 60](#)

register. *See* data storage

softkey, [56](#)

Int Equalization Filter

softkeys, [197](#)

int media, [323](#)

Int Phase Polarity softkey, [189](#)

interface

GPIB, [24](#)

LAN, [25](#)

internal

reference oscillator, using, [23](#)

Internal Baseband Adjustments softkey, [192](#)

internal media, [61](#)

Internal Storage to USB softkey, [56](#)

Internal/USB Storage Selection softkey, [51](#)

interpolator filter, [179](#)

IP

Address softkey, [25](#)

address, setting, [25](#)

definition, [324](#)

IQ map, QAM modulation, [291](#)

## J

jitter on EVENT output, [161](#)

## K

keyboard, using, [111](#)

keys

disabling, [307](#)

front panel, [5](#)

help on, [34](#)

numeric, [6](#)

test, [317](#)

*See also* specific key

knob, [8, 22, 35](#)

## L

L annunciator, [10](#)

LAN

connector, [14](#)

definition, [324](#)

Services Setup softkey, [24](#)

setup, [25](#)

- Setup softkey, 24
- Last Mkr Point softkey, 150
- Last softkey, 21
- LEDs, 8
  - blink test, 317
  - front panel, 8
  - modulation, 49
- leveling
  - external, 93–100
  - turn off ALC, 101
- LF Out, 69
- LF output
  - amplitude, 70, 71
  - configuration example, 70, 71
  - description, 69
  - frequency, 70
  - source
    - function generator, 71
    - internal modulation monitor, 70
    - start frequency, 71
  - waveform, 64, 69, 71
- LFO. *See* LF output
- licenses
  - manager, 29
  - service software, 29
  - time-based, 22, 321
  - viewing, 29
  - waveform, 29
- line power (green) LED, 8
- linear sweep, 42
- list mode values, 45
- List softkey, 51
- list sweep
  - parameters, 45
  - status information, 45
  - troubleshooting, 314
  - using, 44
  - waveform, 46
- listener mode annunciator, 10
- LO, 324
- Load From Selected File softkey, 53, 55
- Load List softkey, 55
- Load softkeys
  - All From Int Media, 132
  - Cal Array From Step Array, 83
  - From Selected File, 54, 55
  - Load/Store, 44, 54, 55
  - Segment From Int Media, 132, 55
- Load/Store softkey, 44, 53, 55
- Local hardkey, 7
- lock up, troubleshooting, 310
- logarithmic sweep, 42
- low frequency output. *See* LF output
- low spurs, 37
- LVDS compatibility with the PXB, 3
- LXI, 324
- M**
- manual control, sweep, 48
- Manual softkey, 101
- Manual softkeys
  - Config Settings, 25
  - Manual, 25, 41
  - Point, 41
- manuals, content of, xv
- Marker softkeys, 150
- markers, aligning signal, 146
- markers, waveform, 145–161
- media
  - BBG, 323
  - erasing, 307
  - Flash Drive, 61
  - int, 323
  - storage, 61
  - types, 130, 307
  - USB, 61, 315
- memory
  - erasing data from, 307
  - See also* media
- menu keys, 6
- messages, error, 316
- messages, warning
  - Opt 25x Licensing, 228
- mirror table, duplicating coefficients, 201, 285
- mixer, troubleshooting signal loss, 312
- Mod On/Off hardkey, 7, 48, 49
- Mod On/Off, Option UNT, 63
- Mod Type Softkeys, 247, 251, 253, 254, 255, 256, 257, 261
- Mode hardkey, 131, 230, 231, 232, 233, 235, 238
- mode, modulation, 324
- modes of operation, 4
- Modulated softkey, 101
- modulation
  - AM, 63
  - analog, 4
    - configuring, 64, 69
    - , 10
    - carrier signal, 48
    - digital, 4
    - external source, using, 67
  - FM, 63
  - generating, 48
  - I/Q, 126, 188
  - phase, 63, 4, 113
  - real-time filter, softkeys, 208
  - simultaneous, 50
  - troubleshooting, 310
- Modulator Atten softkey, 235
- monochrome display, setting, 20
- Monochrome softkey, 20

# Index

MSK softkey, [247](#), [251](#), [253](#), [254](#), [255](#), [256](#), [257](#), [261](#)

MULT annunciator, [10](#)

multi-BBG sync, [209](#)

  configure setup, [213](#)

  equipment setup, [213](#)

  resynchronize, [215](#)

  system delay, [212](#)

  trigger setup, [212](#)

multicarrier setup

  APCO 25 w/C4FM, [278](#)

  Bluetooth, [278](#)

  CDPD, [278](#)

  DECT, [278](#)

  EDGE, [278](#)

  GSM, [278](#)

  NADC, [278](#)

  PDC, [278](#)

  TETRA, [278](#)

multicarrier setup softkeys, [278](#)

multicarrier TDMA waveforms

  creating, [278](#)

multicarrier, Default softkey. *See* quick setup, Default softkey, settings

multiplier, using, [106](#)

multitone, [244](#), [303](#)–[306](#)

multitone mode, [4](#), [5](#)

Multitone softkeys, [303](#)

multitone waveform, setup, [297](#)

## N

NADC softkey, [246](#), [250](#)

Name And Store softkey, [159](#)

Next REG softkey, [111](#)

Next SEQ softkey, [111](#)

No action softkey, [55](#)

No Retrigger softkey, [163](#)

noise, [229](#)

noise bandwidth factor, [229](#)

Noise Bandwidth softkey, [230](#)

Noise Mux softkeys, [232](#), [233](#)

Noise softkey, [230](#), [232](#), [233](#)

non-harmonics, [37](#)

non-volatile memory, [130](#)

non-volatile, definition, [324](#)

number keys, [35](#)

numeric keypad, [6](#)

nyquist filter

  definition

nyquist filter, selecting, [269](#)

## O

OFFS annunciator, [10](#)

offset, [127](#)

offsets

  baseband frequency, [184](#)

I/Q, [192](#)

  output, using, [104](#)

on/off switch, [8](#)

operation

  modes of, [4](#)

operation, basic, [33](#)

operation, remote, [24](#)

optimization, I/Q, [126](#), [189](#)

option

  430

    multitone mode, [303](#)

    two tone mode, [297](#)

Option U01, [91](#)

  internal channel correction, [91](#)

Option UNT

  Mod On/Off hardkey, [63](#)

options

  651/652/654

    description, [4](#)

    multitone mode, [303](#)

    two-tone mode, [297](#)

  4

  enabling, [19](#), [29](#)

  resource, [3](#)

  UNT, [4](#)

Options 250-259, [221](#)

Options Info softkey, [30](#)

oscillator, external reference, [38](#)

oscillator, internal reference, [23](#)

Output Blanking softkey, [37](#), [39](#)

Output Mux softkeys, [230](#)

output, swept, [40](#)

over range error, DAC, [179](#), [186](#), [242](#)

overshoot, [179](#)

overview, signal generator, [1](#)

## P

Page Up hardkey, [6](#)

parameters, saving a waveform's, [139](#)

path delay, [127](#)

PATT TRIG IN connector, [16](#)

Patt Trig In softkeys, [164](#)

PDC softkey, [246](#), [250](#)

peak-to-average power, reducing, [173](#)

performance, optimizing, [73](#)

persistent settings

  definition, [324](#)

  resetting, [34](#), [21](#)

phase noise

  adjustments, [241](#)

  DAC over range & scaling, [242](#)

  description & plots, [239](#)

  impairments, [237](#)

  softkeys, [238](#)

Phase Ref Set softkey, [37](#), [39](#)

- phase skew, [127](#)
  - PHS softkey, [246](#), [250](#)
  - pixel test, [317](#)
  - Plot CDDF softkey, [178](#)
  - PM Config
    - Calibrate Sensor, [86](#)
    - Zero Sensor, [86](#)
  - PM Config softkeys
    - Connection Type, [86](#)
    - PM VXI-11 Device Name, [86](#)
  - Point Trigger softkey, [41](#)
  - point-to-point time, [324](#)
  - polarity, external trigger, [164](#)
  - polarity, marker, setting, [158](#)
  - power
    - meter, [82](#), [87](#)
    - on, settings, [21](#)
    - peak-to-average, reducing, [173](#)
    - receptacle, [12](#)
    - search, [102](#), [104](#), [84](#), [85](#), [37](#), [39](#), [19](#), [21](#), [101](#), [310](#), [8](#)
    - troubleshooting, [311](#)
    - user settable, maximum, [39](#)
  - Power Control Mode softkeys, [231](#)
  - power meter
    - configuration, [87](#)
    - U2000 Series, [87](#)
    - dual display, [74](#)
  - power meter configuration softkeys. *See* PM Config softkeys
  - power meter softkeys. *See* PM Config softkeys
  - Power Search Reference softkey, [101](#)
  - Power Search References, [102](#)
  - Power softkeys
    - On, [21](#), [19](#)
    - Search, [101](#)
  - power units, [37](#)
  - preferences, setting, [19](#)
  - preset
    - hardkey location, [7](#)
    - settings, [21](#)
    - troubleshooting, [315](#)
    - using, [34](#)
  - Preset softkeys
    - Language, [21](#), [44](#), [83](#)
    - Preset, [21](#)
  - Prev REG softkey, [111](#)
  - Prev SEQ softkey, [111](#)
  - Proceed With Reconfiguration softkey, [25](#), [26](#)
  - programming guide content, [xv](#)
  - protection, DAC over range
    - baseband offset frequency, [186](#)
    - phase noise impairment, [242](#)
  - PSK softkey, [247](#), [251](#), [253](#), [254](#), [255](#), [256](#), [257](#), [261](#)
  - pulse
    - annunciator, [10](#)
    - characteristics, [115](#), [13](#)
    - marker, viewing, [155](#), [113](#)
    - narrow, [101](#)
    - sync signal, [42](#)
    - video signal, [42](#)
  - Pulse hardkey, [114](#)
  - pulse modulation, [4](#)
  - Pulse softkeys, [42](#), [114](#)
  - Pulse/RF Blank softkey, [150](#)
  - PWT softkey, [246](#), [250](#)
- ## Q
- Q connector, [8](#)
  - Q Offset softkey, [192](#)
  - QAM modulation IQ map, [291](#)
  - QAM softkey, [247](#), [251](#), [253](#), [254](#), [255](#), [256](#), [257](#), [261](#)
  - quadrature adjustment, [192](#)
  - quadrature angle, [127](#)
  - Quadrature Angle Adjustment softkey, [126](#), [192](#)
  - queue, error, [62](#)
  - quick setup
    - Default softkey settings, [246](#), [250](#)
  - Quick Setup Softkeys, [246](#), [250](#)
- ## R
- R annunciator, [10](#)
  - raised cosine filter. *See* nyquist filter
  - real time, [220](#), [244](#)
  - real-time
    - AWGN
      - softkeys, [230](#), [231](#), [232](#), [233](#)
    - I/Q Baseband AWGN softkeys, [235](#)
    - modulation filter, [208](#)
    - noise, [229](#)
    - phase noise, [237](#)
      - adjustments, [241](#)
      - DAC over range & scaling, [242](#)
      - description & plots, [239](#)
      - impairments, [237](#)
      - softkeys, [238](#)
  - real-time AWGN,bandwidth ratio, [235](#)
  - real-time AWGN,channel bandwidth, [235](#)
  - real-time AWGN,flat bandwidth, [235](#)
  - real-time modulation
    - Dual ARB, [208](#)
  - real-time modulation filter
    - softkey, [208](#)
  - rear panel
    - I/Q outputs, [190](#)
    - overview
      - n5161a, [12](#)
  - Recall hardkey, [57](#)
  - Recall keys
    - hardkey, [111](#)

# Index

Instrument State, [51, 55](#)  
Reg, [111](#)  
State, [55](#)  
recall register, troubleshooting, [314](#)  
receiver test, [244](#)  
rectangular clipping, [174, 177](#)  
rectangular filter  
  definition, [324](#)  
REF annunciator, [10](#)  
REF IN connector, [13](#)  
Ref Oscillator Ext Bandwidth key, [38](#)  
Ref Oscillator Ext Freq key, [38](#)  
Ref Oscillator Source softkey, [37, 39](#)  
Ref Oscillator Tune key, [23](#)  
reference oscillator tune, internal, [23](#)  
reference oscillator, external, [38](#)  
reference, using, [105](#)  
references, content of, [xv](#)  
regrowth, spectral, [172](#)  
remote interface, emulate HP 3300A, [111](#)  
Remote Language softkey, [24, 27, 28](#)  
remote operation annunciator, [10](#)  
remote operation preferences, [24](#)  
Remove Assembly softkey, [31](#)  
Rename File softkey, [51](#)  
Rename Segment softkey, [132](#)  
Reset & Run softkey, [163](#)  
Restart on Trig softkey, [163](#)  
Restore softkeys  
  LAN Settings to Default Values, [25](#)  
  System Settings to Default Values, [21](#)  
resynchronize, multi-BBGs, [215](#)  
Return hardkey, [8](#)  
Reverse Power Protection softkey, [21](#)  
Revert to Default Cal Settings softkey, [194](#)  
RF  
  blanking  
    marker function, [156](#)  
    settings, saving, [146](#)  
  hardkey, [7](#)  
  output  
    configuring, [38, 7](#)  
    leveling, external, [93–100](#)  
    troubleshooting, [310](#)  
RF During Power Search softkey, [101](#)  
RF Output softkey, [189, 190](#)  
RFC NETBIOS Naming softkey, [25](#)  
ringing, [179](#)  
ripple, [179](#)  
RMS, [324](#)  
RMS softkey, [101](#)  
Rohde & Schwarz softkey, [27, 28](#)  
root, [324](#)  
root cosine filter. *See* root nyquist filter  
root mean square, [324](#)

Root Nyquist Filter  
  definition, [324](#)  
root nyquist filter  
  definition, [324](#)  
rotary knob, [35](#)  
Route Connectors softkey, [41, 114](#)  
Route To softkeys, [42, 114](#)  
routing  
  I/Q, [126, 189](#)  
  marker  
    ALC hold, [147](#)  
    RF blanking, [156](#)  
    saving settings, [146](#)  
RPG test, [317](#)  
runtime scaling, [181](#)

## S

S annunciator, [10](#)  
sales, Agilent offices, [321](#)  
sample rate clock, [17](#)  
sample rate softkey, [161](#)  
Save hardkey, [57](#)  
SAVE Seq Reg softkey, [57](#)  
Save Setup To Header softkey, [139](#)  
Scale Waveform Data softkey, [178](#)  
scaling softkeys, [178](#)  
SCPI  
  enabling, [26](#)  
  reference content, [xv](#)  
  softkey, [27, 28](#)  
screen saver settings, [20](#)  
Screen Saver softkey, [20](#)  
search, power, [102](#)  
secure  
  display, [307](#)  
security, [307](#)  
Security softkey, [51](#)  
Segment Advance softkey, [163](#)  
segment advance triggering, [164](#)  
segments  
  advance triggering, [165](#)  
  file headers, [139](#)  
  loading, [132](#)  
  softkeys, [132](#)  
Select hardkey, [35](#)  
Select Seq softkey, [111](#)  
Select softkeys  
  Color Palette, [20](#)  
  Different Header, [139, 143](#)  
  Header, [139](#)  
  Internal File(s) to Copy to USB, [56](#)  
  Reg, [57](#)  
  Seq, [57](#)  
  Waveform, [44](#)  
self test, [318](#)

- Sequence softkey, [51, 139](#)
  - sequences
    - editing, [137](#)
    - file headers, [139](#)
    - marker control, [158](#)
    - playing, [138](#)
    - waveform, [135](#)
  - serial data, synchronizing, [17](#)
  - server, enabling, [26](#)
  - service
    - Agilent offices, [321](#)
    - guide content, [xv](#)
    - request annunciator, [10](#)
  - Set Marker softkeys, [150](#)
  - settings, persistent, [324](#)
  - settings, phase noise, [241](#)
  - Show softkeys
    - Alpha Table, [35](#)
    - Waveform Sequence, [135, 159](#)
  - signal generator
    - modes, [4](#)
  - Signal Studio, [3](#)
  - signal studio licenses, [29](#)
  - sinewave, [324](#)
  - Single softkey, [163](#)
  - Single Sweep softkey, [41](#)
  - skew, I/Q, [192](#)
  - Sockets SCPI softkey, [26](#)
  - sockets, enabling, [26](#)
  - softkeys
    - definition of, [325](#)
    - help on, [34](#)
    - label area, [11, 6](#)
    - See also* specific key
  - source settled signal, [42](#)
  - Source Settled softkey, [42, 114](#)
  - Span softkey, [101](#)
  - Specify Default Storage Path for User Media softkey, [51](#)
  - spectral regrowth, [172](#)
  - spectrum analyzer, troubleshooting signal loss, [311](#)
  - square root raised cosine filter. *See* root nyquist filter
  - Square softkey, [114](#)
  - standard, modulation, [324](#)
  - standby (yellow) LED, [8](#)
  - State softkey, [51](#)
  - states, persistent, [324](#)
  - step array (user flatness), [88](#)
    - See also* user flatness correction
  - Step Dwell softkey, [43, 108](#)
  - Step Spacing softkey, [43](#)
  - step sweep
    - spacing, [42](#)
    - troubleshooting, [314](#)
    - using, [42](#)
  - Step/Knob Ratio softkey, [22](#)
  - Storage Type softkey, [53, 61](#)
  - Store Custom Dig Mod State softkey, [248](#)
  - Store To File softkey, [53, 54, 55](#)
  - Stored Segments softkey, [51, 139](#)
  - Subnet Mask softkey, [25](#)
  - Sum softkey, [189](#)
  - sweep
    - annunciator, [10](#)
    - hardkey, [41](#)
    - linear, [42, 45, 42](#)
    - manual control, [48, 4](#)
    - out connector, [13, 42](#)
    - softkeys, [41–48, 114, 42](#)
    - troubleshooting, [314](#)
    - waveform, including, [46](#)
  - SWEEP hardkey, [41](#)
  - Sweep softkeys, [41–48, 56, 114](#)
  - swept output, [40](#)
  - switch, power, [8](#)
  - SWMAN annunciator, [10](#)
  - synchronize multi-BBGs, [209](#)
    - configure setup, [213](#)
    - equipment setup, [213](#)
    - resynchronize, [215](#)
    - system delay, [212](#)
    - trigger setup, [212](#)
  - system defaults, restoring, [21](#)
- ## T
- T annunciator, [10](#)
  - talker mode annunciator, [10](#)
  - TCP, [325](#)
  - TCP Keep Alive softkeys, [25](#)
  - TDMA
    - custom digital modulation, predefined, [265](#)
  - TDMA digital modulation, [265](#)
  - terminator, [325](#)
  - test, self, [318](#)
  - test, self-web-enabled, [318](#)
  - tests, front panel, [317](#)
  - TETRA softkey, [246, 250](#)
  - text area (on display), [11](#)
  - text entry softkeys, [132](#)
  - time, dwell, [323](#)
  - time, setting, [22](#)
  - time/date reference point, [22](#)
  - Time/Date softkey, [22](#)
  - time-based license, [22, 321](#)
  - Timer Trigger softkey, [41, 108](#)
  - Toggle softkeys, [159](#)
  - Total Noise softkey, [231](#)
  - Total softkey, [231](#)
  - Trig
    - in connector, [13](#)
    - out connector, [42](#)

---

# Index

trigger  
  connectors, 13  
  hardkey, 7  
  initiating, 7  
  multiple BBG sync, 212  
Trigger setup softkeys, 110  
Trigger softkeys  
  & Run, 163  
  Doublet, 114  
  Key, 41  
  Out Polarity, 41  
  Source, 162  
  Triggered, 114, 162  
Triggered softkey, 114  
triggering  
  gated, 164, 166  
  multiple BBG sync, 212  
  equipment setup, 213  
  segment advance, 164, 162  
  waveforms, 162  
troubleshooting, 309  
two tone, 244, 297–302  
two tone softkeys, 298  
two-tone softkeys, 298  
two-tone waveform, setup, 297  
type, modulation, 324

**U**

UNLEVEL annunciator, 10  
unleveled operation, 101  
UNLOCK annunciator, 10  
Unspecified softkey, 139  
UNT, option, 4  
UNU, option, 4  
UNW, option, 4  
Up Directory softkey, 51, 53, 56  
Update in Remote softkey, 20  
urls, 3, 23, 29, 321  
USB  
  connecting media, 61  
  definition, 325, 14  
  host connector, 5, 14  
  keyboard, using, 111  
  softkeys  
    File Manager, 51, 52  
    Keyboard Control, 111  
  to BBG Memory softkey, 56, 315  
Use softkeys  
  As, 55  
  Current Directory As Default Path, 51, 61  
  Only Internal Storage, 51  
user  
  documentation content, xv  
  files, backup and restore, 50, 82  
  preset, 34, 315

user files  
  modifying, 256  
user files, data, 253, 256  
user FIR  
  definition, 325  
User softkeys  
  Configure Power Meter, 83, 53  
  Do Cal, 83  
  Flatness, 37, 39, 51, 83, 56  
  Span, 101  
  User, 21  
user-defined FIR  
  Dual ARB, 199  
Utility hardkey, 19  
Utility softkey, 31

## V

vector operation, 129, 221  
View Next Error Page softkey, 62  
View Previous Error Page softkey, 62  
volatile memory, 130, 132  
volatile, definition, 325  
VXI-11, enabling, 26  
VXT-11 SCPI softkey, 26

## W

waveform  
  adding custom modulation, 265  
Waveform license, Opt 25x  
  adding a waveform, 223  
  backup warning, 228  
  file missing warning, 228  
  license status messages, 225, 221, 228  
  replacing a waveform, 223  
  status messages, 225  
  using, 221  
  waveform licensing softkeys, 223  
Waveform softkeys  
  Licenses, 30  
  Runtime Scaling, 178  
  Segments, 132, 135, 159  
  Utilities, 178  
  Waveform, 41, 44  
waveforms  
  clipping, 169  
  file headers, 139, 179  
  in a sweep, 46  
  license, 29  
  markers, 145, 146, 209, 303–306  
  overview, 130  
  saving instrument state, 58, 178, 132, 135, 132  
  triggering, 162, 297–302  
Web Server softkey, 26  
wideband AM, 67  
window settings, FIR filter, 205, 288



WINT annunciator, [10](#)

## **Y**

yellow LED, [8](#)

## **Z**

Zoom softkeys, [150](#)

---

# Index